STANDING PLATFORM

PARTS: Standing Platform



ATTACHMENT INSTRUCTIONS

TO BEGIN INSTALLATION: Remove the folding platform and telescoping squat stand. **STEP 1.** Position the Standing Platform mounting brackets over the holes on the lower rail just above the base with the curve of the handles pointing toward the tower.





STEP 2. Pull the retractable knob on one side of the Standing Platform and slide the bracket over the hole on the rail as shown. **STEP 3.** Release the retractable knob to secure the pin in place. Repeat on the other side. **STEP 4.** Push and pull the Standing Platform to insure both the pins are engaged completely in the rails.





