

INSTRUCTIONS - HOW TO APPLY YOUR STICKERS

Your sticker has three parts:

- the backing paper (underneath the sticker)
- the sticker itself
- the application film (see through paper on top)

You will need:

- brake cleaner or methylated spirits
- masking tape and scissors
- very weak soapy water in a spray bottle
- small squeegee or credit card wrapped in cloth
- soft dry cloth

Please be careful and patient when applying your stickers as we do not replace stickers that have failed as a result of poor fitment. Also, stickers will not last as long if they are positioned where wiper blades will sweep over them.

DO NOT PEEL ANY BACKING PAPER OFF YET - FOLLOW THESE STEPS:

STEP 1

The surface **MUST** be absolutely clean - no wax, oil, dirt, fingerprints etc. Clean the surface with brake cleaner, rubbing alcohol or methylated spirits and a clean rag. Do not touch the adhesive side of the sticker as oils from your skin will affect the adhesion.

STEP 2

Work out exactly where you want the sticker and use a piece of masking tape at each end to hold it in position. On larger stickers, place a strip of tape across the middle as well.

STEP 3

If you are happy with the position, then remove the masking tape from one end only and **carefully** peel back the backing paper about halfway along the sticker. The sticker itself will stay stuck to the application film. Using scissors, cut off the backing paper that you have peeled back.

STEP 4

For large surface area stickers, very lightly spray some soapy water onto the surface and then slowly lay the sticker down from the middle outwards, using the squeegee or credit card wrapped in cloth to **gently** push any bubbles out. **Do not use soapy water** on smaller stickers.

STEP 5

Now that half of the sticker is in place, you can remove the remaining masking tape and carefully remove the remaining backing paper. Then, as per STEP 4, spray some soapy water and then slowly lay down the second half of the sticker, using the squeegee to remove bubbles.

STEP 6

You now have the sticker in place with the application film on top. Make sure all the water and air bubbles have been removed with the squeegee. If water was used, let it sit for 10min and then slowly peel off the application film, ensuring that it does not pick up any parts of the sticker.

STEP 7

Using a soft dry cloth, pad down all parts of the sticker to make sure that they are firmly attached. If you find some bubbles, you can use a pin to pop them and then push on the bubble to remove the air.



**CHEESY
GRIN
DESIGNS**