ပံ QUICK START

Plug in and turn ON your Mella by turning the knob to the right (110/125V - 120 VAC 60hz 132w)

- Adjust the temperature by turning the knob to the right or left
- ✓ Download The Mella App

Register on the App

- → Log In on the App
- + Add Device on the App

You're ready to go!

TROUBLESHOOTING

MELLA IS NOT CONNECTING:

Make sure the knob is in the ON position
Tap the refresh button in the top right corner
Turn Mella OFF, unplug and reboot

MELLA IS NOT TURNING ON WITH APP SCHEDULED TIMES:

Mella must be left in the ON position in order for the scheduled times to work with the App.

MELLA IS NOT TURNING ON OR OFF WITH MANUAL FUNCTION ON APP: Mella must be left in the ON position in order for the Manual ON and OFF to work with the App.

SILICONE SKIN APPLICATION:

Putting the skin on takes practice.
Lining up the hole for the knob is the key to proper fitting
The flexible nature of silicone allows you to adjust by pulling and shifting if necessary

STILL HAVING TROUBLE? Contact us at info@themella.com Video tutorials at www.themella.com

he mella, llc • seattle, washington • patents pending • www.themella.co

MELLA QUICK START GUIDE

NICE TO MEET YOU.

HERE'S A LITTLE BIT ABOUT ME



WAX TIN RECEPTACLE



ON/OFF & TEMPERATURE CONTROL

ROGRAMMABLE APP READINESS

THE APP

1. DOWNLOAD THE MELLA APP Compatible with Android and iOS

2. REGISTER AND LOG IN Protect your username and password

3. ENTER QR SCAN CODE OR DEVICE ID Located on the bottom of device

4. SET UPThis connects your Mella with WiFi
Device must be in ON position

5. NAME YOUR DEVICE Choose a unique username for each device (up to 6)

6. VIRTUALLY TURN ON AND OFF • Tap the circle • Green for ON and red for OFF

7. SET YOUR SCHEDULE
 Tap schedule to automate ON and OFF according to your salon hour
 Choose your ON and OFF time, enable and save

CLEANING & CARE

MY SILICONE SKIN IS EASY TO CLEAN:

FOR SOFT WAX REMOVAL Use a soft cloth with a small amount of oil on the cloth to wipe soft wax off of the silicone skin.

FOR HARD WAX REMOVAL Simply flick the edge and peel off as if you were removing hard wax from a client's skin.

SILICONE SKIN REMOVAL For a deeper clean remove the silicone skin to clean inside and out as desired.

SILICONE SKIN APPLICATION

Practice makes perfect! • Start with the skin inside out • Line up knob hole with the knob • Place one hand inside to steady while the other hand folds down sections • Visit www.themella.com for a complete tutorial

SAFETY NOTE: UNPLUG AND ALLOW TO COMPLETELY COOL BEFORE HANDLING