

HERE'S HOW TO SERVICE YOUR OSCAR G3 AT HOME:

- Inspect all the rivets and screws that connect your stroller together. They should be clean, tight and secure.
- Remove the wheels (back and front) and wipe them clean with a damp clean rag to remove any dirt, sand or other debris. Put a small amount of greasy lubricant, such as Vaseline or Lithium Grease (available from your local Bunnings or Mitre 10), on the front and rear wheel pins before reinserting into stroller. This helps to protect from corrosion and keep things moving smoothly.
- Make sure the fold joints are free of dirt and debris. Wipe clean with a damp cloth. We suggest cleaning the fold joints when the stroller frame is folded. Apply some WD-40 or Silicone spray (available at Bunnings, Mitre 10 or your local supermarket) to the moving hinges.
 - If you have any questions relating to servicing your stroller, email us hello@edwardsandcobaby.com or call New Zealand: 09 869 8950 Australia: 02 90666702

- Make sure the brake calipers are free from dirt, sand and debris. Engage the brake and wipe the calipers clean with a damp cloth. Apply some WD-40 or Silicone spray to the brake calipers and inside the brake housing (behind the brake pedal). Engage and disengage the brake a number of times to coat the parts in Jubricant. To prevent the metal components from rusting, wipe down your stroller frame after beach or rain use, especially when used in windy & exposed areas. Always store in a dry place. Do not store your stroller in a damp environment that is not well insulated (such as an unfinished basement or outdoor shed).
- If you do find some corrosion forming on the rivets or screws, you can wipe it clean with a damp cloth and Jif. Dry it overnight, then apply a clear lacquer afterwards, such as Rust-Oleum Clear spray (available from Bunnings) or clear nail polish. This prevents the corrosion from re-forming.

EDWARSS&CO

Washing instructions

FRAME WASHING INSTRUCTIONS

Clean with a damp rag and a little mild detergent (such as dishwashing liquid or car wash detergent). Dry thoroughly. DO NOT use abrasives (such as "Jif") because they may scratch your stroller frame.

FABRIC WASHING INSTRUCTIONS

For Stroller shoulder pad, Carry Cot cover, Carry Cot liner, Carry Cot mattress cover, Capsule shoulder pad, Capsule canopy

Machine wash (front loader only) in cold water, gentle cycle with mild detergent. Dry flat and away from direct sunlight. Do not dry clean, iron or bleach.



COLD GENTLE CYCLE



DRY FLAT



DRY IN SHADE



DO NOT



DO NOT IRON



For Capsule seat cover, Capsule Newborn Insert, Stroller canopy

Spot clean or hand wash in cold water with mild detergent. Dry flat and away from direct sunlight before re-use or storage. Do not dry clean, iron or bleach.



HAND WASH



DRY FLAT



DRY IN SHADE



DRYCLEAN



DO NOT



BLEACH

For Stroller seat cover

Spot clean with a damp cloth. Do not wet excessively. Do not dry clean, iron or bleach.





