

Toll Free: (844) 372-0710 Email: office@sgworldusa.com FORM: EW-KITPUS - 4/20 Copyright © SG World Ltd. Reproduction prohibited. UK Patent No. 2444312 US Patent No. 7930846

Audit Date		Name of Auditor (Print)		<b>REMEMBER - WHEN ASSOCIATES ARE USING THE EYE WASH THEY SHOULD FLUSH THEIR EYES FOR FIFTEEN MINUTES</b>		Eye Wash Failings / Notes													
Audit Time								O.K. <input type="checkbox"/> Unsafe <input type="checkbox"/> 4 As necessary											
✓	X	Eye Washes easily identifiable	Clear pathway around the eye wash/showers for easy access	Dust covers clean and disinfected	Eye Wash bowls without cracks, dents or damages	Eye Wash bowls clean from dirt/debris	Shower/eye wash begins water flow within one second of activation	Shower/eye wash must have a continuous water flow	Water pressure removes dust covers	Check water pressure to be certain water height is accessible, but 8 inches of height or less	Ensure enough water flow to cover width of eyes	Water flow a steady even stream from both eye pieces	Flush station for one minute or until water is clear	Dry eye wash with clean cloth after testing	Eye Washes easily identifiable	Clear pathway around the eye wash/showers for easy access	No physical damage to the unit	No debris stored on top of the unit	Ensure the fluid has not been released
WEEKLY EYE WASH AUDIT GUIDE (Plumbed-15)															MONTHLY EYE WASH AUDIT-PORTABLE (Green) (20)				

### EYE WASH AUDIT SLIP

Mark ' ✓ ' in Audit Boxes if OK  
 Mark ' X ' in every box requiring attention

Signature of Auditor

---

Job Title of Auditor