

**Product Description** – SlipDoctors Bathtub Grip is an all-in-one treatment that contains everything you need to help make your ceramic, porcelain or enamel bathtub or shower safe. This product is highly effective in areas that stay wet consistently. It is not a coating that can wear off, but a treatment that creates microscopic treads on the surface of the bathtub or tiled shower. Bathtub Grip will not discolor your tub or shower and there will be no appearance change after application. In just 10 minutes, this treatment will help you prevent slip-and-fall accidents in your shower or bathtub for years.

### SlipDoctors Bathtub Grip

#### Special Features

- Barefoot Friendly
- Increases Traction
- Fast & Easy Application
- Application Time 10 Minutes
- Not a Coating
- Long-lasting Results

#### Suggested Uses

- Commercial and Residential
- Bathtubs
- Showers
- Hotels
- Spas
- Locker Rooms

### Product Characteristics and Benefits

<b>Surfaces*</b>	Porcelain, ceramic, enamel, cast iron, steel and natural stone.
<b>Color</b>	Clear solution
<b>Mode of Application</b>	Scrub pad
<b>Size</b>	250ml Bottle
<b>Dry Time</b>	N/A
<b>Water Resistant</b>	N/A
<b>Stain Resistant</b>	N/A
<b>Product Type</b>	Micro-treading solution
<b>Coverage</b>	One standard-size bathtub or standard-size shower
<b>Storage</b>	50°F (10°C) - 80°F (27°C); Protect from freezing
<b>Shelf Life</b>	5 years
<b>Warranty</b>	2 years
<b>Removal</b>	N/A
<b>Disposal</b>	Dispose of container and unused contents in accordance with local, state, and federal regulations.

*\*This product is not for use on fiberglass or acrylic bathtubs or showers.*

## Directions for Preparation, Application and Use

Read entire product label, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) before using.

### Safety Precautions:

- Use in a well-ventilated area

### Optional Safety Equipment:

- Wear a long sleeve shirt
- Eye protection
- Nitrile glove

**Surface Preparation:** Clean the bathtub/shower using a general household cleaner. Rinse several times with clean water. Use a towel to dry the bathtub completely. If possible, remove drain or protect drain by adding tap water to cover it. Avoid extended direct contact with metal surfaces.

### Application Instructions:

- Step 1** Pour contents of the bottle onto the bottom of a standard-size bathtub.
- Step 2** Using a scrub pad, spread the product over the bottom of the bathtub or shower. The solution should cover the entire surface.
- Step 3** Allow the solution to sit for approximately 4-8 minutes, spreading the liquid to keep the surface wet. Do not allow the solution to dry on the surface.
- Step 4** If solution comes in contact with skin, metal or any other surface, wash off immediately.
- Step 5** Open the drain, and thoroughly rinse your bathtub/shower several times and allow to air dry.
- Enjoy your new slip-resistant bathtub or shower!**

**Maintenance:** For general cleaning and maintenance, use a pH-neutral cleaner and soft bristle brush in a circular scrubbing motion to agitate the surface of your shower or tub.

## Precautions & Technical Support

**Please refer to Safety Data Sheet (SDS) for detailed Precautions and First Aid Instructions.**

Bathtub & Shower Treatment Safety Data Sheet can be found at [www.slipdoctors.com](http://www.slipdoctors.com)

**Technical Support:** Please contact SlipDoctors at 1-888-436-5404 or [support@slipdoctors.com](mailto:support@slipdoctors.com)

**Office Hours:** Monday - Friday from 8:00 am - 5:00 pm CST

## Warranty & Disclaimer

**WARRANTY:** All properly installed SlipDoctors products are guaranteed to increase the coefficient of friction of your surface for 2 years (provided surface preparation and cleaning procedures are followed and no contaminants are present). If at any time during the warranty period the treated surface should lose its coefficient of friction, SlipDoctors shall at its option replace any product that proves defective. This warranty applies only to the product itself. Neither the seller nor the manufacturer shall be liable for any injury, loss or damage direct or consequential, arising out of the use or the inability to use the product. Before using, user shall determine the suitability of the product for the intended use, and the user assumes all risk and liability whatsoever in connection therewith. No statement or recommendation not contained herein shall have any force or effect unless in an agreement signed by seller and manufacturer. Buyer assumes all risks and responsibility associated with disposal. SlipDoctors cannot eliminate all possibilities of slip-and-fall accidents. Please visit [www.slipdoctors.com](http://www.slipdoctors.com) to find further warranty information. **KEEP OUT OF REACH OF CHILDREN.**