



ACMOSOL® 133 - 1

Cleaner for pressing plates (especially in processing melamine resin sheets)

BASIS:

No materials are used in the production of **ACMOSOL 133-1** that are categorised as toxic or carcinogenic under the hazardous materials regulations.

PROPERTIES:

ACMOSOL 133-1 is a cleaner used to remove deposits that form on pressing plates.

APPLICATION:

ACMOSOL 133-1 is used as supplied. The cleaner must only be applied to cold plates. After the substance has been left for a short time to take effect, the softened deposit is removed with a cloth. The plate should then be well rinsed with clean water.

Applying **ACMOSOL 133-1** has no effect on the degree of glossiness of pressing plates. It is recommended that the cleaner is applied when even the slightest deposit or discoloration of the plates is observed, because the cleaning process is easiest at this stage.

STORAGE:

Protect from extremes of temperature.
Storage time 12 months.

SUPPLY FORM:

Disposable drum containing 5 kg, 20 kg, 200 kg and 850 kg.

Additional information can be found in the EU safety data sheet.

Our technical service department will gladly advise you on all questions concerning the application of our products. Free samples can be made available to you on request.

All information given is accurate to the best of our knowledge but provided without guarantee.

Bremen, 15 July 2015