


# **MONTANOV**<sup>TM</sup>





# 5 KEY POINTS

## **MONTANOV**<sup>TM</sup>

# to keep in mind!



## Amazing emulsifying capacity!

Used at low levels, **between 0.5 and 3%,** MONTANOV™ emulsifiers significantly reduce the interface tension and can therefore emulsify up to 60% oily phases:

- Vegetable oils
- Mineral oils
- Esters
- Silicones




## **Perfect** harmony with the environment

- 100% vegetable origin sustainable resources
- Non-GM raw materials, solvent and preservative-free
- Original and patented synthesis of fatty alcohols and alkyl polyglucosides







- Excellent skin compatibility
- Excellent biodegradability
- Validated by ECOCERT



## Compatible with the majority of active ingredients ... ... and highly stable at all pH = 3-11

- Glycols
- Glycerin
- Alcohol
- Mineral filters
- Organic sunscreens
- Pigments
- Whitening agents
- Cationic agents
- Reducing agents
- H<sub>2</sub>O<sub>2</sub>

- Oxidizing agents
- AHA
- NaCl
- Mineral salts
- AICI3



## A variety of different applications

MONTANOV™ emulsifiers are recommended for all types of applications:

- Skin care, toiletries, hair care, deodorants ... for the face, body & hair
- For dry, oily, mixed, sensitive and mature skins
- For all types of conventional and more specific products: young problem skins, ethnic skins, men, etc.
- To create **all type of textures** (sprays, lotions, creams, butters & waxes) with a **broad range of skin feeling** (light and evanescent, melting or rich)



## the **best friends**


## for your

## GREEN formulas and concepts!

5

## More than excipients ...


- MONTANOV<sup>™</sup> emulsifiers are excellent **liquid crystal promoters** 
  - In the oily phase, they prevent coalescence thanks to the formation of a rigid shell around oil droplets.
  - In the aqueous phase, the liquid crystals extend to form a **continuous network** of lamellar phases which **provide a dominant elastic character** and a **very good stability** that prevents creaming.




Liquid crystals in an emulsion based on MONTANOV™

Stability of emulsions over time

- MONTANOV™ emulsifiers can be used to formulate emulsions with an **intrinsic moisturizing effect** linked to the presence of liquid crystals:
  - Thanks to the bi-layers similar to those of the skin formed by the liquid crystals, the skin's lipid barrier is reinforced and the skin is protected **against dehydration** ...



Moisturizing properties of MONTANOV™ emulsions - Validated in vivo by Corneometry



Hydration of the skin over time



Reduction of TEWL - In vivo validation

■ MONTANOV™'s emulsions are extremely soft during application and after time

Moderate thixotropy

+ rheofluidifying character of MONTANOV™ ···· Easier to spread

Presence of liquid crystals ..... Provides comfort and softness



## Skin care .... 202 ... 82 ... L ... 68 ... 14 .

#### **7035B SPA BODY MILK**

	■MONTANOV™ 82	1.00%
	■MONTANOV <sup>™</sup> 202	1.00%
Α	■Paraffin oil	5.00%
	<ul><li>Pentaerythrityl</li></ul>	
	tetraethylhexanoate	10.00%
	■SEPICIDE™ HB	1.00%
		sp 100%
R	•Xanthan gum	0.15%
D	■SEPIPLUS™ 400	1.00%
	*3EFIFLU3 400 	1.00%
	■GIVOBIO™ GMg	1.00%
C	■GIVOBIO™ GZn	1.00%
	<ul><li>Glycerin</li></ul>	5.00%
D	<ul> <li>Cyclopentasiloxane</li> </ul>	5.00%
ט	- Cyclopelitasiloxalle	3.00%
Ε	<ul><li>Fragrance</li></ul>	0.30%

#### **7065 ORGANIC DAY CREAM**

Complies with ECOCERT® standards

A	■MONTANOV™ 202	3.00%
	■MONTANOV™ 14	1.50%
	■Behenyl Behenate	2.00%
	<ul><li>Butyrospermum Parkii (ORG)</li></ul>	1.50%
	<ul><li>Squalane</li></ul>	3.00%
	<ul> <li>Glyceryl Undecylenate</li> </ul>	1.50%
	Jojoba oil (ORG)	3.00%
	<ul> <li>Caprylic/Capric Triglycerides</li> </ul>	3.00%
	<ul><li>Isopropyl isostearate</li></ul>	3.00%
	<ul><li>Tocopherol</li></ul>	0.10%
	•Aqua/water Qs	p 100%
В	•Water, hordeum vulgare	
D	plant extract (ORG)	11.00%
	■Xanthan Gum	0.60%
C	■Dehydroacetic Acid	
	and Benzyl Alcohol	0.60%
	■AQUAXYL <sup>™</sup>	3.00%
	Sodium Levulinate	0.50%
	■Sodium Hvdroxide	0.14%

### Men's care

## 6849A NON-GREASY BUTTER CREAM

ЬU	I IER CREAW	
Α	■ MONTANOV™ 202 ■LANOL™ P ■SIMULSOL™ 165 ■Isodecyl neopentanoate ■LANOL™ 99 ■Butyl methoxydibenzoyl methane ■Ethylhexyl methoxycinnama	3.00% 5.00% 2.00% 5.00% 9.00% 2.00% te 5.00%
В	■MICROPEARL™ M305 ■SEPITONIC™ M3 ■SEPICALM™ S ■Disodium EDTA ■Aqua/water	2.00% 1.00% 2.00% 0.20% Qsp 100%
C	■Cyclomethicone ■SIMULGEL™ EG	8.00% 2.50%
D	■Dye ■Fragrance ■Alcohol 95 ■SEPICIDE™ HB	qsp 0.40% 4.00% 0.50%

Non-greasy and light textures that are quickly absorbed by the skin

## Sun care ··· 82 ·· 14 ·· s ·· L

#### **7085 HIGH-PROTECTION SUN SPRAY**

A	■MONTANOV™ L ou 82	1.00%
	C12-15 Alkylbenzoate	17.00%
	<ul><li>Dimethicone</li></ul>	3.00%
	<ul><li>Octocrylene</li></ul>	6.00%
	<ul><li>Ethylhexyl methoxycinnamate</li></ul>	6.00%
	<ul><li>Bis-Ethylhexyloxyphenol</li></ul>	
	Methoxyphenyl Triazine	3.00%
В	-Aqua/water	Qsp 100%
C	■DC345	5.00%
	■SIMULGEL™ INS100	0.50%
	•AQUAXYL	3.00%
D	■DL · Tocopherol acetate	0.50%
U	■SEPICIDE™ HB	1.00%
	■Fragrance	0.20%
E	<ul><li>Methylene bis-benzotriazolyl</li></ul>	
	tetramethylbutylphenol	10.00%
	■Citric acid 25%	QS pH5

To create fluid and sprayable sun care formulas with a high chemical filter and mineral sunscreen content ...

To formulate easy-to-spread, non-sticky sun care products!

## Makeup

Airy formulas ...

To emulsify mineral pigments

2<sup>nd</sup>-skin textures ...

### Hair care

#### 7079 BRIGHTENING CONDITIONING BALM

A	<ul><li>Aqua/water</li><li>Hydroxyethylcellulose</li></ul>	Qsp 100% 1.00%
В	Butyrospermum parkii Cetearyl alcohol MONTANOV™ 82 Behentrimonium chloride Polyquaternium-11 Dimethicone	1.00% 3.00% 2.00% 2.00% 2.00% 1.00%
С	<ul><li>D-panthenol</li><li>SEPICIDE™ HB</li></ul>	0.10% 1.00%
D	■AQUAXYL™ ■Fragrance	2.00% 0.10%

### **COLORING PRODUCTS**

- •Cream consistency stable over time
- Easy mixing of dye and primer
  Good distribution on hair
- No dripping
- For a completely safe, high-performance color

## Toiletries ···· 82 ·· 68 ····

E

#### **7029 FOAMING FACE WASH**

Sodium chloride

A	■Aqua/water ■MONTANOV™ 82 ■PEG-120 methylglucose dioleate ■Lactic acid 12%	Qsp 100% 3.00% 1.00% 4.10%
В	Sodium lauryl ether sulfate 28%	22.00%
C	■Glycerin	5.00%
D	■AMONYL™ 380BA ■Fragrance ■KATHON™ CG	7.00% 0.30% 0.10%

Refattening foam effect + soft

Allows the addition of oils without affecting the foam

To formulate opaque but not pearlescent products!

0.10%



Make the right choice ...

The **BEST MOISTURIZING** grades

MONTANOV™ 202 MONTANOV™ L MONTANOV™ 68

Your best friends for ultra-white creams:

> MONTANOV™ 202 MONTANOV™ L

Formulate ultra-fluid products
(sprays and liquids for impregnating wipes) using a concentration of only 1% ... or MONTANOV™ 82 or MONTANOV™ S

Improve the richness of your GEL-CREAMS ...

Add:

For improved comfort and easier spreading

Offer a **touch of softness** to your conventional formulas by adding:

0,5 to 1% MONTANOV™ S

■ Addition of MONTANOV<sup>™</sup> 14

provides consistency WITHOUT changing the sensory profile

To formulate with high electrolytes content ...

#### combine:

1% MONTANOV™ 202 + 1% MONTANOV™ 82 or to emulsify

1% SEPIPLUS™ 400 + 0.15% Xanthan gum to thicken

To improve the dispersion of mineral sunscreens

add to MONTANOV™ 82: SEPIFEEL™ ONE!

For sun care products with a high chemical and physical filter content ...

Don't forget the winning combination of ...


2% MONTANOV<sup>™</sup> 82 + 1% SENSANOV<sup>™</sup> WR or MONTANOV<sup>™</sup> S + SIMULSOL<sup>™</sup> 165

Easy spreading guaranteed and non-sticky texture




#### **PROCESS:**

#### Heating



or ...



#### **Indirect process**

\*heating at 75°C except for MONTANOV™ 202: 85°C

#### Agitation



The use of a high-shear agitation system (rotor-stator type) is recommended



In the laboratory, we advise you not to start agitation until the two phases are present

#### Cooling



Slow cooling under gentle agitation promotes the formation of liquid crystals

The use of a lower shear (deflocculator-type) is possible if polymers are added in sufficient quantities, at the beginning of the process or during the emulsification, so that the emulsion becomes finer

	202	82	L	68	S Co-emul:	14 sifier
INCI Name	Arachidyl alcohol & Behenyl alcohol & Arachidyl glucoside	Cetearyl alcohol & Coco glucoside	C14-22 alcohols & C12-20 alkyl glucoside	Cetearyl alcohol & Cetearyl glucoside	Coco glucoside & Coconut alcohol	Myristyl alcohol & Myristyl glucoside
Emulsifying capacity	+++	+++	+++	+++	++	+
Liquid crystals	+++	+	+++	+ +	+/-	+/-
Consistency of emulsions	Thick lotion to cream	Variable consistency: spray to thick cream	Variable consistency: spray to thick cream	Fluid to thick cream		
Sensory profile	Light texture, matt finish	Rich texture	Light texture	Rich texture	Rich texture	Neutral texture
Strong points & Specific characteristics	<ul> <li>Whiteness         of the emulsion</li> <li>Matt and silky</li> <li>Long-lasting         moisturizing effect</li> </ul>	Very good resistance to cold (-25°C) Good resistance to electrolytes SPF stable over time	■Emulsion whiteness ■Versatility of use	*Stabilizer not compulsory (if absence of electrolytes)	■Refattener ■SPF stable over time  ■ The stable over	NEUTRAL consistency factor     Soft, non-greasy texture
Specific compatibilities	•Mineral ingredients (makeup)	Chemical filters & mineral screens Cationic (hair care) Anionic (cleansers)	•Mineral ingredients (makeup)		•Chemical filters & mineral screens	
Applications	■SKIN CARE Oily skins Range for men ■HAIR ■MAKE-UP	■SKIN CARE ■SUN CARE ■TOILETRIES ■HAIR	<ul> <li>SKIN CARE         Oily skins         Range for men</li> <li>HAIR</li> <li>MAKE-UP</li> <li>WIPES</li> </ul>	■SKIN CARE ■TOILETRIES ■HAIR	■SKIN CARE ■SUN CARE ■TOILETRIES	■SKIN CARE ■SUN CARE
Melting point	70-80°C	55-60°C	66-72°C	61-65°C	56-60°C	46-50°C

#### www.seppic.com

The analytical specifications warranted are only those mentioned on the certificate of analysis supplied with each delivery of the product.

Except as set forth above, SEPPIC\* makes no warranties, whether express, implied or statutory, as to the product which is the subject of this document. Without limiting the generality of the foregoing, SEPPIC\* makes no warranty of merchantability of the product or of the fitness of the product for any particular purpose. Buyer assumes all risk and liability resulting from the use or sale of the product, whether singly or in combination with other goods. The information set forth herein is furnished free of charge and is based on technical data that SEPPIC\* believes to be reliable. It is intended for use by persons having technical skill and at their own discretion and risk. Since conditions of use are outside SEPPIC\*'s control, SEPPIC\* makes no warranties, express or implied, and assumes no liability in connection with any use of this information. Nothing herein is to be taken as a license to operate underor a recommendation to infringe any patents.

© 2008 SEPPIC - MONTANOV™ is registered as Trade Mark of SEPPIC - SEPPIC\* a subsidiary of the AIR LIQUIDE group.

#### \*SEPPIC being:

#### SEPPIC S.A.

Tour Kupka C 7, boulevard Franck Kupka 92039 Paris La Défense Cedex **FRANCE** 

Tel.: +33 (0) 1 55 91 57 00 Fax: +33(0) 1 55 91 50 50

#### **SEPPIC ITALIA Srl**

Via Quarenghi 27 20151 Milano ITALY

Tel.: +39 02 38009110 Fax: +39 02 38009140

#### **GIVAUDAN LAVIROTTE S.A.**

56, rue Paul Cazeneuve BP 8344 - 69008 Lyon

**FRANCE** 

Tel.: +33 (0) 4 78 61 55 00 Fax: +33 (0) 4 72 05 60 89

#### **SEPPIC China**

Room 510 Jin Tai Building 58 South Mao Ming Road Shanghai 200020 CHINA Tel.: +86 (21) 64 66 01 49 Fax: +86 (21) 64 66 11 09

#### SEPPIC Inc.

30, Two Bridges Road, suite 210 Fairfield, New Jersey 07004-1530 **USA** 

Tel.: +1 973 882 5597 Fax: +1 973 882 5178

#### SEPPIC GmbH

ABC Tower Köln Ettore - Bugatti - Str.6-14 51149 Köln-Porz **GERMANY** 

Tel.: +49 (0) 220 3890 3100 Fax: +49 (0) 220 3890 3199

#### **SEPPIC UK Ltd**

50 Salisbury Road PO Box 338 - Hounslow TW4 6SH - ENGLAND Tel.: +44 208 577 8800

Fax: +44 208 570 2106

### **SEPPIC Belgium NV**

Nieuwe Weg 1 Haven 1053 B – 2070 Zwijndrecht BELGIQUE

Tel. : +32 3 250 3911 Fax : +32 3 250 3912