



FILTER100 INSTRUCTIONS FOR MODELS BIM100, SCIM101, & ALIM100
READ AND FOLLOW INSTRUCTIONS BEFORE OPERATING YOUR ICEMAKER

This water purification filter must be installed in order to operate the icemaker. The filter cycle is typically 6 months, but might be shorter, depending on your environment and the quality of your water. **When the filter is no longer active, your icemaker will not function until it is replaced.**

You can order replacement filters online at
summitappliance.com/filter100

Installing the filter upon initial startup:

1. Remove the round punch-out on the lower right hand side of your icemaker's front. It has been precut to make this process easy. You can discard the plastic cutout, as you will no longer need it
2. Insert the filter into the hole, turning it clockwise until it is locked in place
3. When you first turn the icemaker on, check the area around the filter to ensure there are no leaks. If you see any water, reinsert the filter and make sure it is properly connected.

Changing the filter:

1. Remove the old filter by turning it counterclockwise and pulling it out of the filter hole
2. Discard your old filter
3. Insert the new filter, turning it clockwise until it is locked in place
4. After turning on the icemaker, check the area around the filter to ensure there are no leaks

***Helpful Hint:** Upon installing or changing your filter, record the date on the bottom so your staff can easily identify when it is time to change the filter.*

If you require additional support installing the filter, contact our technical support team at **718-893-3900 ext. 513** or email techsupport@summitappliance.com.