



CIRO ACCESSORY PERCH MOUNT

Parts Included:

- 1 Giro Accessory Perch Mount
- 1 Hardware Kit Including:
 - 2 1/4-20 x 1-3/4" Bolts
 - 2 M6 x 45mm Bolts
 - 2 Spacers

Installation Instructions:

1. Park on a level surface and shut off the motorcycle. Ensure that the engine has time to cool before installation. Cover your tank with a clean towel or blanket to protect it.
2. Remove the two perch bolts with a T27 Torx on the side that you would like your perch mount. Be careful not to let your controls fall on the tank. (Fig. 1)



3. Compare the threads of your old bolts to the bolts supplied in the kit. The shorter 1/4-20's are commonly used in newer Harley models. Use the M6 for metric bikes. Prepare the perch mount as shown above. (Fig. 2)

4. Use a 3/16" allen to install the perch mount in the location of the removed torx bolts. (Fig. 3)

5. You may use a 5/32" allen to loosen the small bolt on top of the mount to adjust the position of the ball.

*If you have purchased any Giro accessories to go with your ball mount, please refer to those instructions to complete your installation.



WARNING:

This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION:

This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION:

This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Giro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

NOTE:

Giro products are designed and manufactured under very strict quality control. Giro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a lifetime warranty against LED failure. Giro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed and maintained. Giro will not be liable for any consequential and incidental damages, including labor, or non-Giro products. Please visit our website Ciro3d.com for our complete warranty policy.

CIRO3D.COM



CIRO DRINK/CUP HOLDER

Parts Included:

- 1 Drink/Cup Holder Assembly**

Installation Instructions:

- 1. Remove the large plastic nut from your drink holder and slide it over the Giro ball mount with the threads facing outward.**



- 2. Snap your drink holder onto the ball and thread the large plastic nut back onto the drink holder. Adjust the angle, tighten it down, and you are ready to go.**



WARNING:

This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION:

This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION:

This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Giro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

NOTE:

Giro products are designed and manufactured under very strict quality control. Giro products are warranted to be free of defects in material and workmanship for 1 (one) year from date of purchase by the consumer.

Giro will have no obligation if the customer cannot show proof of purchase.

Warranty will not be granted unless the part is properly installed and maintained.

Giro will not be liable for any consequential and incidental damages, including labor, or non-Giro products.

Please visit our website Ciro3d.com for our complete warranty policy.

CIRO3D.COM