NL ELECTRONIC LOCK INSTRUCTIONS











GETTING STARTED:

Use a Brand New <u>Duracell Coppertop</u> 9-Volt Battery expiring 5 years into the future. WHY THIS SPECIFIC BATTERY? Because it has the highest amperage output that is needed to operate the safe lock.

GENERAL LOCK INFORMATION:

LOW BATTERY: A series of signals indicates that the battery is weak and must be replaced. ONLY USE a Brand New Duracell Coppertop 9-Volt Battery that expires at least 5 Years in the future. Otherwise the lock will NOT work correctly. The battery compartment is located at the bottom of the keypad.

LOCKOUT: Manipulation protection: Entry of four consecutive invalid codes results in a 5 minute lockout. During this period, the LED flashes every 10 seconds and any key pressed causes a long signal. After 5 minute period, entry of two or more invalid codes restarts 5 minute lockout.

CHANGING DEFAULT COMBINATION:

NOTE: The following instructions are for changing the combination for the first time from the set default combination.

- Enter default combination to unlock the safe: 1-2-3-4-5-6
- Open the door and extend the bolts
- Press and HOLD [0] on keypad until double signal. LED light will remain on during next steps:
- Enter DEFAULT combination: 1-2-3-4-5-6 [double signal]
- Enter NEW combination: six-digit code [double signal]
- Re-enter NEW combination [double signal]
- Your new combination is now set

<u>IMPORTANT</u>: Make sure you test your new combination several times with the door open before closing the safe to ensure your new code was set properly.

REPLACING USER COMBINATION:

- Enter existing user six-digit combination to unlock the safe
- Open the door and extend the bolts
- Press and HOLD [0] on keypad until double signal. LED light will remain on during next steps:
- Enter existing user combination [double signal]
- Enter NEW combination: six-digit code [double signal]
- Re-enter NEW combination [double signal]
- Your new combination is now set
- Test new combination several times before closing the door