PYRAMD

071976 Honda CB500X Hugger Fitting Instructions

Kit Includes:

1X	C071976	Hugger Moulding		
1X	CFK071974	Mounting Bracket		
2X	CRUB0001	Rubber Strip (cut to 140mm)	(pre-cut by Pyramid)	
4X	CBOLM60008	M6 X 16mm Stainless Bolt		
2X	CWASM60003	M6 Plastic Washer		
2X	CWASM60007	M6 Rubber Washer		
2X	CGROM60001	Rubber Grommet		
2X	CSPAM60004	M6 Steel Collar (8mm)		
2X	CNUTM60008	M6 Cage Nut		
1X	CFOA0001	Foam Strip (30mm length)	(pre-cut by Pyramid)	
			—	

Any questions? sales@pyramid-plastics.co.uk +44 (0)1427 677990 www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!

- To gain better access to the rear swingarm, remove the exhaust and right-hand side pillion footpeg.
 Also remove the left-hand side rider and pillion footpegs.
- Remove the OEM chainguard.
- Trim and attach the **rubber strips** as shown in **Fig 1**.
- Install the rubber grommets and M6 steel collars in the two holes on the chainguard side of the Pyramid Hugger (see Fig 2 below). Fit the M6 cage nuts (See Fig 3 & 4 below).
- The mounting bracket supplied with the Pyramid Hugger is attached on the right-hand side of the bike. Remove the OEM bolt and fit the mounting bracket loosely using the same OEM bolt (see Fig 3 below).
- Loosely attach the Pyramid Hugger to the mounting bracket using two M6 X 16mm stainless bolts, two M6 plastic washers and two M6 rubber washers (see Fig 4 below).
- Loosely attach the chainguard side of the Pyramid Hugger using the remaining two M6 X 16mm stainless bolts (fitted through the previously installed rubber grommets and M6 steel collars).
- Fully tighten all mounting points and then re-install all items which were removed in the first bullet point.
- Check all fixings periodically.





