

# **Z750/S 07 > HUGGER** Part # 073511

#### General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked for tightness.

### **CONTENTS:**

1 x 2 Piece strap bracket	CFK07327
1 x m6 x 12 Allen bolt	CBOLM60007
1 x m6 shake proof washer	CWASM60002
2 x m6 x 16mm Allen bolt	CBOLM60008
2 x m6 washer	CWASM60003

## **Fitting Instructions:**

Undo the 3 Allen headed bolts & remove the chainguard.

Hook the strap bracket over the swing arm, on the brake hose side, between the hose guide and the cross member.

Slide the hugger into place from the rear right and loosely fasten with two of the original chainguard bolts.

With the hugger on the outside of the strap bracket fasten with the bolts and back plate provided.

Align the hugger by moving the box bracket back or forward along the swing arm. Tighten all the bolts.

#### Notes:

Check bolts and fittings regularly.

We recommend Plexus Plastic Protect and Polish for guaranteeing the lifespan, colour and finish of our Huggers.