



1. Product Name

Porter

2. Product Code

22879

3. Colour

Natural wood finish

4. Brief Description

Makes the ROMPA® Panels mobile and allows these to be pushed from room to room.

5. Contents

- 1 x Porter

6. Snoezelen® Stimulations

Not applicable

7. Best Use

Use with two ROMPA® Deluxe Wall Panels.

8. Compatible ROMPA® Products

22871 Colour Command Centre™
22869 Multifinity Explorer™
22872 Fireworks Extravaganza™
22870 Sound to Sight Showtime™
22873 ColourCatch Combo™
19210 Light Source
22611 LED Projector
22612 LED100 Projector
21509 ROMPA® Rainbow Wi Fi Projector



9. Starting Up

- Secure two panels to the Porter.
- Add additional products as required – ROMPA® Projectors and Light Sources
- Plug the panels into the central bank of plug sockets.
- Plug the cable from the Porter into a wall socket.

10. Detailed Description

Makes the ROMPA® Panels mobile and allows these to be pushed from room to room. Perfect for use between chairs or beds. Ideal for where wall-mounting is not viable. For up to 2 ROMPA® Wall Panels. With 1 plug but includes an integral 6-socket extension lead. Can also house 2 Light Sources inside and 2 Projectors (all to be purchased separately) on the top central shelf. Not suitable for use with the Bubble Panel 22874.

11. Safety

- **Always supervise the use of this product.**
- Use the brakes on the castors to keep the Porter in position.
- Use the handles to move the Porter.
- When moving a Porter that has a Light Source inside with fibre optics emerging from the side circles, make sure that the fibres are safely out of the way so they cannot become trapped under the castors – either removed from the light source boss or else tucked out of the way inside the Porter.
- For use indoors, in dry environments only.



- Do not remove the nut caps (circled below) at the front of each open side of the Porter. These are to cover the castor fixings.



12. Technical Specification

Size: 77.5W x 71.5D x 140cmH

Weight: 18kg

Plug: UK 6-socket bank with UK fused plug (unless specifically requested otherwise)

13. Installation

1. Secure two panels to the Porter. Please refer to the separate instructions supplied with your Panel. Any of the ROMPA panels listed above can be used. Please note that the Double Bubble Bonanza™ cannot be used with the Porter.

Secure the two mounting brackets (supplied with each panel, one for the top of the panel and the other for the bottom) to the panel porter using an appropriate number of fixings, no longer than 10mm in length using the predrilled pilot holes. Repeat this step on the other side of the porter for a second panel. Please refer to the panel instructions for further details on mounting the panels.



2. Plug the panels into the central bank of plug sockets. There is a block of 6 sockets at the base of the Porter.



3. Place up to 2 Light Sources inside the Porter and plug them into the central bank of sockets. Pass the fibre optics through the circular holes in the closed sides of the Porter.
4. Place up to 2 Projectors on the top shelf of the Porter and plug them into the central bank of sockets. Use the cut outs (one at each side of the shelf) for the Projector cables. These cut outs are wide enough for an IEC cable (kettle lead) to pass through. If there is any risk of the Projector(s) falling off the shelf, or being knocked off the shelf, you may wish to secure the Projector by screwing the Projector stand in place. Double-check the position of the Projector(s) before screwing any holes in the shelf to avoid any errors.
5. Do not connect any other products into the bank of sockets.
6. Plug the cable from the Porter into a wall socket.



14. Care and Maintenance

1. Wipe clean with a very slightly damp and clean cloth. Do not immerse in water. Do not use bleach or abrasive cleaners.
2. Keep and use this product and the products used with it in a dry, clean and indoor environment.
3. Handle with care.

15. Troubleshooting

Not applicable

Further copies of these instructions can be downloaded at www.rompa.com

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at producthelp@rompa.com