CUSTOMER SUPPORT •

CONTACT ADDRESS USA

Nureca INC.USA 276 5th Avenue, Suite 704-397, New York (NY) - 10001, USA

INDIA Corporate Office (Mumbai)

Nureca Limited 128 Gala Number Udyog Bhavan,

1st Floor Sonawala Lane, Goregaon East Mumbai City Maharashtra 400063 Contact us

India: +91-7527013265 /+91-9356658436 Website: www.drtrust.in

Corp Website: www.nureca.com
Email: customercare@nureca.com

Connect with us on social networks
Facebook: @drtrust

Instagram: @drtrustisin Youtube: Nurecal Isa



Scan to View Product Demo Video www.drtrustusa.com/1031

COPYRIGHT@2021 NURECA LTD ALL RIGHTS RESERVED

ABOUT US

Here at Dr Physio USA, we make the most imaginative, unwinding, and restorative, wellbeing and individual care Products.

In the hubbub of today's lifestyle, it becomes impossible to nurture youself at times. In the chaos of maintaining every aspect of life efficiently, we forget that our bodies are not machines. They need absolute care and tenderness. Pain in neck, shoulder, back or foot should never be taken for granted. They can lead to serious aliments in the long run. To help you ease the situtions of painfulness, Dr Physio USA brings to you excellent ways of relaxation and pain relief through our premium gadgets. We offer a non-intrusive answer to help renew and reestablish your muscles and relieve throbbing pain with our various products

The variety of items and massagers we offer are intended to target particulers areas of the body viz neck, shoulder, back, foot and so on. the adaptable capabilities of our gadgets are meant for utmost body relaxation after a long day at work. Since we are continually in pursuit of excellence, our research and development team at NY, USA works diligently to ensure that each of our innovations are available at a value you would appreciate.

Sit Back, Relax and enjoy the amazing Dr Physio experience by Dr Trust!!

Dr Physio from Dr Trust www.drphys.io | www.drtrust.in

Dr Trust°

Dr Physio Facial Massager – 1031

QUICK STARTUP GUIDE

Step 1.

Before you begin, charge the unit for minimum 1.5 hours with the provided cable.

Step 2.

Apply cleanser and remove all makeup.

Step 3.

Wet the Dr Physio Facial Massager then dampen your face and apply your regular cleansing product.

Step 4.

Turn on your massager by pressing the center POWER button once.

Step 5.

Press intensity buttons to customize the massage as per your choice.

Step 6.

Rinse and dry your face to complete the 5-minute cleansing & massaging routine.

PRODUCT BRIEF

Dr Physio Facial Massager – 1031 is designed to mark a revolution in facial cleansing. As a sophisticated skincare technology it transmit vibrations to skin for a gentle & soft deep pore cleansing. Innovative silicone brush featuring touch-points and suitable for all skin types. Waterproof design featuring high density soft skin-friendly brush heads for deep cleaning by reducing greasy dirt, blackheads, pores blockage, makeup residue and other problems. The five-speed adjustment make easy to adjust the intensity according to your own needs. It can be used together with skin care products to achieve the best cleaning and skin care effect. It removes dirt and oil as well as makeup residue and dead skin cells effectively. We recommend 5 minutes cleansing with the Dr Physio facial massager every day.

▶ PRODUCT FEATURES ●

- 1. Food-grade silica gel.
- 2. Hygienic as easy to wash and clean.
- 3. Safe as causes no irritation or allergy.
- Multi-vibration silicone cleansing technology can be transmitted through the skin surface to the deep layer to clean impurities in pores.
- Adjustable five-speed gear to choose speed level as peryour own needs.
- 6. Waterproof design, micro-hole DC charging port.
- 7. Effectively prevents water entry into the fuselage.

OPERATION AND PARTS DESCRIPTION



- 1. Power Button: One button on/off
- 2. Vibration Buttons: Each press of the corresponding button strengthen or weaken the speed. There are five adjustable gears.
- 3. Charging: Connect the USB port of the charging cable to the power supply, and insert the other end into the charging port of the product. At this time, the charging indicator light is always red and lasts for about 1.5 hours.

SPECIFICATION

	0. 200
Product Name	Dr Physio Facial Massager – 1031
The Input	5V/0.2A
Product material	Silicone + ABS plastic
Net Weight	75g
Water Proof	lpx7

Product Size	125 (I)X58 (m) X 28 (h) mm
Battery Capacity	600mAH
Battery Type	Built-in-battery
Power	12W
RPM	8000
Use time	5min/day, 30day, 45 day
Suggested Charging Time	3 hours
Accessory	Charging cable + user manual
Other Feature	5 speed adjustment
Certification	CE

CAUTIONS

- 1. Please take special care when cleaning the area under the eyes. Do not let the product directly touch the eyelids or eyes
- 2. Do not use silicon-soluble or granular cleanser, exfoliating cream or scrub at the same time as the product, as these substances may damage the soft silicone contacts.
- 3. Please avoid using too much force or moving too fast. It is recommended not to over clean any area for more than 20 seconds.
- The process of using silica gel cleanser should be comfortable. If you have any discomfort, please stop using it immediately.
- Please do not use it when charging. After charging, please place it in the ventilation position.

CLEANING AND MAINTENANCE



- After each use, please thoroughly clean the product, use water and soap to clean the surface of the brush head, and then rinse with warm water, dry with a cloth or towel without any hairs.
- Caution: Do not use cleaning products containing alcohol, gasoline, or acetone, which may damage the product.
- 2. Clean the brush head and body with water, dry it and place them in a dry and ventilated place.
- 3. Do not use sharp cleansers or corrosive, volatile diluents to clean.
- 4. If it is not in use for a long time (about three months), please take it out and store it back after it is fully charged to avoid damage to the battery due to lack of power.