

## Equicizer All-Terrain Wheels - Attachment Instructions

To fasten the Equicizer All-Terrain wheels to your Equicizer, all you will need is a  $\frac{3}{4}$ " wrench. This process may be more easily completed if you carefully lift and rest the Equicizer up on its rear but can also be done by laying the Equicizer on its side.

Step 1. The lock washer (included) is resting on the nut located on the threaded stem of the All-Terrain wheel. Remove the tape that was used to secure the washer in place during transit. Locate the 4 threaded slots on the Equicizer's frame.



Step 2. Line up the threaded stem of the wheel to the threaded slot of the Equicizer's frame. Using your fingers, turn the nut clockwise to begin tightening the wheel onto the Equicizer's frame.

Step 3. Using the  $\frac{3}{4}$ " wrench, continue to turn the nut on the wheel clockwise until it is tight to the Equicizer's frame.



Step 4. Repeat the process with all 4 wheels. Once completed, carefully set the Equicizer down. The process is complete. When riding, make sure that all 4 wheels are in the locked ("on") position as this will help optimize the movement and feel of the Equicizer.

***Please contact Wooden Horse Corporation at 419-663-1472 or send us an email at [info@equicizer.com](mailto:info@equicizer.com) with any questions or concerns.***