Manual Supplement

Manual Title:i410/i1010 Service InformationPart Number:642733Print Date:December 1996Revision/Date:Enter Service Information

Supplement Issue:5Issue Date:4/10Page Count:1

This supplement contains information necessary to ensure the accuracy of the above manual. Enter the corrections in the manual if either one of the following conditions exist:

- 1. The revision letter stamped on the indicated PCA is equal to or higher than that given with each change.
- 2. No revision letter is indicated at the beginning of the change.



Change #1

On page 3, under *Required Equipment* add the following:

To ensure Range and Accuracy Specifications are maintained, warm up the Current Clamp for 20 minutes prior to performing the Performance Tests or Calibration and Adjustment procedures.

Change #2

On page 5, Table 4, replace steps 18 and 19 with the following:

18	18.0A dc	900.0A dc	0.9000V	NA	NA	881.5mV	918.5mV
19	-18.0A dc	-900.0A dc	-0.9000V	NA	NA	-918.5mV	-881.5mV

Change #3

On page 5, Table 4, step 23, remove 400Hz from the Calibrator Setting column.

Change #4

On page 5, Table 4, remove Step 21.

Change #5

On page 5, Table 4, remove Steps 8, 10 and 12.