

NOTE!

Please do not put this product away or leave it for extended periods of time with a low charge because if the battery falls below 2%, it will no longer accept a charge.

DISCLAIMER

Thank you for purchasing the Starry aromatherapy diffuser. We hope you enjoy the quality and performance of your Starry.

To ensure optimal performance and safety of the Starry, please read this entire manual.

Please read and follow these instructions carefully. Understand them fully before using your Starry.

We recommend you keep these instructions in a safe place for future reference.

Starry is not a medical device and is not intended to diagnose, cure, treat or prevent diseases or other conditions. If you have any health problems, consult your doctor before using the Starry.

This product should not be used by children, women who are pregnant or breast feeding, or those with life threatening illnesses without first consulting a doctor. Never use before driving or operating heavy machinery.

Starry is not intended to administer medicinal or illegal substances of any kind. Any use of this device could subject the user to fines, penalties, and/or imprisonment under the laws of your jurisdiction.

THIS PRODUCT DOES NOT CONTAIN ANY PLANT MATERIAL.

3







356°F 356°F

Timer C

Current Temperature

Battery Power

5.Setting temperature:Press the "+" to increase temperature. Press the "-" to decrease temperature.(Starry will automatically remember your last setting when restarted.)

6.The " will turn solid and the Starry will vibrate when ready. Inhale through the mouthpiece and enjoy until the Starry shuts off with a vibration.



7.Switching between Fahrenheit and Celsius: Hold the Power and "-"buttons at the same time for two seconds.



8.Toggle Shutdown Timer:Hold the Power and "+" buttons at the same time for two seconds to toggle the shutdown timer between five and ten minutes.



CHARGING

1. To protect and extend the battery, it is recommended your Starry be charged with a wall adapter for at least six hours before its first use. (External 18650 battery charger is available but not included.)

6



CLEANING/AND MAINTENANCE

To maintain the Starry, we recommend emptying the heating chamber and wiping the mouthpiece screen after each use.

 To clean the mouthpiece, use a cotton swab and wipe the inner part of the mouthpiece, then wipe again with a damp paper towel.

2. To clean the mouthpiece screens, prepare a glass container filled with isopropyl alcohol. Remove the metal screens and ceramic filter from magnetic cap, and soak them in the isopropyl alcohol until clean. Do not soak the silicone gasket in alcohol.



3. To clean the ceramic heating chamber, wet a cotton swab in the alcohol. Hold the Starry upside down, and insert into the chamber and scrub the sides and bottom with a circular



4. After soaking, remove any remaining debris using a cotton swab. Allow pieces to dry completely, and reassemble before use.

NOTE:

DO NOT CLEAN THE WHOLE DEVICE WITH WATER.

DO NOT INJECT ANY LIQUID OR OIL INTO THE CERAMIC CHAMBER.

TURN THE STARRY OFF WHEN FINISHED. MAKE SURE IT HAS NOT BEEN USED FOR AT LEAST 30 MINUTES AND IS COMPLETELY COOLED OFF BEFORE STORING.

WARNING

DO NOT TOUCH THE HEATING ELEMENT IMMEDIATELY AFTER USE, PLEASE ALLOW DEVICE TO COOL DOWN.

DO NOT SUBMERGE IN WATER OR ISOPROPYL ALCOHOL.

SAFETY

Prior to your first use, please read and fully understand the instructions including the safety information. We recommend that these instructions be kept for future reference.

Failure to follow warnings may result in a safety hazard including electric shock, fire, property damage, bodily injury or death.

9

You must be of legal age in your jurisdiction to purchase or use the STARRY. For adult use only.

USE

Never use the product before reviewing the manual in its entirety. If any section or topic is unclear, prior to use, please contact customer service for clarification.

This product should not be used by children, women who are pregnant or breast feeding, or those with life threatening illnesses without first consulting a doctor. It is recommended that all users consult a doctor prior to use with your chosen herb or concentrate. Note that the STARRY is not a medical device and is not intended to diagnose, cure, treat, or prevent any diseases or other medical conditions. STARRY is not intended to administer medicinal or illegal substances of any kind. Any illegal use of this device could subject the user to severe fines, penalties, and/or imprisonment under the laws of your jurisdiction.

DAMAGE

Immediately discontinue use of the product if the vaporizer unit is damaged in any way including but not limited to: dents, overheating, unusually restrictive airflow, and/or electrical malfunctions. Do not attempt to repair product by disassembly of non-replaceable parts except mouthpiece, heating element, packing tool, and removable battery. Please contact customer service for help with any All Batteries may explode or burst into flame if used improperly or mistreated. Do not disassemble, puncture, tamper, cut, crush, short-circuit, incinerate or expose to water, fire or high temperature above 60 °C or 140°F. Never use damaged or improperly wrapped batteries with this device.

It is your responsibility to understand the dangers as well as the proper procedures for handling all batteries. Do not dispose of in trash containers nor litter the environment. Please recycle or dispose according to local safety regulations. (Cover terminals with proper insulating tape before disposal.)

WARNING

THIS PRODUCT IS NOT INTENDED FOR NICOTINE.

PRODUCT IS DESIGNED FOR LEGAL HERB USE ONLY. PRODUCT DOES NOT CONTAIN ANY HERBAL MATERIALS.

KEEP DEVICE AWAY FROM CHILDREN AND PETS.

LIMITED WARRANTY

The product is warranted for a period of one (1) year from purchase with receipt or one (1) year from date of manufacture without receipt against defects in manufacturing, workmanship, and materials. This device is designed for the use of legal substances only. Any use of the STARRY with illegal substances will void the warranty. The warranty does not apply to damage caused by accident, abuse, misuse, natural disaster, user error, or use outside the intended use described in this manual. Use outside the intended use asdescribed in this manual also includes any tampering with the device in any way including, but not limited to, modification to alter functionality or appearance.

The warranty also does not apply to cosmetic damage including, but not limited to, dents, scratches/chips to finish, and/or broken plastic

Normal product wear and tear is not covered under warranty. Normal performance degradation of batteries is also not covered by the warranty

To make a warranty claim, please contact customer support at hello@planetofthevapes.com. The originalbill of sale, authenticity code, pictures orany serial numbers are required to redeem the warranty.

At the manufacturer's discretion, warranty service will be provided by repair of the product or exchange of the product and/or part with a new, or functionallyequivalent, product/part.

CUSTOMER SUPPORT

For any question or concerns with the products, it's use or defects, please contact customer support at hello@planetofthevapes.com. We will do our best to provide a response within two (2) business days after receipt of written notice.

www.planetofthevapes.com

