

T

С

۵

Ω

EPIC2 WIRELESS EARBUDS

We love that you are rocking JLab Audio! We take pride in our products and fully stand behind them.



YOUR SATISFACTION IS GUARANTEED

You may exchange or return merchandise within 30 days of the purchase date. Learn more at **jlabaudio.com/guarantee**

YOUR WARRANTY

You may register your product at **jlabaudio.com/register**. All warranty claims are subject to JLab Audio authorization and at our sole discretion. Retain your proof of purchase to ensure warranty coverage.

3

CONTACT US

Reach out to us at support@jlabaudio.com or visit jlabaudio.com/contact

FIRST TIME SETUP: BLUETOOTH PAIRING



When power is OFF, press and hold Power Button for **10 seconds**.

Voice prompt "Ready to pair" followed by **blue and red blinking lights** indicate Epic2 is in pairing mode.





Turn on the Bluetooth

Select "Epic2 BT" in your device settings to connect. If a password is required type in "0000".

Light will **slow blink blue** when Bluetooth is paired.

Voice prompt "You are connected" followed by a **slow blue blinking light** indicates connection.



RECURRING USE

Once JLab Epic2 has initially paired to your device, the earbuds will auto-connect to your Bluetooth device when powered back ON. (Follow **BUTTON FUNCTIONS** instructions)

CHARGING



1 Locate the Micro USB door and plug in the cable.







2 Red light indicates charging and will turn off once battery is fully charged.

Full charge is approximately 4 hours.



3 To ensure the water resistance of your Epic2, the cover for the Micro USB port must be firmly closed.

ACCESSORIES



BUTTON FUNCTIONS



VOLUME UP: Click once.

TRACK FORWARD: Click and hold 2+ seconds.

POWER ON: Click and hold 3 seconds.

POWER OFF: Click and hold 5 seconds.

ANSWER/HANG UP CALLS: Click once.

ACTIVATE SIRI (iOS) OR "OK GOOGLE" (ANDROID): Click twice.

BLUETOOTH PAIRING: (Follow First Time Setup: Bluetooth Pairing)

VOLUME DOWN: Click once.

TRACK BACKWARD: Click and hold 2+ seconds.

FITTING

1 Place the earbud housing to your ear while wrapping the memory wire behind the ear.

2 Rotate earbud in ear canal and adjust memory wire to your desired fit.

CABLE MANAGEMENT CLIPS

Note: Optional cable clips may affect your Bluetooth connectivity. Removing cable clips can improve connectivity. For more info: jlab.audio/ClipsBT

1 Create a desired length by looping the cable.

For best connectivity: Make sure the microphone doesn't come in direct contact with skin (leave the cord loose around back of neck).



2 Secure a cable clip on one end of the loop by pushing in from the top and bottom.



3 Secure the second cable clip on the other end of the looped cable. 4 Cable clips should be secured to both ends of cable.



CLEANING

The Epic2 is 100% splashproof, sweatproof + washable with an IP55 rating. Simply rinse off your earbuds after use.

Note: Keep charging port tightly sealed when rinsing.

WARNING



WARM-UP YOUR HEADPHONES

Optional: Burn-in is the process for exercising new audio equipment. We recommend 40 hours of burn-in time for most headphones to reach optimal performance. The main purpose of the process is to loosen the diaphragm of a newly crafted headphone and to stress the headphone driver. Normal, everyday use can also burn-in the headphones though JLab's proprietary burn-in provides an ideal mix of sounds and frequency sweeps to achieve this.



Burn-in your audio equipment with the JLab Audio app available on the App Store and Google Play. Or access the burn-in method at: jlabaudio.com/burnin

CAUTIONS

- Avoid getting moisture or liquids into the tip of the earbuds or charging port.
- Avoid extreme heat, cold, and humidity.
- Avoid dropping or crushing the earbuds, stressing the cable by rapid pulling or extreme force, or bending the cable at a sharp angle.
- Wax may build up in the earbud tips, lowering the sound quality. Carefully remove the wax with a cotton swab or other small tool to improve the sound quality.
- If you experience discomfort or pain, try lowering the volume or discontinuing use temporarily.
- If you experience regular discomfort while using this product, discontinue use and consult your physician.
- We recommend you treat your earbuds as you would a nice pair of sunglasses and keep them in safe location when not in use.