

PRODUCT DATA SHEET

Shoulder Braces/ Suspenders

SKU: TMH

Description

Padded Shoulder Braces/ Suspenders -fluro Orange

Shoulder Braces designed to fit our range of tool belts. Our braces allows for better distribution of weight and relieves some of the strain that can affect the lower lumber.

The front chest strap can be unclipped for easy removal of your belt and braces combination.

Information

1. This product complies with AS/NZS 1906:4:2010 – Reflective materials (Hi vis component).
2. Allows for better distribution of weight and relieves some of the strain that can affect the lower lumber. This is achieved through the weight being transferred to the wearers shoulders as opposed to their back.
3. Will only fit the padded belt range.
4. Fully adjustable using the 3 moulded plastic tri-slides for easy positioning.
5. The flat tri-slides avoid twisting of the straps (this is an issue with clip on systems).
6. Note: The braces straps should fit firmly against the wearers body and not hanging loose. The leather 'Y' section should sit toward the top of the wearers back and the chest strap should fit centre across the widest part of the wearers body.
7. Once the braces have been affixed and are comfortable for the wearer, they don't ever need to be removed from the tool belt. The belt and braces combo now mimics a jacket. The front chest strap simply unclips for easy removal of your belt and braces combination.
8. Sizing Available: One Size Fits All. Larger sizes can be manufactured upon request.



Materials

- Felt
- Webbing
- Kip Leather
- Hi Vis
- Plastic Hardware
- Thread

BUCKAROO®

16A Bellambi Lane
Bellambi, NSW , 2518

+612 4225 9333
info@buckaroolleather.com.au
www.buckarobelts.com

Country of origin	L x H x D (mm)	Weight (kg)	Barcode EAN/ UPC
Australia	One size fits all	0.2	9325154000395

PRODUCT DATA SHEET

Shoulder Braces SKU: TMH

How to attach the Shoulder Braces

1. Lay belt on a flat surface with easy access to the 3 metal loops that are positioned evenly along the top edge of the belt.
2. Undo the 3 braces straps as they are wrapped up for POS purposes.
3. Beginning with the back shorter strap, attach to the middle wire loop on the belt. Attach by passing the webbing through the wire loop and then threading through the plastic trip slide until the strap is tucked in with no overhang.
4. Before affixing the 2 front braces straps, fasten belt to the body.
5. Step 5: As the back strap is already fixed, the wearer needs to bring the 2 front straps over the front of their body and attach to the wire loops whilst the belt is being worn (this way the tension can be determined without needing to trial and error too much). Thread the 2 remaining straps through as per Step 3.
6. Connect chest strap for a firm fit.



BUCKAROO®

16A Bellambi Lane
Bellambi, NSW , 2518

02 4225 9333
info@buckarooleather.com.au
www.buckarobelts.com