



TRD 1

Compact Controller with program function

Operating Manual

2009-05-27/00456143



Please read this Operating Manual before commissioning the instrument. Keep the manual in a place which is accessible to all users at all times.

Please assist us to improve this operating manual. Your comments will be appreciated.

All necessary settings are described in this operating manual. If any difficulties should still arise during start-up, please do not carry out any unauthorized manipulations on the unit. You could endanger your rights under the instrument warranty!

Please contact the Elstein-Werk plant or the nearest Elstein representative.



This manual is valid from instrument software version 192.02.05.

It appears by simultaneously pressing the and \(\text{\text{N}} \) keys.



When accessing the inner parts of the unit and returning modules, assemblies or components, please observe the regulations accordings to EN 61340-5-1 and EN 61340-5-2 "Protection of electrostatic sensitive devices". Only use **ESD** packaging for transport.

Please note that we cannot accept any liability for damage caused by ESD.

ESD=Electro Static Discharge

Elstein-Werk M. Steinmetz GmbH & Co. KG Stettiner Straße 14 D-37154 Northeim Germany

www.elstein-werk.de

E-Mail: elstein-werk@t-online.de Tel.: +49 (0) 5551 983-0 Fax: +49 (0) 5551 983-61

Contents

1	Introduction	5
1.1	Description and scope of delivery	. 5
1.2	Typographical conventions	. 6
2	Mounting	7
2.1	Mounting site and climatic conditions	. 7
2.2	Dimensions	. 7
2.3	Side-by-side mounting	. 7
2.4	Fitting in position	. 8
2.5	Removing the controller module	. 8
3	Electrical connection	9
3.1	Installation notes	. 9
3.2	Electrical isolation	10
3.3	Connection diagram	11
4	Operation	13
4.1	Displays and keys	13
4.2	Level concept	14
4.3	Level inhibit	14
4.4	Entries and operator prompting	15
4.5	Operation of the fixed-setpoint controller / Manual mode	16
4.6 4.6.1	Operation of the program controller Entering programs	

Contents

5	Operator level	21
6	Parameter level	23
7	Configuration	25
7.1	Overview of the configuration levels	27
7.2 7.2.1	Analog input "InP" Customized fine tuning	
7.3	Controller "Cntr"	32
7.4	Generator "Pro"	34
7.5	Limit comparators "LC"	36
7.6	Outputs "OutP"	40
7.7	Binary functions "binF"	41
7.8	Display "diSP"	44
7.9	Timer "tFct"	45
8	Tuning (optimization)	47
8.1	Autotuning (self-optimization)	47
8.2	Check of the tuning	50
9	Appendix	51
9.1	Technical data	51
9.2	Alarm messages	53
10	Index	55

1.1 Description and scope of delivery


The freely programmable controller in DIN format is used to control temperature. It has been pre-programmed with a type K thermocouple for Elstein infrared radiators. After connecting up the power supply, the thermocouple and the controller output, the controller can be commissioned without any further configuration. Please refer to "Note" under item 6.

The high-contrast, multicolor LCD display for process value, setpoint and operator prompting contains two four-digit 7-segment displays, two single-character 16-segment displays, display of the active setpoints, six status indicators, and displays for the unit, ramp function and manual operation.

Just four keys on the front panel are needed for operation, parameterization and configuration. The software includes a program or ramp function, parameter set changeover, autotuning (self-optimization), a math and logic module, as well as 4 limit comparators.

Linearizations for the usual transducers are stored, and a customer-specific linearization table can be programmed.

The electrical connection is made at the back of the instrument, via screw terminals.



Scope of delivery

1 controller

1 seal

fixing items

1 Introduction

1.2 Typographical conventions

Warning signs



Danger

This symbol is used when there may be danger to personnel if the instructions are ignored or not followed correctly!



Caution

This symbol is used when there may be damage to equipment or data if the instructions are ignored or not followed correctly!



Caution

This symbol is used where special care is required when handling components liable to damage through electrostatic discharge.

Note signs



Note

This symbol is used when your special attention is drawn to a remark.



Reference

This symbol refers to further information in other operating instructions, chapters or sections.

Action instruction This symbol indicates that an action to be performed is described.

The individual steps are marked by this asterisk, e.g.

* Press EXIT

Representation

Menu items

Texts from the setup program are shown in italics, for example: edit program.


Blinking display





2.1 Mounting site and climatic conditions


The conditions on the mounting site must meet the requirements specified in the technical data. The ambient temperature on the mounting site can be from 0 to 55 $^{\circ}$ C, with a relative humidity of not more than 90 %.

2.2 Dimensions









2.3 Side-by-side mounting


Minimum spacing of panel cut-outs

horizontal: 11 mm vertical: 30 mm

2.4 Fitting in position

- * Fit the seal that is supplied onto the instrument body.
- * Insert the controller from the front into the panel cut-out.
- * From behind the panel, slide the mounting brackets into the guides on the sides of the housing.

 The flat faces of the mounting brackets must lie against the housing.
- * Push the mounting brackets up to the back of the panel, and tighten them evenly with a screwdriver.




Care of the front panel

The front panel can be cleaned with normal commercial washing, rinsing and cleaning agents. It has a limited resistance to organic solvents (e.g. methylated spirits, white spirit, P1, xylol etc.). Do not use high-pressure cleaning equipment.

2.5 Removing the controller module

The controller module can be removed from its housing for servicing.

* Press together the knurled areas (top and bottom, or left and right for landscape format) and pull out the controller module.





When inserting the controller module, make sure that the latches (below the knurled areas) snap into place.



The modules can be damaged by electrostatic discharge. So avoid electrostatic charge during fitting and removal. Carry out retrofitting on an workbench that is earthed.

3.1 Installation notes

- The choice of cable, the installation and the electrical connection must conform to the requirements of VDE 0100 "Regulations on the Installation of Power Circuits with Nominal Voltages below 1000 V" or the appropriate local regulations.
- The electrical connection must only be carried out by qualified personnel.
- If contact with live parts is possible while working on the unit, it must be disconnected from the supply on both poles.
- A fuse interrupts the supply circuit in the event of a short-circuit. The load circuit
 must be fused for the maximum relay current, in order to prevent the output relay
 contacts becoming welded in the event of a short circuit.
- Electromagnetic compatibility conforms to the standards and regulations cited in the technical data.
- ⇒ Chapter 9.1 "Technical data"
- Run input, output and supply cables separately and not parallel to one another.
- Sensor and interface cables should be shielded cables with twisted conductors.
 Do not run them close to current-carrying components or cables. Ground the shielding on one side.
- Do not connect any additional loads to the supply terminals of the instrument.
- The instrument is not suitable for use in areas with an explosion hazard (Ex areas).
- In addition to faulty installation, incorrect settings on the controller (setpoint, data of the parameter and configuration levels, internal alterations) can also interfere with the correct operation of dependent processes, or even cause damage. Safety devices should always be provided that are independent of the controller (such as temperature limiters/monitors) and only capable of adjustment by specialist personnel. Please observe the relevant safety regulations for such matters. Since adaptation (self-optimization) can not be expected to handle all possible control loops, an unstable parameterization is theoretically possible. The stability of the actual value that is produced should therefore be checked.



The electrical connection must only be carried out by specialist personnel.




The instrument version can be identified by the type code.

Conductor cross-sections and core-end ferrules for installation

	Minimum cross-section	Maximum cross-section	Min. length of core-end ferrule
Without core-end ferrule	0.34 mm ²	2.5mm ²	10mm (stripped)
Core-end ferrule, no lip	0.25 mm ²	2.5mm ²	10mm
Core-end ferrule, lip up to 1.5mm ²	0.25 mm ²	1.5mm ²	10mm
Core-end ferrule, lip above 1.5 mm ²	1.5mm ²	2.5mm ²	12mm
Twin ferrule with lip	0.25 mm ²	1.5mm ²	12mm


3.2 Electrical isolation




3.3 Connection diagram




The electrical connection must only be carried out by specialist personnel.




Terminal strip 3




Terminal strip 2





4.1 Displays and keys



(1)	7-segment display (factory setting: process value)
	four-digit, red, decimal place is configurable
	(automatic adjustment on display overflow)
(2)	Active setpoint (factory setting: SP1)
	SP1, SP2, SP3, SP4 (SP=setpoint); green;
(3)	7-segment display (factory setting: setpoint)
	four-digit, green; decimal place is configurable;
	also used for operator prompting (display of parameter and level symbols)
(4)	Keys
(5)	Indication
	yellow, for
	- switch status of binary outputs $1-4$ (display lights up = on)
	- ramp/program function is active
	- manual operation is active
(6)	16-segment display + dim. units
	two-digit, green; for the unit °C/°F and symbols for h, min, %


The displays are configurable.

⇒ Chapter 7.8 "Display "diSP""

4 Operation

4.2 Level concept

The parameters for making the settings on the instrument are arranged at different levels.



Time-out

If no key is pressed for 30 sec, the instrument returns to normal display.

- ⇒ Chapter 5 "Operator level"
- ⇒ Chapter 6 "Parameter level"
- ⇒ Chapter 7 "Configuration"

4.3 Level inhibit

The access to the individual levels can be prevented.

Code	Operator level	Parameter level	Configuration level
0	enabled	enabled	enabled
1	enabled	enabled	inhibited
2	enabled	inhibited	inhibited
3	inhibited	inhibited	inhibited

- **★** Go to code entry with PGM and **V** (simultaneously for >5 sec).
- * Alter code with PGM (display blinks!)
- ★ Enter code with and Ex-factory: all levels enabled.
- * Return to normal display with EXIT or automatically after approx. 30 sec

The parameter and configuration levels can also be inhibited via the binary function.

⇒ Chapter 7.7 "Binary functions "binF""

4.4 Entries and operator prompting

Entering values

When entries are made within the levels, the parameter symbol is shown in the lower display.

Select parameter Alter parameter


- ★ Select parameter with or
- * Change to entry mode with PGM (lower display blinks!)
- ★ Alter value with and The value alters dynamically with the duration of the key stroke.
- * Accept the setting with PGM or automatically after 2 sec

or

* Cancel entry with The value is not accepted.

Entering times

When entering times (e.g. timer time), the time unit is shown in addition.



The highest time unit of the display is shown for the unit.

If, for instance, "h" is shown for the hour, then the time format for the value is hh:mm.


- ★ Select parameter with △ or ▼
- Change over to the entry mode using PGM (lower display blinks!)
- ★ Alter value with and The value alters dynamically with the duration of the key stroke.
- * Accept the setting with PGM or automatically after 2 sec

or

* Cancel entry with The value is not accepted.

4 Operation

4.5 Operation of the fixed-setpoint controller / Manual mode



Altering the setpoint

In normal display:

★ Alter the present setpoint with and (the value is accepted automatically)

Manual mode

In manual mode, the controller output can be altered by hand.

* Change to manual mode with EXIT (press for more than 2 seconds)

The output appears in the lower display. The hand symbol and the unit "%" light up in addition.

* Alter the output with \(\textstyle \) and \(\textstyle \)

In the case of a modulating controller, the actuator is opened or closed using the keys.

The various levels can be accessed from the manual mode.

* Return to the normal display with EXIT (press for more than 2 seconds)

The output entry on a changeover is configurable. The manual mode can be inhibited.


⇒ Chapter 7.3 "Controller "Cntr""

Additional operating options for the fixed-setpoint controller can be implemented via the binary functions.

⇒ Chapter 7.7 "Binary functions "binF""

On overrange/underrange and probe break, the controller automatically changes over to manual mode.

4.6 Operation of the program controller



Normal display

No program run in normal display, the controller controls to the selected setpoint.

Altering the setpoint

From normal display:

- * Change to setpoint input with
- ★ Alter the present setpoint with and and (the value is accepted automatically)

Starting the program

From normal display:

* Start program with (the ramp symbol lights up!)

Canceling the program

When the program is running:

* Cancel program with

Pausing the program

When the program is running:

- * Pause program with EXIT (press for more than 2 seconds) (the lower display blinks!)
- * Continue with EXIT (press for more than 2 seconds)

The program is canceled in the event of a power failure.

Additional program control functions via binary functions.


⇒ Chapter 7.7 "Binary functions "binF""

4 Operation

4.6.1 Entering programs

Function

A setpoint profile can be implemented with a maximum of 8 program segments.



Entry on the instrument


The instrument must be configured as a program controller/generator.

⇒ Chapter 7.4 "Generator "Pro"" (Function)


Configurable time base: mm:ss, hh:mm und dd:hh (s=seconds, m=minutes, h=hours, d=days).

⇒ Chapter 7.4 "Generator "Pro"" (unit)

The segment setpoints (SPP1 - SPP8) and segment times (tP1 - tP8) are set in the program editor.




The program segments (up to eight) are defined by the segment setpoint and the segment time.



4 Operation

Access




The four setpoints are displayed and edited here, and additional process variables are shown in accordance with the configuration.

Symbol	Meaning			
SP 1	Setpoint 1 (editable)			
SP 2	Setpoint 2 (editable)			
SP 3	Setpoint 3 (editable)			
SP 4	Setpoint 4 (editable)			
SPr	Ramp setpoint (only if configured)			
inP i	Measurement of analog input 1			
1065	Measurement of analog input 2 (only if available)			
FI	Calculated result of math formula 1 (only if available)			
F2	Calculated result of math formula 2 (only if available)			
4	Controller output			
Frun	Program run time (only with program controller/generator)			
t-ES	Residual program time (only with program controller/generator)			
E I	Timer: time 1 (only if configured)			
E2 Timer: time 2 (only if configured)				

5 Operator level

Definition of the program times




(1) Program run time	(3) Segment run time
(2) Residual program time	(4) Residual segment time

General

Two parameter sets (PAr1 and PAr2) can be stored.

Access



The level can be inhibited.

Applications

- Parameter set switching via binary function
- ⇒ Chapter 7.7 "Binary functions "binF""

Note

Parameter set 1 is preprogrammed for Elstein radiators, except for type HLS Pb1 = 10° C, dt = 2s, rt = 8s, Cy1 = 1s

Parameter set 2 is preprogrammed for Elstein radiators type HLS Pb1 = 40° C, dt = 6s, rt = 25s, Cy1 = 1s

6 Parameter level

PA-A → PA- ! (PA-2)

Parameter	Display	Value range	Factory setting	Meaning
Proportional band	P6 1	09999	10 (40)	Size of the proportional band
Derivative time	dE	09999 s	2s (6s)	Influences the differential component of the controller output signal
				The effect of the D component increases with increasing derivative time.
Reset time	rE	09999 s	8s (25s)	Influences the integral component of the controller output signal
				The effect of the I component decreases with increasing reset time.
Cycle time	CA 1	0.0999.9s	1s (1s)	With a switched output, the cycle time should be chosen so that a) the pulsed energy flow to the process does not cause any impermissible PV fluctuations and b) the switching elements are not overloaded.
Contact spacing	db	0.0999.9	0	The spacing between the two control contacts for 3-state or modulating controllers.
Switching	H95 :	0.0999.9	1	Hysteresis for switching controllers
differential	HYSZ	0.0999.9	1	with Pb1,2 = 0. y 100% HyS1, 2 w x
Actuator time	EE	53000 s	60 s	Actuator time range used by the control valve for modulating controllers.
Working point	40	-100+100%	0%	Output for P and PD controllers
Output limiting	91	0100%	100%	(when x = w then y = Y0). The maximum limit for the output.
Output infining	75	-100+100 %	-100%	The minimum limit for the output. The minimum limit for the output.
	שכ	-100+100 %	-100%	The minimum limit for the output.

The parameters Pb2, Cy2, HyS2 and y2 refer to the second controller output for a 3-state or modulating controller.

The decimal place of some parameters depends on the decimal place setting in the displays.



The parameter display on the instrument depends on the controller type selected.

⇒ Chapter 7.3 "Controller "Cntr""

General


The following applies to the visualization at the configuration level of the parameters and functions listed below:

The parameter is not shown or cannot be selected if:

the equipment level does not permit the function assigned to the parameter.
 Example: Analog output 2 cannot be configured if no analog output 2 is available in the instrument.

The symbol (appears in the display) that corresponds to the menu item is shown in the chapter headings (e.g. Chapter 7.2 "Analog input "InP"").

Access to level



Levels can be inhibited.

⇒ Chapter 4.3 "Level inhibit"


Analog selector

With some parameters, you can choose from a series of analog values. To provide you with an overview, this selection is listed below.

- 0 no function
- 1 analog input 1
- 2 analog input 2
- 3 process value
- 4 present setpoint
- 5 ramp end value
- 6 program setpoint
- 7 math 1
- 8 math 2
- 9 setpoint 1
- 10 setpoint 2
- 11 setpoint 3
- 12 setpoint 4
- 13 controller output level
- 14 controller output 1
- 15 controller output 2

- 21 program run time in sec
- 22 residual program time in sec
- 23 segment run time in sec
- 24 residual segment time in sec
- 25 timer run time for timer 1 in sec
- 26 timer run time for timer 2 in sec
- 27 residual run time for timer 1 in sec
- 28 residual run time for timer 2 in sec
- 20 residual full time for timer 2
- 29 present segment end value
- 30 analog marker (Profibus)31 reserved
- 32 reserved
- 33 reserved

Definition of the program times



(1) Program run time	(3) Segment run time
(2) Residual program time	(4) Residual segment time

7.1 Overview of the configuration levels

	•	•	_	
Level	3 InP Page 28	4 InP I InP2	5 SEnS Li n OFFS SCL SCH dF FES FES FEE HERE	Sensor type Linearization Measurement offset Display start Display end Filter time constant Fine tuning start value Fine tuning end value Heater current monitoring
		InP I2	Uni E CYcL	Unit Sampling cycle time
	Entr Page 32		CESP CREE INTR HRNd -OUE SPL SPH CP- ESP FEEEd ESPE INTE OUE! OUE! SUBJECT SOUE SOUE	Controller type Control action Inhibit manual mode Manual output Range output Setpoint low Setpoint high Controller process value external setpoint Output feedback Method of tuning Inhibit tuning Output of tuning 1 Output of tuning 2 Controller standby output Step size
	Pro Page 34		Frict Uni t rASL toUP	Function Unit of slope Ramp slope Tolerance band
	LE Page 36	LC 1 LC3 LC4	Frict RL HYSE Rc-R EON EOFF Rc-N EPUL LCP- LCSP	Function Limit value Switching differential Action/Range response Switch-on delay Switch-off delay acknowledgement pulse time Limit comparator PV Limit comparator SP
	DuŁP Page 40	OUEL	0uE 1 	Binary output 1
			0uE4 	Binary output 4
	binF Page 41		F: n2 F: n2 F: n1	Binary input 1 Binary input 2 Limit comparator 1
			 EF I EF2 Lo I Lo2 CC I	Limit comparator 4 Timer 1 Timer 2 Logic 1 Logic 2 Control contact 1
			CCY EaLS Pres	Control contact 4 Tolerance band alarm signal Program end signal
	di SP Page 44		ರು SU ರು SL ರEcP ರು SE	Upper display Lower display Decimal point 16-segment display
	EFcE Page 45	FES FE I	Frict t tolt	Function Timer time Tolerance band

7.2 Analog input "InP"

Configuration

Analog input

Controller
Generator
Limit comparators
Outputs
Binary functions
Display
Timer
Interfaces

Analog input 1 InP I →

Sensor type

Linearization

Symbol	Value/selection	Description
SEnS	0 1 2 3 4 5 6 7 8 9 10	no function Resistance thermometer in 3-wire circuit Resistance thermometer in 2-wire circuit Resistance thermometer in 4-wire circuit Thermocouple Resistance transmitter Heater current 0 — 50mA AC (analog input 2 only) 0 — 20mA 4 — 20mA 0 — 10V 2 — 10V 0 — 1V factory-set on analog input 2: no function
£10	11 12 13 14 15	Linear Pt100 Pt500 Pt1000 KTY11-6 W5Re_W26Re C W3Re_W25Re D NiCr-Con E Cu-Con T Fe-Con J Cu-Con U Fe-Con L NiCr-Ni K Pt10Rh-Pt S Pt13Rh-Pt R Pt30Rh-Pt6Rh B NiCrSi-NiSi N W3Re_W26Re

Factory settings are shown **bold**.

Analog input - continued

Analog input 1 InP I →

	Symbol	Value/selection	Description
Measurement offset	OFFS	-1999 0 +9999	The measurement offset is used to correct a measured value by a certain amount upwards or downwards.
			Examples: Measured Displayed value offset value
			294.7 +0.3 295.0 295.3 -0.3 295.0
			The controller uses the corrected value (= displayed value) for its calculation. This value is not the same as the actually measured value. If incorrectly applied, this can result in impermissible values of the control variable.
			Special case: 2-wire circuit If the input is connected to a resistance thermometer in 2-wire circuit, then the lead resistance is set in ohms here.
Display start	SCL	-1999 0 +9999	On transducers with standard signal and on potentiometers, a display value is assigned to the physical signal.
Display end	SCH	-1999 100 +9999	Example: $0 - 20 \text{mA} \triangleq 0 - 1500 ^{\circ}\text{C}$.
			The range of the physical signal can be 20 % wider or narrower without generating an out-of-range signal.
Filter time constant	dF	0 0.6 100 s	To adjust the digital input filter (0sec = filter off). 63% of the alterations are acquired after 2x filter time constant at a signal step change. When the filter time constant is large: - high damping of disturbance signals - slow reaction of the process value display to process value changes - low limit-frequency (2nd order low-pass filter)
Fine tuning start value	FES	-1999 0 +9999	See description on the following pages.
Fine tuning end value	FEE	-1999 1 +9999	If these values are altered by mistake, then this setting has to be canceled, using the procedure described under "Customized fine tuning". As a rule, these values can not be adopted by another instrument.
Heater current monitoring (output)	HERE	0	No function

Factory settings are shown **bold**.

Analog input (general) I⊓ I →

	Symbol	Value/selection	Description
Temperature unit	Uni E	0	deg. Celsius deg. Fahrenheit Unit for temperature values
Sampling cycle time	CAcr	1 2	50 msec 90 msec 150 msec 250 msec

Factory settings are shown **bold**.

7.2.1 Customized fine tuning

Principle

The customized fine tuning (= fine adjustment) is used to correct the values displayed by the device. This may be necessary, for example, after a system validation, if the displayed values no longer coincide with the actual values at the point where the measurement is taken.

Using a reference measuring instrument, two measured values are determined which should be as far apart as possible (start value, end value). Ensure that the measuring conditions are stable. Enter the reference value found as the start value (FtS) or end value (FtE) on the device to be adjusted.




Caution:

If start value and/or end value deviate from the factory-set values (FtS=0 and FtE=1), a fine adjustment has already been done before. In this case the fine adjustment has to be reset (see below).

Repeating fine adjustment without doing a reset before means that an already adjusted characteristic curve is used. This leads to wrong values.

Example

The temperature inside an oven is measured with a resistance thermometer and displayed on a device. The reading on the device deviates from the actual temperature as a result of the sensor temperature drifting. At 20°C the device reads 15°C, at 80°C it shows 70°C (exaggerated example for better understanding).




Procedure

- * Determine lower measurement value (as low as possible and constant) with a reference measuring instrument;
 - Example: Oven temperature 20°C (= room temperature)
- Set start value at the device to this lower measurement value;
 Example: Set start value (FtS) to 20
- * Increase temperature and determine higher measurement value (as high as posible and constant) with reference measuring instrument;
 - Example: Increase oven temperature to 80°C
- Set end value at the device to this higher measurement value;
 Example: Set end value (FtE) to 80

Characteristic curve

The following diagram shows the changes in the characteristic curve caused by the fine adjustment (point of intersection with the x axis as well as ascent)



Special case: Offset

If the deviation between measured value and displayed value at the low and high measuring point is identical, an offset correction is sufficient (ascent remains unchanged). In this case, fine adjustment is not required.

⇒ Chapter 7.2 "Analog input "InP"" Parameter OFFS

Reset fine adjustment

In order to reset fine adjustment, the same value hast to be given to start value (FtS) and end value (FtE) (e. g. set both parameters to 0). This automatically sets the start value to 0 and the end value to 1 (factory setting).

7.3 Controller "Cntr"

Configuration

Analog inputs
Controller
Generator
Limit comparators
Outputs
Binary functions
Display
Timer
Interfaces

The following are set here: controller type, input variables of the controller, the setpoint limits, conditions for manual mode and the presettings for autotuning (self-optimization).

	Symbol	Value/selection	Description
	Configuration		
Controller type	CFAb	0 1 2 3 4	no function 2-state controller 3-state controller Modulating controller Continuous controller
Control action	CAct	0 1	Direct Inverse
			inverse: The controller output Y is > 0 when the process value is smaller than the setpoint (e. g. heating). direct: The controller output Y is > 0 when the process value is larger than the setpoint (e. g. cooling).
Inhibit manual mode	InHA	0 1	enabled inhibited
			If the manual mode is inhibited, changing over to "manual" is not possible from the keys or via the binary input.
Manual output	HAnd	-100 101	Defines the controller output level after changing over to manual mode. 101 = last output, acceptance with manual mode Please take note of the output limiting y1 and y2 on page 22.
Range output	rOut	-100 0 101	Output on over/underrange. 101 = last output

Factory settings are shown **bold**.

Controller - continued

	Symbol	Value/selection	Description
Setpoint low	SPL	-1999 0 +9999	Setpoint limiting prevents the input of values outside the defined range.
Setpoint high	SPH	-1999 1100 +9999	The correction value is limited for external setpoint with correction.
	Inputs		
Controller process value	(Pr	(analog selector) 1 (Analog inp. 1)	Defines the source for the process value of the control channel. ⇒ See "Analog selector" on Page 26.
External setpoint	ESP	(analog selector) 0 (switched off)	Activates the external setpoint input and defines the source for the external setpoint. ⇒ See "Analog selector" on Page 26.
Output feedback	FEEd	(analog selector) 0 (switched off)	Defines the source for output feedback for a modulating controller. ⇒ See "Analog selector" on Page 26.
	Autotuning		
Method of tuning	E4PE	0	Oscillation method Step response method ⇒ Chapter 8.1 "Autotuning (self-optimization)"
Inhibit tuning	InHE	0 1	enabled inhibited
			The start of autotuning can be inhibited from the keys or through the binary function.
Output of tuning 1	OFF I	0	Relay Solid-state + logic
Output of tuning 2	0FFS		Continuous
Controller standby output	50ut	-100 0 +100%	Initial output with step response
Step size	SES 1	10 30 100%	Step size with step response

Factory settings are shown **bold**.

7.4 Generator "Pro"

Configuration

Analog inputs
Controller
Generator
Limit comparators
Outputs
Binary functions
Display
Timer
Interfaces

The basic function of the instrument is defined here. The instrument can be operated as a fixed-setpoint controller with or without a ramp function, or warm-up ramp for hot-channel equipment, program controller or program generator.

Function

Symbol	Value/selection	Description
General		
Fnct	0 1 2 3 4	Program generator
		Ramp function: A rising or a falling ramp function can be implemented. The ramp end value is determined by the setpoint input.
		Setpoint Process value w1 11 Power on (w1 aktiv) 12t3 Power failure / manual operation / probe break
		t4t5 Ramp stop
		The ramp function is interrupted on a probe break, or for manual mode. The outputs react as for overrange/underrange (configurable).
		Program generator: The setpoint profile is output via a continuous output.
Uni E	0 1 2	Ramp function °C/min °C/hour °C/day Program mm:ss hh:mm dd:hh
		s=seconds; m=minutes; h=hours;d=days
		Unit of ramp slope in °C per time unit, or format of segment times for program controller/generator.


Factory settings are shown bold.

Unit of slope

Generator - continued

Ramp slope

Tolerance band



Factory settings are shown bold.

7.5 Limit comparators "LC"


Configuration

Analog inputs
Controller
Generator
Limit comparators
Outputs
Binary functions
Display
Timer
Interfaces


Limit comparators (threshold monitors, limit contacts) can be used to monitor an input variable (process value for the limit comparator) against a fixed limit or another variable (the setpoint for the limit comparator). When a limit is exceeded, a signal can be output or an internal controller function initiated.

4 limit comparators are available.

Limit comparator functions (lk)



In the case of the limit comparator functions lk7 and lk8, the measurement that is set is monitored with respect to a fixed value AL.



Limit comparators - continued

Limit comparator 1 LC I →
Limit comparator 2 LC2 →
Limit comparator 3 LC3 →
Limit comparator 4 LC4 →


Function
Limit value
Limit value
Switching differential

Symbol	Value/selection	Description
Fnct	0 1 2 3 4 5 6 7 8	no function Ik1 Ik2 Ik3 Ik4 Ik5 Ik5 Ik6
AL	-1999 0 +9999	Limit value to be monitored Limit range for lk1 and lk2: 0 — 9999
HYSE	0 1 9999	Switching differential

Limit comparators - continued

Limit comparator 1 LC I → Limit comparator 2 LC 2 → Limit comparator 3 LC 3 → Limit comparator 4 LC 4 →

Action/ range response



Limit comparators - continued

Limit comparator 1 LC I →
Limit comparator 2 LC2 →
Limit comparator 3 LC3 →
Limit comparator 4 LC4 →

	Symbol	Value/selection	Description		
Switch-on delay	£0n	0 9999	Delays the switch-on edge by a definable time period		
Switch-off delay	EOFF	0 9999s	Delays the switch-off edge by a definable time period		
Acknowledgement	AcnL	0 1 2	no acknowledgement acknowledgement; only with inactive limit comparator acknowledgement; always possible For settings with acknowledgement, the limit comparator is latching, which means it remains ON, even when the switch-on condition is no longer present. The limit comparator must be reset via the + EXIT keys or binary signal.		
Pulse time	EPuL	0 9999s	The limit comparator is automatically reset after an adjustable time period.		
Limit comparator PV	LCPr	(analog selector) 1 (analog input 1)	see circuit diagrams ⇒ See "Analog selector" on Page 26.		
Limit comparator SP	LCSP	(analog selector) 4 (present setpoint)	see circuit diagrams (only with lk1 — lk6) ⇒ See "Analog selector" on Page 26.		

7.6 Outputs "OutP"

Configuration

Analog inputs
Controller
Generator
Limit comparators
Outputs
Binary functions
Display
Timer
Interfaces

Numbering of the outputs

(Binary) output 1 = relay
(Binary) output 2 = relay
(Binary) output 3 = logic output
(Binary) output 4 = logic output
Terminal strip 3 see page 9
Terminal strip 2 see page 9
Terminal strip 2 see page 9

Binary outputs Dutt

Binary output 1

Binary output 4

Dinary 0	Binary outputs DDCC					
Symbol	Value/selection	Description				
Out 1	0	no function				
1000 .	1	Controller output 1				
	2	Controller output 2				
	5	Binary input 1				
_	6	Binary input 2				
Out4	13	Limit comparator 1				
	14	Limit comparator 2				
	15	Limit comparator 3				
	16	Limit comparator 4				
	17	Control contact 1				
		Control contact 2				
		Control contact 3				
		Control contact 4				
	21	Logic formula 1				
	22	Logic formula 2				
		Timer 1 active				
		Timer 2 active				
	25	Program active				
	26	Program end signal				
		Tolerance limit signal				
		Manual mode on/off				
	29					
		Any binary value from storage address (only through setup)				
	31	always active				
		Function of the binary output				

Factory settings

0ut 1	13	Limit comparator 1
0ºFS	14	Limit comparator 2
0ut3	1	Controller Output 1
0uE4	1	Controller Output 1

7.7 Binary functions "binF"

Configuration

Analog inputs
Controller
Generator
Limit comparators
Outputs
Binary functions

Display Timer


Interfaces

Functions are assigned here to the binary signals of the binary inputs and limit comparators.

In addition, the functions for control contacts, tolerance limit signal and program end signal are defined for program controllers/generators.

In the case of a fixed-setpoint controller, functions can be assigned to the ramp end signals.

Switching action



The functions are arranged in two groups:

Edge-triggered functions

The binary function reacts to switch-on edges.

The following functions are edge-triggered:

- Start/stop of autotuning
- Acknowledge limit comparators
- Program start/cancel
- Start timer
- Segment change

State-triggered functions

The binary function reacts to switch-on or switch-off states.

- All remaining functions

Binary functions - continued

Binary input 1

Binary input 2

Limit comparator 1

Limit comparator 4

Timer 1

Timer 2

Logic 1

Logic 2

Symbol	Value/selection	Description
binl	0	no function
	1	Start autotuning
	3	Cancel autotuning Change to manual mode
p, n2	1 4	Controller off (controller outputs are switched off)
0,,,,,	5	Inhibit manual mode
LE I	6	Hold ramp
	7	Cancel ramp
	8	Setpoint changeover
		Parameter set switching
LC4		Key inhibit Level inhibit
EF :		Display "off" with key inhibit
<u>'</u> ' '		Acknowledge limit comparators
FE5		Inhibit program start
		Start program
Loi		Pause program
	17	
ro5		Segment change
		Start timer 1 Start timer 2
	21	
		Cancel timer 2
		Level inhibit: The parameter and configuration levels are inhibited.

Factory settings: Bin1 = 8, Bin2 = 10

Setpoint and parameter set switching

A binary function can be used to switch between setpoint 1 and setpoint 2 or parameter set 1 and parameter set 2.

Setpoint switching	Parameter set switching	Binary signal	
Setpoint 1 active	Parameter set 1 active	0/contact open	
Setpoint 2 active	Parameter set 2 active	1/contact closed	

In order to switch between the four possible setpoints, two binary functions must be configured to "setpoint switching". The states of the two binary functions are designated Z1 and Z2 and switch the setpoints over as shown in the table below:


Setpoint	Z2	Z 1
Setpoint 1	0	0
Setpoint 2	0	1
Setpoint 3	1	0
Setpoint 4	1	1

0 = contact open /OFF

1 = contact closed /ON

Binary functions - continued

The states Z1 and Z2 are assigned to the binary functions in descending order (see list on the right), i.e. the first binary function selected in the list is Z1.



Example:


The setpoint is to be selected via a binary input and the state of one limit comparator.

This results in the following assignment:


Z1 - binary input 1

Z2 - limit comparator 1

The binary function for the binary input 1 and limit comparator 1 have to be configured to "setpoint switching"



Depending on the further configuration, the following diagram applies:



* An exception to this is the configuration for a program controller with external setpoint input, with or without correction. Setpoint 2 is the program setpoint in this case.

7.8 Display "diSP"

Configuration
Analog inputs Controller Generator Limit comparators Outputs Binary functions Display Timer Interfaces

	Symbol	Value/selection	Description
	General		
Upper display	d. 5U	(analog selector) 1 (controller process value)	Displayed value for the upper display ⇒ See "Analog selector" on Page 26.
Lower display	d. SL	(analog selector) 4 (controller setpoint)	Displayed value for the lower display ⇒ See "Analog selector" on Page 26.
Decimal point	dEcP	2	no decimal place one decimal place two decimal places If the value that is be displayed can no longer be represented with the programmed decimal point, then the number of decimal places will be automatically reduced. If, subsequently, the measured value decreases, the number increases to the programmed value of the decimal point.
16-segment display	di SE	2	Displayed value for the two-digit 16-segment display switched off Unit (°C or °F) current segment current parameter set no function

7.9 Timer "tFct"

Configuration

Analog inputs
Controller
Generator
Limit comparators
Outputs
Binary functions
Display
Timer
Interfaces

Time-dependent control actions can be carried out with the help of the timer. The timer signal (timer 1+2) shows whether the timer is active. It can be output via the binary outputs or processed internally.

The timers are started or canceled via the binary functions.

⇒ Chapter 7.7 "Binary functions "binF""

The current times for the timers can be viewed at the operator level (process data).

Timer 1 년두 ¦ → Timer 2 년두군 →

Function

Symbol	Value/selection	Description
Fnct	0 1 2 3	no function with the timer running: binary signal=1 (signal is active) with the timer running: binary signal=0 (signal is not active) Tolerance band
		Function: "Tolerance band"
		SP toLt Start Timer is running when the process value has reached a tolerance band around the setpoint.
۲	099:59 (hh:mm)	Time input
tolt	0 999	0=off

Timer time
Tolerance limit


8.1 Autotuning (self-optimization)

Oscillation method

Autotuning (self-optimization, SO) establishes the optimum controller parameters for a PID or PI controller.

Depending on the controller type, the following controller parameters can be defined: Reset time (rt), derivative time (dt), proportional band (Pb), cycle time (Cy), filter time constant (dF)

The controller selects one of two procedures (a or b), depending on the size of the control deviation:



Step response method

This type of optimization involves determining the control parameters through an output step that is applied to the process. First a standby output is produced until the process value is "steady" (constant). Afterwards, an output step (step size), which can be defined by the user, is automatically applied to the process. The resulting response of the process value is used to calculate the control parameters.

Autotuning establishes the optimum control parameters for a PID or PI controller, according to the selected control structure.

Depending on the controller type, the following control parameters can be determined: Reset time (rt), derivative time (dt), proportional band (Pb), cycle time (Cy), filter time constant (dF)

Autotuning can be started from any system status, and can be repeated as often as is required.

The controller outputs (logic, relay), the controller standby output and the step size (min. 10%) have to be defined.


Principal applications of the step response method


- Autotuning instantly after "power on", during the approach phase
 Considerable time savings, setting: controller standby output = 0 %.
- The process does not readily permit oscillations (e.g. highly insulated furnaces with small losses, long oscillation period)
- Process value must not exceed setpoint
 If the output (with stabilized setpoint) is known, overshoot can be avoided through
 the following adjustment:
 standby output + step size <= output in stabilized condition</p>




With the "relay" output type, care has to be taken that the process value is not influenced by the cycle time, since otherwise autotuning can not be completed successfully.

Solution: Reduce the cycle time Cy, until the process value is no longer influenced. (Manual mode can be used for the adjustment!)





Start of autotuning during operation



Starting autotuning

* Start with and (simultaneously >2 sec) "tUnE" is shown, blinking, in the lower display

Autotuning is ended when the display automatically changes over to normal display.

The duration of autotuning depends on the control process.





The controller output types have to be defined for autotuning.

⇒ Chapter 7.3 "Controller "Cntr""

For a program controller, autotuning can only be started in the normal display.


Canceling autotuning

★ Cancel with and (simultaneously)

8.2 Check of the tuning

The optimum adaptation of the controller to the process can be checked by recording the approach phase with the control loop closed. The diagrams below indicate possible maladjustments and how these can be corrected.

The control response of a third-order control loop for a PID controller is shown as an example. However, the procedure for adjusting the controller parameters can also be applied to other control loops.



9.1 Technical data

Thermocouple input

Designation		Measuring range	Measuring accuracy	Ambient temperature error
Fe-Con L		-200 to + 900°C	≤0.25%	100 ppm /°C
Fe-Con J	EN 60584	-200 to +1200°C	≤0.25%	100 ppm /°C
Cu-Con U		-200 to + 600°C	≤0.25%	100 ppm /°C
Cu-Con T	EN 60584	-200 to + 400°C	≤0.25%	100 ppm /°C
NiCr-Ni K	EN 60584	-200 to +1372°C	≤0.25%	100 ppm /°C
NiCr-Con E	EN 60584	-200 to +1000°C	≤0.25%	100 ppm /°C
NiCrSi-NiSi N	EN 60584	-100 to +1300°C	≤0.25%	100 ppm /°C
Pt10Rh-Pt S	EN 60584	0 to 1768°C	≤0.25%	100 ppm /°C
Pt13Rh-Pt R	EN 60584	0 to 1768°C	≤0.25%	100 ppm /°C
Pt30Rh-Pt6Rh B	EN 60584	0 to 1820°C	≤0.25% ¹	100 ppm /°C
W5Re-W26Re C		0 to 2320 °C	≤0.25%	100 ppm /°C
W3Re-W25Re D		0 to 2495 °C	≤0.25%	100 ppm /°C
W3Re-W26Re		0 t o 2400 °C	≤0.25%	100 ppm /°C
Cold junction			Pt100, internal	

^{1.} in the range 300 to 1820 °C

Input for resistance thermometer

Designation		Connection	Measuring range	Measurin accuracy	J	Ambient temperature error
				3-/4-wire	2-wire	
Pt100	EN 60751	2-wire / 3-wire / 4-wire	-200 to +850°C	≤0.05%	≤0.4%	50 ppm / °C
Pt500	EN 60751	2-wire / 3-wire / 4-wire	-200 to +850°C	≤0.2%	≤0.4%	100 ppm /°C
Pt1000	EN 60751	2-wire / 3-wire / 4-wire	-200 to +850°C	≤0.1%	≤0.2%	50 ppm /°C
KTY11-6		2-wire	-50 to +150°C	≤1.0%	≤2.0%	50 ppm /°C
Sensor lead resis	stance	max. 30Ω per lead for 3-wire or 4-wire circuit				
Measuring curre	nt	approx. 250μA				
Lead compensat	ion	Not required for 3-wire or 4-wire circuit. With a 2-wire circuit, the lead resistance can be compensated in software by a correction of the process value.				

Input for standard signals

Designation	Measuring range	Measuring accuracy	Ambient temperature error	
Voltage	0(2) - 10V 0 - 1V input resistance R _{IN} > 100kΩ	≤0.05% ≤0.05%	100 ppm / °C 100 ppm / °C	
Current	0(4) — 20 mA, voltage drop ≤ 1.5V	≤0.05%	100 ppm / °C	
Heating current	0 — 50mA AC	≤1%	100 ppm / °C	
Resistance transmitter	min. 100 Ω , max. 4 k Ω	±4Ω	100 ppm / °C	

Binary inputs

Floating contacts	

9 Appendix

Measuring circuit monitoring

In the event of a fault, the outputs move to a defined (configurable) status.

Sensor	Overrange / underrange	Probe or lead short-circuit	Probe or lead break
Thermocouple	•	-	•
Resistance thermometer	•	•	•
Voltage 2 — 10V 0 — 10V 0 — 1V	•	• - -	• - -
Current 4 — 20mA 0 — 20mA	•	•	• -
Resistance transmitter	-	-	•

^{• =} recognized -= not recognized

Outputs

Relay (changeover) contact rating contact life	3A at 230V AC resistive load 350,000 operations at rated load / 750,000 operations at 1A
Logic output	0/12V / 30mA max. (sum of all output currents)
Auxiliary voltage	DC 17V at 20mA load, 25V with no load, electrically isolated, not stabilized

Controller

Controller type	2-state controller,		
	3-state controller, modulating controller, continuous controller		
Controller structures	P/PD/PI/PID		
A/D converter	dynamic resolution up to 16-bit		
Sampling cycle time	250 msec		
	50msec, 90msec, 150msec, 250msec		

Electrical data

Supply voltage (switchmode PSU)	110 — 240V AC -15/+10%, 48 — 63Hz		
Electrical safety	to EN 60730		
	Overvoltage category III, pollution degree 2		
Power consumption	max. 7VA		
Data backup	EEPROM		
Electrical connection	at the back, via screw terminals, conductor cross-section up to 2.5mm ² with core ferrules (length: 10mm)		
Electromagnetic compatibility interference emission interference immunity	EN 61326-1 Class B to industrial requirements		

Housing

Housing type	plastic housing for panel mounting to IEC 61554
Depth behind panel	90 mm
Ambient/storage temperature range	0 to 55°C / -30 to +70°C
Climatic conditions	rel. humidity ≤90% annual mean, no condensation
Operating position	horizontal
Enclosure protection	to EN 60529, front IP65 / back IP20
Weight	420g

9.2 Alarm messages

Display	Cause	Fault removal test/repair/replace
- 1999 (blinking!)	Underrange for the value being displayed.	Check that the connected probe com- plies with the configured sensor type and linearization
9999 (blinking!)	Overrange for the value being displayed.	Check the probe connection and the terminals
		- Check the cable
		- Check probe for short-circuit and probe break
		- In case of standard signal: Is the signal within the permissible range (e.g. 4 - 20mA)?
9999 (lower display)	Error in output feedback of modulating controller	Check the source signal for output feedback
 (blinking!)	Source signal for controller process value is switched off	Select a source signal in configuration level
all displays on; lower 7-segment display is blinking	Watchdog or power-on trigger initialization (reset).	Replace the controller if the initialization continues for more than 5 sec
OPE	Hardware configuration error	Check which option boards are installed in the slots

Overrange / underrange covers the following events:

- Probe break or short-circuit
- Measurement is outside the controllable range for the probe that is connected
- Display overflow

9 Appendix

Α

Access code 25
Acknowledgement 39
Analog input 28
Analog selector 28
Autotuning (self-optimization) 33, 47

B

Binary functions 41 Binary output 40

C

Commissioning 2
Connection diagrams 11
Control action 32, 45
Controller 32
Controller module, removing 8
Controller standby output 33
Controller type 32, 40, 42, 45

D

Decimal point 44 Dimensions 7 Display 44 Display end 29 Displays 13

Ε

Electrical isolation 10 Entering programs 18 Entering times 15 Entering values 15

F

Filter time constant 29
Fine tuning 29–30
Fitting 8
Front panel, care of 8

Н

Heater current monitoring 29 Hot-channel controller 36

I

Installation notes 9

L

Level concept 14
Level inhibit 14
Limit comparator 36
Limit comparator functions 36
Limit value 37
Linearization 28

M

Manual mode 16
Manual mode, inhibiting 32
Manual output 32
Measurement offset 29
Mounting site 7

0

Outputs 40

P

Parameter level 23
Parameter set switching 42
Password 25
Process data 21
Pulse time 39

R

Ramp slope 35 Range output 32

S

Sampling cycle time 29
Sensor type 28
Setpoint 21
external 33
Setpoint limits 33
Setpoint switching 42
Side-by-side mounting 7
Step response method 47
Step size 33
Switching action 41
Switching differential 37
Switch-on delay 39

T

Tolerance band 35, 45 Tuning (optimization) 50

U

Unit 29, 34

W

Warranty 2



Industrial Heat Sources

PO Box 770327 1414 Riverside Drive, Suite 204 Lakewood, Ohio, 44107 Tel: 844-862-7880 Fax: 216-862-7979

Email: info@ihshotair.com Website: www.ihshotair.com