

TRAKAMEC LITE INSTALLATION GUIDE

TD0195

17/02/20

V1.0

This Document is the subject of copyright and must not be copied or otherwise reproduced either in whole or in part without the written permission of Traka.

This Document is uncontrolled when printed unless over-stamped "CONTROLLED DOCUMENT"

CONTENTS

Version History		
Conte	nts3	
1. I	ntroduction4	
2. P	rerequisites	
2.1	What You Should Have5	
2.2	Tools And Materials Required6	
2.3	Dimensions6	
3. I	nstallation8	
4. T	echnical Support10	

1. INTRODUCTION

TrakaMEC is a new addition to Traka Automotive. TrakaMEC is designed to meet the needs of many dealerships and service centres which are not yet demanding fully networked and integrated Key Management Systems. It is a highly cost-effective and robust mechanical Peg-in-Peg-out Key Management System.

TrakaMEC Lite is a low cost & effective mechanical Key Management solution that comes in a black powder coated steel frame with a locking T-Handle. TrakaMEC Lite is an ideal solution where there are no security risks. Please note that the TrakaMEC Lite Cabinet can also be used for the TrakaMEC Lite licence plate holder.







2. PREREQUISITES

2.1 WHAT YOU SHOULD HAVE

1) TrakaMEC Lite Cabinet



2) T-Handle



TD0195

2.2 TOOLS AND MATERIALS REQUIRED

Traka does not provide tools and certain materials for the installation of the TrakaMEC Lite, so you will need to source the following:

- Drill
- Wall Fixings (appropriate for the type of wall you are fixing to)
- Large Flat Headed Screwdriver
- Hammer
- Spirit Level
- Measuring Tape

NOTE: Due to the weight of this product we recommend you use appropriate support. Please be advised that the TrakaMEC Supreme Cabinet installation is a TWO person job and due to the weight and size of the Cabinet you should always follow correct Manual Handling techniques.

NOTE: TrakaMEC systems can be very heavy and therefore need a strong wall to fix to. The wall fixings are not included so when selecting the appropriate fixings it is essential they are strong enough to retain the system to the wall.

NOTE: The wall (and any wall covering) to which the TrakaMEC System is fixed must be made of low flammability material (at least 94 UL-5V flammability class equivalent).

2.3 DIMENSIONS







3. INSTALLATION

1. Unpack the TrakaMEC Cabinet from the box.



2. With the help of another person following correct Manual Handling techniques, lift and locate the TrakaMEC Cabinet to the desired wall position.



3. Open the Cabinet door and mark out the 4 fixing holes located inside the Cabinet on the wall referring to the template found in Section 2.3 Dimensions if required.



NOTE: Make sure that you use a spirit level to check that you holes are straight and level.

V1.0 04/02/20

TD0195

Page 8 of 10

This Document is uncontrolled when printed unless over stamped "CONTROLLED DOCUMENT"

4. Drill the marked fixing points. Ensure you are using correct PPE including googles and ear protection.



5. Next, insert the correct fixings appropriate to the wall type that you are mounting the Cabinet onto.



6. With the help of another person, lift the cabinet and align with drilled fixing points. Secure the Cabinet to the wall using the 4 drilled fixing points.



- 7. To fit the T-Handle follow the instructions included within this Cabinet.
- 8. You are ready to use your Cabinet, for further information please visit www.trakamec.com

4. TECHNICAL SUPPORT

If you need to contact Traka/distributor for technical support:

Technical Support Information

UK Telephone: 0333 920 5809

Web: <u>www.trakamec.com/support</u>