

# PROAIM L CINEMA SERIES J Euro/Elemac to Mitchell Riser Adapter (MA-293-00)

#### Assembly Manual



### What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Proaim Euro/Elemac to Mitchell Riser Adapter

All rights reserved.

#### Euro to Mitchell Riser Adapter **Setup**

 Loosen the ratchet knob of the Mitchell Riser Adapter and mount it on the euro adapter quick lock (Not Included), as shown in the image.





 Secure the Mitchell Riser Adapter using the ratchet knob.

**NOTE:** Proaim Euro Base to Mitchell Camera Riser is used to raise the height of your camera setup.





 Now, the Mitchell Riser Adapter is properly mounted.

**NOTE:** You can attach it to any Dolly or Bazooka via Euro Mount Adapter.



 Loosen and remove the castle nut of the Mitchell Fluid Head (Not Included) and mount it on the Mitchell mount, as shown in the image.





• Re-insert the castle nut from the bottom and tighten it.





 Remove the plate of the Fluid head by pressing the buttons present on it and attach it to the camera (Not Included), as shown in the image.





• Securely tighten the plate using an Allen key and slide it onto the Fluid Head.





• Now, secure the camera (Not Included) using the locking lever, as shown in the image.





**NOTE:** It allows easy mounting of Mitchell mount products. It has various  $\frac{1}{4}$ "-20 and  $\frac{3}{6}$ "-16 accessory mounting threads.



## YOUR PROAIM EURO/ELEMAC TO MITCHELL RISER ADAPTER ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

**Warranty:** We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

**Liability:** We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

**Contact Us:** In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.