PR → A | MB-10 Lightweight Clip-On Matte Box (MB-10)

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Matte Box Setup

Attaching Filter with Metal Frame

If you want to attach the filter (Not Included)
press the button and insert filter (Not
Included) into the frame. Be sure your filter is
fitted properly.





Attaching Rubber Hood with Metal Frame

 Attach the rubber hood with metal frame properly.





NOTE: The adapter which is attached to the bottom of the metal frame knob is for multi-purpose usage within different setups

 Attach 15mm Rod adapter in the provided metal frame knob connector and tighten the knobs properly with the help of Allen key. You can adjust the lense position movement according to your requirement.





 Next, attach your top flag into the metal frame, you can adjust top flag movement of the metal frame by loosen/tighten the knob to secure the sections together.





Ring Clamp Setup

 114-110mm ring clamp attached into metal frame. You can adjust the lens position movement according to your requirement. Follow the same process Remaining 5 rings clamp.





YOUR PROAIM MB-10 LIGHTWEIGHT CLIP-ON MATTE BOX ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.