Quado 4-Leg Mitchell Camera Tripod Stand (TP-QUADO)

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Quado 4-Leg Mitchell Base Stand **Setup**

 Loosen the telescopic ratchet knob of the Quado Stand to extend the legs.

Note: Quado stand has an angle marking of 0-9 on all the legs. Angle markings make sure all the stand legs are out at the same angle.





• Tighten the ratchet knob to the desired angle according to your setup requirements.





 Loosen the leg rotating knob of the quado stand, open all four legs equally according to the requirement and tighten the knob back.





Note: Four locking knobs help to set the Stand legs accurately and firmly. In addition, a toothed locking mechanism on the top of the legs helps securely lock the legs at the desired position.





Note: Quado can go down flat on the floor as 4" and function just as low as a hi-hat, or as a 1'6" mini stand or go up as high as full 3'9" height.



Fluid Head Mounting on Quado Stand

 To mount a 100mm or 150mm or any other fluid head (Not-Included) on the Quado Mitchell Base Stand, you must first install a 150mm bowl mount (Not-Included), as shown in the images.





 To mount 150mm fluid head (Not-Included), insert it into the bowl through the screw and secure it with the knob at the bottom. Now you can mount the camera setup as per your requirement.

Note: It works efficiently with equipment such as Camera Slider and Geared Heads. When using with Sliders, open the legs as per the length of the Slider for better Stability.









YOUR PROAIM QUADO 4-LEG MITCHELL CAMERA TRIPOD STAND ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.