

CHEPIN

CLEANING YOUR CHAPIN 1900 SERIES SPRAYER

1949 / 19049 / 19149 / 19249 / 1979 / 19069 / 1999 / 19099

BETWEEN USE ON THE JOB



When leaving product in sprayer (short term)

1 Pressurize sprayer



2 Tip sprayer upside-down, or on its side (with outlet tube at 12:00). Spray until only air is fully expelled



3 Turn right-side up and place in shaded area before using again



4 Remove nozzle and soak in Xylene*

^{*}ALWAYS READ YOUR USER MANUAL CAREFULLY AND FOLLOW
CHEMICAL MANUFACTURER'S INSTRUCTIONS FOR PROPER USE. IF
CHEMICAL COMPATIBILITY WITH SPRAYER IS IN QUESTION, BEFORE USE
CONTACT CHAPIN TECHNICAL SUPPORT: 800.950.4458





CLEANING YOUR CHAPIN 1900 SERIES SPRAYER

1949 / 19049 / 19149 / 19249 / 1979 / 19069 / 1999 / 19099

STORAGE UNTIL NEXT JOB



Cleaning your sprayer thoroughly (long term)





2 Pour half quart of Xylene* into sprayer. Spray until all Xylene is expelled



- 3 Repeat steps 1 and 2
- 4 Remove nozzle and soak in Xylene*



^{*}ALWAYS READ YOUR USER MANUAL CAREFULLY AND FOLLOW
CHEMICAL MANUFACTURER'S INSTRUCTIONS FOR PROPER USE. IF
CHEMICAL COMPATIBILITY WITH SPRAYER IS IN QUESTION, BEFORE USE
CONTACT CHAPIN TECHNICAL SUPPORT: 800.950.4458