



# Toyota Prius 2005-2009



TY-60-09-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

When properly installed, the metal between the ball and 2 small holes is all that is exposed.  
(Some exceptions apply).

**TOOLS REQUIRED:** Dash Trim Removal Tool (DTRT), 10mm socket and driver

**PARTS INCLUDED:** VSM G3, A Plate, J Stem

**LOCATION:** Right of Display

**Step 1:** The air vent trim piece to the right of the radio must first be removed (picture 1). Begin by placing the DTRT in the space between the radio and the air vent trim piece. Use the DTRT in a gentle twisting motion around this trim piece in order to release a series of 6 retainer clips. Open the passenger side upper and lower glove boxes in order to make the removal of the air vent trim piece easier. Once the air vent trim piece has been removed, set it carefully off to the side.



**Step 2:** Locate the 10mm bolt pictured (picture 2). Use a 10mm socket and driver to remove the bolt and set it carefully aside. Place the VSM G3 in position just as pictured. Make sure the bottom of the VSM G3 runs parallel with the plastic ledge as indicated by a highlighted line in picture 2. Once the VSM G3 is flush and in position, replace the 10mm bolt over VSM G3 through the pilot hole and secure the VSM G3 as flush to the dash molding as possible.



**Step 3:** Once the VSM G3 is secured and in position, begin to replace the dash back together in the reverse order in which it was dismantled. You have successfully installed your VSM G3!



Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™.

Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

