

VERRIDE

FOR HEALTHCARE PROFESSIONALS

This over-the-glasses model helps to reduce workplace accidents. Equipped with an **anti-scratch and anti-fog coating** on both sides of the lens, OVERRIDE ensures long-lasting comfort, performance and reliability. Compatible with most prescription glasses. Suitable for healthcare industry.



1650515 • Clear wrap-around frame



45 g



+ CLOSE FITTING HIGH CONTOUR DESIGN FOR IMPROVED EYE PROTECTION

+ FITS OVER PRESCRIPTION GLASSES

+ SINGLE PIECE POLYCARBONATE DISTORTION FREE LENS


+ WASHABLE AND REUSABLE

+ ADJUSTABLE TEMPLE ARMS FOR A SECURE, COMFORTABLE FIT

bolle
SAFETY

VERRIDE

FOR HEALTHCARE PROFESSIONALS

MODEL	VERSIONS	REFERENCES	LENS MARKING	FRAME MARKING	COATINGS
VERRIDE	 Clear	1650515	IO	AS/NZS 1337.1:2010	Anti-scratch/Anti-fog

LENS MARKING

- I. The letter 'I' signifies 'Medium Impact' approval.
- O. The letter 'O' signifies that the product has been approved for the use both outdoors and indoors, and the terminology used by Australian standards is 'outdoor un-tinted'. This marking appears on all clear lenses.

Ocular lens category:

- O. Range of luminous transmittance 80–100% (Clear)

LENSES

- 2mm polycarbonate
- Anti-scratch/anti-fog coating on both sides of Clear lens
- 99.9% UV 385 – Clear

FRAME MARKING

AS/NZS 1337.1:2010 Tested and approved to AS/NZS 1337.1.2010 for medium impact protection. Resists a 6 mm ball at 45 m/s.

CLEANING AND STORAGE

CLEANING: The lenses should be cleaned regularly. Bollé Safety recommends only using the B-clean lens cleaning system.

MAINTENANCE: Pitted, scratched or damaged lenses must be replaced by replacing the complete product. If the frame is damaged also replace the complete product. After each use it is recommended to keep the spectacles or goggles in a microfiber pouch or rigid case.

STORAGE: All products must be stored in a dry and clean environment.

Always read and follow the instructions on the label.

CHARACTERISTICS

LENSES	PC - 2,2 mm
FRAME	PC
TEMPLE	PC
STRAP	Non applicable
FOAM	Non applicable
SPARE LENSES	No



Non-contractual pictures
26/05/2021

ASIA/PACIFIC HEADQUARTERS:

Bollé Safety AU Pty Limited
32–40 Fairchild Street
Heatherton VIC 3202
T: 1300 138 098
E: sales@bollesafety.com.au

bollesafety.com.au

NEW ZEALAND:

T.: 0800 2655 369
E: sales@bollesafety.com.au

bolle
SAFETY