

SpecializedRx 3787 95th Ave NE Suite 100 Circle Pines, MN 55014 USA 888.512.1209 www.specializedrx.com

SmartPopps[™] Holder Assembly Instructions

SmartPoppsTM Holder requires assembly prior to use. The two end legs need to be fastened to the center rail section. Six (3/16) screws are provided along with a (3/16) Alan wrench to fasten the legs to the center rail. Care should be taken to not overtighten during assembly as overtightening can strip the screw threads on either of the legs.

- 1. Step 1- assemble both of the legs to the ends of the center rail, looking to line up holes properly. The SpecializedRx logo should be facing upward on the center rail.
- 2. Step 2- carefully start threading each screw by hand so that it engages with the threads. Not lining up the threads properly to start will cause an improper thread alignment and potentially damage the threads.
- 3. Step 3- tighten screws so that they are snug with the allen wrench provided. Do not overtighten. There should not be a gap between each end leg and center rail, it should be a tight fit. If there is a gap, remove screws, realign leg and center rail and start Step 2 again.
- 4. Step 5- once all screws are securely fastened, the SmartPopps™ Holder is ready for use.

SmartPopps[™] System Suggested Use Instructions

- 1. Separate mold cavities and visually inspect them, assuring they are free of any foreign particles.
- 2. SmartPopps were engineered to not require mold release lubricant when used with SpecializedRx Candy Bases. If needed, a very light coating of mold release (Pam® cooking spray, cocoa butter, etc.) can be applied to the interior of the cavities to help aid lollipop removal.
- 3. Insert sticks provided into the SmartPopps™ molds. Be sure to use only SpecializedRx provided sticks as other sticks should not be used due to dimensional/quality requirements to function with molds.
- 4. Place SmartPopps[™] Stand on a clean, level working surface.
- 5. Then insert molds into the preferred open spaces of the SmartPopps™ Lollipop Stand Item# E0502-00.

 The stand is required to apply the pressure needed to the cavity halves for a tight fit. Not using the stand may result in contents flashing or leakage along the cavity seams.
- 6. Then visually inspect to assure each stick is resting on the level working surface. This will ensure consistent filling accuracy from unit to unit. If a stick is not resting on the working surface, pull the stick down to meet the surface.
- 7. Once all molds and sticks are in place, they are ready to start filling. We recommend using the variety of SpecializedRx bases available found online at www.specializedrx.com
- 8. Carefully fill each mold to prevent overflow. For ease of filling, recommended use of a catheter tip style syringe (Item E0568) or beaker based on preference.
- 9. Once mold contents are cooled and set, the molds can be removed from the stand by pushing each unit up from the bottom. Lollipops can be inspected by separating the halves to ensure contents move freely. Individual SmartPopps™ can be separated by gently breaking the two center tabs off each side.
- 10. Each unit should be checked for proper weight according to your quality control procedure to maintain appropriate weight tolerance.
- 11. Once the weight has been verified, the child resistant caps can be applied to each unit. Use only SpecializedRx supplied child resistant caps. Other caps should not be used due to dimensional requirements to securely fasten caps to SmartPopps™ molds.

SpecializedRx 3787 95th Ave NE Suite 100 Circle Pines, MN 55014 USA 888.512.1209 www.specializedrx.com

Note:

- Procedures should be adjusted based on use and the variety / quantity of ingredients to be used.
- Use only SpecializedRx supplied lollipop sticks and child resistant caps. Use of any other product has not been verified for functional use or child resistant assurance. Only SpecializedRx supplied SmartPopps™ System components meet the requirements of the CFR and ISO standards for child resistance.

Disclaimer: SpecializedRx makes no warranties or claims to the accuracy or completeness of the above information given the variations in use and formulations. These suggested use instructions are provided as user guidance considering varying circumstances. The SmartPoppsTM System was designed for compounding single use units. Components should be discarded or recycled following patient use.

Associated Products:

SmartPopps CR Lollipop Molds, 24 Count, Item# E0500-01

SmartPopps Prescription Lollipop Stand (30 count) Item# E0502-00

Pipette, Large Volume High Temp Glass, (60ml) Item# E0573-00 (1pk)

Nextol SFTM Candy Base w/ Bitter-Bloc (sugar-free) 1Kg, Item# B0030-55

Nextol SF[™] Candy Base w/ Bitter-Bloc (sugar-free), 2.0Kg, Item# B0030-62

Krystal SF[™] Quickset Candy Base w/ Bitter-Bloc (sugar-free)1Kg, Item# B0020-55

Krystal SF[™] Quickset Candy Base w/ Bitter-Bloc (sugar-free)2.0Kg, Item# B0020-62