

WOCA WOODCARE

₱ 877-962-2645

■ info@wocawoodcare.com

WOCA DIAMOND ACTIVE MAINTENANCE OIL

WOCA Diamond Active Maintenance Oil is for "re-oiling" oiled wood surfaces which restores and refinishes oiled wood floors. Product, room and floor temperature should be at least 59 degrees. Ensure good ventilation during application and drying time.

Work Instructions:

- 1. Damp mop the floor with WOCA Intensive Wood Cleaner (dilute 3 ounces of WOCA Intensive Wood Cleaner to 1 gallon of lukewarm water). Let the floor dry completely. This is a mandatory step that deep cleans the oiled wood surface and preps it for oiling.
- 2. Shake oil container well before and during use.
- 3. Apply approx. 3 ounces per 40-50 sq.ft. on to the floor and polish the oil by hand (use a white 3M Scotch Brite pad) or with a floor buffer and white floor pad.
- 4. WOCA Diamond Active Maintenance Oil must be polished into the wood. Continue polishing until the wood appears saturated and the surface looks uniform.
- 5. Polish off all excess oil from floor using cotton terry cloths either by hand or attached under the floor machine white pad before proceeding with the next section of floor to be finished. Hand wipe all edges and corners. The floor should not appear wet and no excess oil should be left on the surface.
- 6. When using a floor machine the oil will be pre-hardened after approx. 4 hours and may be cautiously taken into use. Manually polished floors can be used after 24 hours.
- 7. Do not expose floor or woodwork to water during the hardening time of 24 hours.
- 8. After 48 hours the floor may be treated with WOCA Natural Soap to provide additional protection.

Tip: For fastest drying time, leave windows slightly open to ensure a steady flow of fresh oxygen.

Packaging: Natural & White – 2.5 liter containers

Coverage Rate: 1075-1350 per 2.5 liter can

Warning! Rags, pads or waste soaked with WOCA oil may self-ignite if improperly discarded. Immediately after use, place all rags and waste in a sealed, water filled bucket for proper disposal.