



Anderson Excalibur Knob Instructions

Fig.1



Your new Anderson knobs will replace stock knobs on the Minelab Excalibur. They are larger and also have a pointer.

Fig. 2



To remove the stock knobs you must remove the yellow cap with a small flat screwdriver to expose the nut.

Fig. 3



Loosen the 1/4" nut and slide off the old knob. Make sure you clean any sand or dirt from the shaft before installing the new knobs.

Fig. 4



Make sure the pointers on the knobs align with the proper location on the detector. Use a small standard screwdriver to tighten the set-screws.

Note: do not over tighten the set-screws as this may damage the knobs or shafts.

Anderson Detector Shafts
550 Murdock Ave
Fort Erie, ON, L2A 1S4
Canada

1-800-967-1909

www.andersondetectorshafts.com