

## **CLEAR - CRYO**

FACE SHIELD FOR CRYOGENIC PROTECTION

**CE 0068**

CAT. 3 EN166, EN170



CLEAR - CRYO is a face shield designed to protect the face, the front of the head and neck from splashes, drops, sprays etc. in operations that involve the use of liquid nitrogen.

Protects against impact and UV rays and can be used for prolonged use because it does not create distortions and visual fatigue. No color distortion.

Made with specially designed composite materials for this application. Successfully tested by prolonged contact with liquid nitrogen (RDP 0913/2015 issued by Istituto di Ricerche e Collaudi M. Masini to the producer Univet Srl). The face shield must bear the following marking:



Item of 3<sup>rd</sup> category CE Certified

Personal Protective Equipment – Face Shield

Distributed by Kora Srl and produced by Univet Srl.

**Warning!** Persons handling cryogenic gases must be familiar with the risks that they involve, and should be adequately trained to handle security operations. Must also be established emergency procedures and adequate training of all functioning equipment. The cryogenic gas should never be handled without proper protective equipment.

### Features

face shield for protection against splashes of liquid gases composed of:

- Ergonomic half-shell
- Head sweat band
- 90° tilting head band adjustment with Polycarbonate Screen.
- Development: 395x240x2 mm
- Optical class 1

### Applications

Suitable for liquid nitrogen sprays to prevent burns in the event of gas leakage of the liquid (drops, splashes, etc.).

Code  
**CLEAR – CRYO**  
607.A7.00.00+605.04.00.00