

1. Turn off the power to your HVAC system
2. Unplug the P-MAC
3. Remove it from the filter slot
4. Open the two red latches
5. Remove the media
6. Discard the media in the trash
7. Replace it with genuine P-MAC media purchased from your authorized HVAC contractor.*
8. Align the media so that the LPD landing pad line up with the white disc on the P-MAC screen. This insures proper contact with the titanium power probe.
9. Make sure the media is centered, then close and the frame securing the red latches.
10. Plug the power cord back into the powerhead
11. Turn power back on and ensure that the red LED light is lit on the P-MAC.



The media should be changed every 3-4 months depending on your home environment.

**To protect the performance and integrity of the P-MAC the media is not sold retail or online. Online clone media will not have the patented carbon grid to conduct the electricity from the powerhead probe and low pressure drop dielectric fiberglass for a uniform charge to the P-MAC. Using other than genuine P-MAC media will void the Lifetime Warranty and may affect the performance of the P-MAC or cause damage and challenges with your HVAC system!*