

1. Since we produce full shell custom in-ear monitors a full impression is required for each ear, which includes the full helix, crus of the helix, tragus and antitragus. Cord exits above tragus so leave a little bit of extra material in this area. Ear impression also must be taken past the **SECOND BEND** of the ear canal. (Please check for inflammation or excess ear wax)

2. We require silicone ear impression material that's medium to high viscosity.
(We do not accept powder and liquid material nor Westone X-ACT red silicone material)

3. To achieve a better seal in the final product we require an **OPEN MOUTH** impression using a 1"-2" bite block, which will help reduce jaw movement during the curing process.

Customer Only: Once you have received your ear impressions please mail them to our office at:

InEarz Audio
170 N Cypress Way
Casselberry, FL 32707



(These are examples of acceptable ear impressions)

We will NOT accept pre trimmed ear impressions and have the right to reject impressions we do not see fit.

ATTENTION ALL AUDIOLOGISTS!

Would you like us to refer customers to you?
Fill out the information to the right or email Matt@inearz.com to be added to our database of recommended audiologists & hearing specialists.

Thank you!

Name: _____

Company: _____

Phone: _____

Address: _____

Website: _____