



INSTRUCTIONS

For use for depilatory wax

- Connect the removable power cord to the heater and plug into the mains supply.
- Fill the chamber halfway with Bombshell hard wax. Refill as the wax melts and as needed.
- Switch the heater on and move the temperature clockwise to the setting required to melt the wax. The thermostat light will illuminate until the correct temperature is reached.
- The red thermostat light will switch on and off automatically to maintain the temperature for as long as the setting remains the same.
- To melt the wax quickly, turn the dial to 10.
- After 40 minutes turn the dial to between 6 and 7 to stabilize the wax consistency.
- The temperature regulator can be moved clockwise to increase the temperature or counter-clockwise to reduce the temperature.
- **CLEANING:** USE APPROVED BOMBSHELL WAX CLEANER, 'KISS IT GOODBYE'

CAUTION

- Switch the heater on at least 40 minutes before treatment commence.
- Wax will be hot so please exercise caution to prevent burns.

WARNING

- Test wax consistency and temperature before use.
- Please follow wax manufacture instructions for application procedure.
- Never keep the heater switched on where there is no wax in the chamber.
- Ensure the electrical mains supply and power corresponds to the rating of the appliance. It is imperative to ensure that the supply socket is properly earthed. Please make sure to use only the power cord supplied with this product.
- The manufacturer accepts no liability for any damage to persons or property, whether due to operational misuse or failure to respect the above safeguards and warnings.

CONTENT

- 3.38oz wax heater
- Heater lid
- Removable power lead
- Product number: 930572