Bed Safety Wall & Divider Instructions

1. Once off install of Hardware



This document illustrates how to install the CaravanMods bed safety wall and divider available for purchase at www.CaravanMods.com.au/BedWallKit

1. Remove the existing bed rail - this is typically held in place with 4 screws



2. From the existing bed rail you need to remove the black buckles and add them to the new supplied front safety wall





- 3. Drill two 5mm screw holes in each of the sail tracks provided. These two holes should be about 50mm in from each end.
- 4. Secure the two sail tracks into the bed base as pictured, symmetrical about the centre, and approximately 50mm from the left/right side of the bed.



Bed Safety Wall & Divider Instructions

2. Install of Safety Wall and Divider



- 1. Lay the middle divider on top of the bed and pass the webbing strap under the middle of the mattress.
- 2. Thread the hockey stick through the top pocket on the divider wall.
- 3. Connect the webbing strap to the webbing buckle to secure the divider wall in the middle of the mattress.



- 4. Extend the supplied aluminium pole and thread it into the top pocket of the front safety wall.
- 5. Thread the bottom edge of the front safety wall into the sail track.



6.Connect the buckles on the safety wall to the existing buckles above the bed on the left and right.

Note: The weight of the safety wall should be carried by the 2 x webbing buckle straps.

NOT the middle tie attached to the hockey stick.

