

## Air Link Adapter

## Instruction Manual

Thank you for purchasing "Air Link Adapter".

By using this product, it's possible wireless two-way communication between XARVIS and TAOII.

Please check the direction of the connector first, and connect this product and XARVIS and brain unit (OP-15012 or TAO II all in one package accessories) correctly as shown below.



At this time, please be sure to switch the setting mode of XARIVS (XARVIS Owner's Manual P.10) to program card mode.

If the communication confirmation lamp of the brain unit (see the lower line of TAO II Instruction Manual P.2) blinks when turning on the XARVIS power supply, it is connected correctly.

Continued pairing TAO II and brain unit (TAO II Instruction Manual P.6) If you can prepare for wireless bi-directional communication.

Please refer to the instruction manual of TAO II, please use various functions such as wireless setting change and data log.

For product inquiries -

## ACUVANCE CORPORATION Technical Service Dept.

7F, Shin-Osaka Marubiru Annex, 1-18-22, Higashinakajima, Higashiyodogawa-ku, Osaka, 533-0033, Japan. www.acuvance.co.jp