

JACOB JENSEN 806



1. Use of the chronograph:

Press button “A” to start the chronograph.

To stop, press button “A” again.

By pressing button “B” the chronograph will reset.

Split time scan be measured by pressing button “B” while the chronograph is running. The split time can then be read, when button “B” is pressed again the chronograph will return to the total lapsed time.

2. Setting the timers to zero:

By pulling out the crown completely, button “A” can be used to correct the seconds counter.

Button “B” will correct the 1/10th seconds counter.

By pulling out the crown one step, button “B” can be used to correct the minutes counter. Turning the crown will change the date.

3. Hands and counters:

Upper left : the minutes counter
Upper right : the 1/10th seconds counter
Bottom : the seconds hand
Centre : the seconds counter