

TEGOSOFT[®] LSE 65 K Soft

Hydrophilic Emollients

•	Blend of sucrose esters with fatty acids from
	coconut oil

- Provides a pleasant re-fatting effect
- Increases foam density and creaminess
- Increases the viscosity in common surfactant combinations
- Vegetable source
- Preservative free
- PEG-free
- Conforms with the eco-label criteria for shampoos and body washes

Personal Care

INCI name (CTFA name)

Sucrose Cocoate

Chemical and physical properties (not part of specifications)				
Form	paste			
Colour	light yellow			

Properties

TEGOSOFT[®] LSE 65 K Soft is a blend of sucrose esters with fatty acid esters from coconut oil produced from natural, renewable sources: sucrose and vegetable fat. It is solvent-free, readily biodegradable (aerobic & anaerobic) and has low aquatic toxicity. It conforms to eco-label criteria for shampoos and body washes.

TEGOSOFT[®] LSE 65 K Soft is a re-fatting agent designed for use in skin and hair cleansing formulations providing the following advantages:

- very mild to skin and eyes
- improves skin feel
 - during washing process
 - after feel (softness and smoothness)

- improves foam creaminess and stability
- thickening properties in common surfactant combinations
- suitable for clear products
- foam stabilizing

Improvement of foam quality and skin feel

Figure 1 shows the results of a sensory hand wash test in comparison to the market standard PEG-7 Glyceryl Cocoate.

TEGOSOFT[®] LSE 65 K Soft outperforms the market standard in the essential properties foam creaminess and skin feel.



Figure 1: results of sensory hand wash tests 9 % SLES / 3 % CAPB; 7 Panelists

Thickening property

Figure 2 shows an increasing viscosity effect due to the addition of TEGOSOFT® LSE 65 K Soft into a surfactant base, comprising of 11.25 % SLES, 3.75 % CAPB and 0.7 % NaCl in comparison to the market standard, PEG-7 Glyceryl Cocoate.

Low concentrations of TEGOSOFT $^{\circ}$ LSE 65 K Soft appreciably increase viscosity while PEG-7 Glyceryl Cocoate does not affect viscosity.

Viscosity [mPas]



Figure 2: Thickening effect of TEGOSOFT* LSE 65 K 9 % SLES / 3 % CAPB / 0.8 % NaCl

Application

TEGOSOFT[•] LSE 65 K Soft can be added to hair and body cleansing formulations and is suitable for clear products. It is especially recommended for use in very mild cleansing products. It can also be used as moisturizers in skin care products (creams and lotions).

Preparation

With regard to the chemical characteristics of the products we recommend that TEGOSOFT^{*} LSE 65 K Soft is heated during processing to approx. 40 °C and thoroughly mixed before processing.

It should be added directly to the concentrated primary surfactant.

Storage

At higher temperatures (> 25 °C) TEGOSOFT° LSE 65 K Soft might separate into two phases of different viscosities. If this occurs the sample should be heated to 40 °C and mixed thoroughly before use. This does not impact product performance.

Hints for analytical measurements / non-usage of complete package

If the total container of TEGOSOFT° LSE 65 K Soft is not used (mainly for analytical purpose), we recommend the following mixing procedure in order to achieve similar analytical results as compared to the certificate of analysis:

- Temper the drum 10 15 hours at 45 - 50 °C.
- In order to avoid water loss, open the pail without removing the lid completely.
- Mix for 2 hours with a simple cement mixing blade (see figure 3) at
 300 500 rpm.
- Move the blade up and down during the mixing procedure.
- Take the sample directly after mixing.

Note: This procedure reduces water loss by less than 0.3 %.



Figure 3: Mixing equipment (cement mixer, I = 14 cm) to homogenize TEGOSOFT[•] LSE 65 K soft (mainly before analytical tests)

Recommended usage concentration

for cleansing formulations	0.7 - 4.0 %
for emulsions	3.0 - 5.0 %

Packaging

400 kg pallet (16 x 25 kg can)

Hazardous goods classification

Information concerning

- classification and labelling according to regulations for transport and for dangerous substances
- protective measures for storage and handling
- measures in case of accidents and fires
 toxicity and ecological effects

is provided in our material safety data sheets.

Guide Line Formulations

Shower Gel for Sensitive Skin KA 05272		
Sodium Laureth Sulfate (28 %)	15.0 %	
TEGOSOFT® GC (PEG-7 Glyceryl Cocoate)	1.0 %	
TEGOSOFT [®] LSE 65 K Soft	1.5 %	
REWOPOL® SB CS 50 B (Disodium Laurylcitrate Sulfosuccinate; Sodium Laureth Sulfate)	7.5 %	
Water	61.5 %	
TEGO® Betain F 50 (Cocamidopropyl Betaine)	9.0 %	
TEGO [®] Betain 810 (Capryl/Capramidopropyl Betaine)	4.0 %	
ANTIL® 200 (PEG-200 Hydrogenated Glyceryl Palmate; PEG-7 Glyceryl Cocoate)	2.5 %	
Preservative, Perfume	q.s.	
Preparation: Mix the ingredients in the given order. Adjust the pH value with Citric Acid to 6.0.		

Shower Bath - PEG and Sulfate-free			
FM 11124			
REWOTERIC [®] AM C	15.0 %		
(Sodium Cocoamphoacetate)			
REWOPOL [®] SB F 12 P	3.8 %		
(Disodium Lauryl Sulfosuccinate)			
Water	61.7 %		
TEGOSOFT [®] LSE 65 K Soft	2.5 %		
ANTIL [®] HS 60	4.0 %		
(Cocamidopropyl Betaine, Glyceryl			
Laurate)			
TEGO® Betain F 50	13.0 %		
(Cocamidopropyl Betaine)			
Preservative, Perfume	q.s.		
Preparation:			
Mix the ingredients in the given order at			
approximately 30 °C. Adjust the pH value with			
Citric Acid to 5.5. Finally add preservatives as			
required.			

Clear Baby Bubble Bath, Sulfate-free		
ST-BB 1		
TEGOSOFT [®] GC	2.0 %	
(PEG-7 Glyceryl Cocoate)		
Bisabolol	0.1 %	
TEGO® Betain F 50	40.0 %	
(Cocamidopropyl Betaine)		
REWOPOL [®] SB FA 30 B	15.0 %	
(Disodium Laureth Sulfosuccinate)		
TEGOSOFT [®] LSE 65 K Soft	2.0 %	
Panthenol	0.2 %	
Water	36.9 %	
ANTIL [®] 171	3.0 %	
(PEG-18 Glyceryl Oleate/Cocoate)		
REWOMID [®] SPA	0.8 %	
(Isostearamide MIPA)		
Preservative, Perfume	q.s.	
Preparation:		

Mix the ingredients in the given order and stir while slightly warming up. Adjust the pH value at room temperature with Citric Acid to 5.5 and the desired viscosity with NaCl. Finally add preservatives as required.

2 in1 Shampoo for Kids		
VK 54/4		
Sodium Laureth Sulfate (28 %)	20.0 %	
REWOPOL [®] SB FA 30 B	6.0 %	
(Disodium Laureth Sulfosuccinate)		
TEGOSOFT [®] LSE 65 K Soft	2.5 %	
ABIL® Quat 3272	2.0 %	
(Quaternium-80)		
Water	54.9 %	
Polyquaternium-10	0.1 %	
(Polymer JR 400, Amerchol)		
TEGO® Betain F 50	7.0 %	
(Cocamidopropyl Betaine)		
VARISOFT [®] PATC	2.5 %	
(Palmitamidopropyltrimonium Chloride)		
REWODERM [®] LI S 80	3.0 %	
(PEG-200 Hydrogenated Glyceryl		
Palmate; PEG-7 Glyceryl Cocoate)		
TEGO [®] Pearl N 100	2.0 %	
(Glycol Distearate; Steareth-4)		
Preservative, Perfume	q.s.	
Preparation:		
Stir the PQ-10 into the water and let it swell. Mix		
the ingredients in the given order.		

G 11/09

This information and all further technical advice are based on Evonik Goldschmidt GmbH's present knowledge and experience. However, Evonik Goldschmidt GmbH assumes no liability for providing such information and advice including the extent to which such information and advice may relate to existing third party intellectual property rights, especially patent rights. In particular, Evonik Goldschmidt GmbH disclaims all CONDITIONS AND WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY. EVONIK GOLDSCHMIDT GMBH SHALL NOT BE RESPONSIBLE FOR CONSEQUENTIAL, INDIRECT OR INCIDENTAL DAMAGES (INCLUDING LOSS OF PROFITS) OF ANY KIND. Evonik Goldschmidt GmbH reserves the right to make any changes according to technological progress or further developments. It is the customer's responsibility and obligation to carefully inspect and test any incoming goods. Performance of the product(s) described herein should be verified by testing and carried out only by qualified experts. It is the sole responsibility of the customer to carry out and arrange for any such testing. Reference to trade names used by other companies is neither a recommendation, nor an endorsement of any product and does not imply that similar products could not be used. (Status: February, 2008)

Evonik Goldschmidt GmbH Goldschmidtstrasse 100 45127 ESSEN, GERMANY P.O. Box 45116 Essen TELEFON +49 201 173-2854 TELEFAX +49 201 173-1828 personal-care@evonik.com www.evonik.com/personal-care

