

301 Conover Station SE; Conover, NC 28613

NatuVerex TM Copper

C/o Fine Cotton Factory Inc.

110 Belfield Road

Etobicoke, Ontario, Canada, M9W1G1

REFERENCE: TS 161026

Style: SY2158 Color: Black

Description: DL20343

Received Date: September 25, 2020 Completed Date: October 29, 2020 Revision Date: November 5, 2020 Revised to add Description

Sample Type: Knitted Fabric /Mask

Sample Form: Yardage Size: N/A

TEST RESULTS:

AATCC TM100-2019

• Test Method for Antimicrobial Finishes on Textile Materials: Assesment of

This test is accredited under the laboratory's ISO/IEC 17025 accreditation issued by the ANSI-ASQ National Accreditation Board. Refer to certificate and scope of accreditation L2238

Testing Results:	Results: cfu/sample		
tested after 100x wash/dry	Zero Contact Time	24hr Contact Time	Percent Reduction
Staphylococcus aureus ATCC 6538	3.70E+05	1.00E+03	99.73%
 Klebsiella pneumoniae ATCC 4352 	2.90E+05	1.00E+03	99.66%

Calculate % reduction to formula 10.3: 100 (C-A)/C = R (Eq.2)

Testing Information:

Table I - Standard Washing Machine Parameters: top loading machines with powdered detergent only

AATCC Laboratory Procedure 1 -2018, "Home Laundering: Machine Washing"

Testing Information:

Home Laundered 100 times using AATCC Laboratory Procedure 1-2018

Table I - Standard Washing Machine Parameters

Laundry Test Conditions: load size = 1.8kg (4lbs.). Launder Right Side Out

Top Loading Machine Wash; Normal Cycle (III)Warm: 41+/-3C (105+/-5F)

using 66±1g 1993 AATCC Standard Reference Detergent WOB

(A) Tumble Dry Table V - Standard Drying Conditions

Type 3: 50% cotton/ 50% polyester bleached plain weave

Table VII - Ballast Parameters



301 Conover Station SE; Conover, NC 28613

Testing Information:

• Staphylococcus aureus ATCC 6538

Klebsiella pneumoniae ATCC 4352

• Growth media: Tryptic Soy Broth

Sample size: 1 gramSterilization: none

Neutralizing Solution: 100ml Letheen Broth w. Tween

• Target inoc. Level: (1.0-3.0) x 10⁵ CFU/ml

• Suspension Medium: 5% (1:20) Nutrient broth w. 0.05% Triton X-100

• Inoculum size: 1.0ml +/- 0.1ml

Contact time: 24 h
 Temperature: 37 +/- 2° C
 Samples are tested as submitted

• Samples are prepared and enumerated using automatic equipment; Tempo, BioMerieux.

• Cultures stored at 5° +/-2°C.

Report prepared:

Chen Lettuhun

Cheryl Nettesheim Antimicrobial Testing Lab

MSC – Testing Lab (828) 327-7000 ext. 4512 <u>cnettesheim@manufacturingsolutionscenter.org</u> <u>www.manufacturingsolutionscenter.org</u>

The test results are based on the submitted sample(s) only. MSC/HTC's liability shall not exceed the fees paid for the testing reflected on this report. It is the customer's responsibility to ensure that they comply with all U.S. federal, state/ local laws & regulations. These tests are not to be used for marketing purposes without the express written consent of the Director of the Manufacturing Solutions Center at Catawba Valley Community College. The test report shall not be reproduced except in full, without written approval from MSC/HTC. All results will be kept confidential.