

C.C.Rider Seat

Installation Instruction

Rider Backrest Mounting Hardware Kit

WARNING

After installing the seat, pull upward on the seat to be sure it is locked in position. While riding, a loose seat can shift causing loss of control, which could result in death or serious injury.

INSTALLATION

1. Remove the seat.
2. Remove the Electronic Control Module (ECM) caddy/battery cover by removing two screws.
3. Remove plastic protective cap and locknut from the stud. Leave the small plastic washer in place or the stud plate will fall out. With the backrest mounting bracket tab facing forward, attach the backrest mounting bracket (3) to the stud plate with stock locknuts from the stud plate.
4. Tighten the locknuts.
5. Attach the front mounting bracket (6) to the frame cross member using two flange screws (8) and flange nuts (7). Tighten.
6. Attach the bracket support (4) to the front mounting bracket (6) with screw (8) and nut (7). Install screw (5) and nut (9) to bracket support and backrest tab. Tighten.
7. Install the ECM caddy/battery cover using two screws previously removed. Tighten. Hold slit between rider and passenger seat open. On rider backrest, compress backrest rods and spring. Insert rods into backrest mounting the bracket.

