

Assembly instructions for 0909** Wellington Hydraulic Bed**

There will be 2 boxes for this bed. The smaller box has the bed middle frame and the cover for the Hydraulic.

1. Remove all the parts and take off all the packaging.
2. Screw the adjustable legs into the bottom of the base.
3. Position the hydraulic into the base section making sure the poles for the stepper are facing the long ends of the base (these are 2 silver studs with holes in them). The stepper needs to be facing the side of the bed.
4. Connect the 4 nuts to the bolts on the bottom of the hydraulic, make sure you include the washers first then fully tighten.
5. With the base on the ground slip the Chrome cover over the hydraulic and insert the screw into the top to hold it in place.
6. Insert the stepper into the 2 chrome poles in the hydraulic and tighten the grub screws in the sides of the poles using an allen key.
7. Next lay the 3 cushion sections face down, remove the screws from the backs of the cushion pieces and connect the hinges. Start all the screws before fully tightening.
8. Now remove the other 4 screws from the back of the middle section and connect the middle frame section that came from the smaller box. Again, start all the screws first before you tighten them.
9. Have someone assist you and flip the top section onto the top of the hydraulic and secure with the nut in the top of the hydraulic.
10. The last thing to do is to put the 2 chrome brackets into either end of the middle frame section that hold the back and leg sections and connect the springs. Be careful not to over stretch the spring as it will not work as effectively as it should.