
Accessories Inch/Metric

Fittings, Valves & Tubing Catalog



How to make a Push-Fit connection





To connect

Keep product clean until ready to use. Always pressure test once installed.



Step 1

Cut the tube square and remove any burrs or score marks. We recommend using a tube insert for soft or thin-walled plastic tubing.



Step 2

Push the tube into the fitting and up to the tube stop.



Step 3

Pull on the tube to check that it is secure. Test the system before use.

To disconnect



Step 1

Make sure that the system is depressurized, then push the collet square against the fitting. With the collet held in this position, the tube can be removed.





JJ DOWNS INDUSTRIAL PLASTICS INC.

416.236.1884

Toronto, ON

JJDOWNS.COM

Fluid Systems Accessories Inch/Metric



Collet Cover



The slip-on Collet Cover shown in the illustration prevents accidental removal or tampering with tubing. Tubing can be inserted with the Collet Cover already attached to the fittings or the cover can slide into position afterwards. The cover is easily removed when required and comes in a variety of colors for color coding.

The following suffixes indicate colors available:

E = Black Y = Yellow B = Blue R = Red S = Gray G = Green

Collet Cover - Inch Size

Part Number	Tube OD	Bag Qty	Box Qty
PM1904S	5/32"	10	1000
PI1906S	3/16"	10	1000
PI1908S	1/4"	10	1000
PM1908S	5/16"	10	1000
PI1912S	3/8"	10	500
PI1916S	1/2"	10	500

Please indicate required collet color by suffix, or gray will be supplied.

Collet Cover - Metric Size

Part Number	Tube OD	Bag Qty	Box Qty
PM1904E	4mm	10	1000
PM1905E	5mm	10	1000
PM1906E	6mm	10	1000
PM1908E	8mm	10	1000
PM1910E	10mm	10	500
PM1912E	12mm	10	500
PM1915E	15mm	100	400
PM1918E	18mm	10	200
PM1922E	22mm	50	200

15mm to 22mm sizes are only available in black (standard), white, red or blue. Please indicate required collet color by suffix, or black will be supplied.

Locking Clip



Part Number	Tube OD	Bag Qty	Box Qty
PIC1808R	1/4"	100	5000
PIC1812R	3/8"	100	1000
PIC1816R	1/2"	100	2000
PMC1808R	8mm	100	8000



Secures collet in locked position to prevent accidental disconection of tube. Locking Clips should be connected only after tubing is fully inserted to prevent scraping of the tube. Locking Clips are not designed for use with our Stem Adapters in Swivel Combinations.

Flow Bend Clip



Part Number	Tube OD	Bag Qty	Box Qty
PM2608S	5/16" (8mm)	10	300
PM2610S	3/8" (10mm)	10	200

Designed to support tube and eliminate kinking





JJ DOWNS INDUSTRIAL PLASTICS INC.

416.236.1884

Toronto, ON

JJDOWNS.COM

Fluid Systems **Accessories** Inch/Metric





Part Number	Size OD	Bag Qty	Box Qty
SVMC-06	1/4"	200	200
SVMC-10	3/8"	100	100

out ing clip is designed to give a very firm grip. ting action is needed to remove the valve. The in be used with either acetal shut-off valve. used with the short handle version, valves can



Part Number	Tube ID	Tube OD	Bag Qty	Box Qty
TSI250S	1/4"	5/16"	10	1000
TSI312S	5/16"	3/8"	100	2500
TSI375S	3/8"	1/2"	10	500
TSM10N	-	10mm	50	1000
TSM15N	-	15mm	50	500
TSM22N	-	22mm	25	250
TSM28N	-	28mm	10	150



TSNIP 50 Blades Only 300

Suitable for up to 12mm tube or 1/2" tube





