


RESPIRATORY PROTECTION PRODUCTS





Disclaimer: Not all items that appear in this catalogue are available ex stock. Some items may need to be manufactured to your specifications upon placement of order. Please refer to your Sperian price list for pricing and availablility. Products are subject to change without notice.



Global leaders in respiratory protection

Sperian Protection, now part of Honeywell, lead the way in the design and manufacture of respiratory protection products



Important safety considerations

Harmful substances may be in the form of dusts, mists, fumes, gases, vapours, or combinations of these. Many important factors need to be considered before choosing the most suitable respirator.

- Ensure there is sufficient oxygen present. Please refer to standards or regulations for concentration level details.
- Determine the physical and chemical properties of the contaminant, which can be ascertained from the most current Material Safety Data Sheet (MSDS) for the substance concerned, or from other appropriate reference material.
- > Determine the concentration of the contaminant in your workplace environment. Lower capacity respirators are only designed to work in

concentrations up to a certain level and you may need to use a different respirator depending on the concentration present.

- > Assess the working conditions and respirator protection factor. P1 respirators are for protection against mechanically generated particulates. P2 respirators are for protection against mechanically and thermally-generated particulates. Class P3 respirators are intended for use against all particulates including highly toxic materials.
- > Other filter types or types of respirators are to be considered for protection from gases and vapours. The type of contaminant and concentration will determine which filter/respirator is required. You need to know the workplace exposure standard for the contaminant, e.g. 'Worksafe Australia Exposure Standards for atmospheric contaminants

in the occupational environment' or 'OSH Workplace Exposure Standards and Biological Exposure Indices for New Zealand'.

- > Select the right respirator / filter for the task, and ensure a proper face fit. Where concentrations permit, disposable respirators are a good solution and are more likely to be worn because of their greater comfort. If you use replaceable filter respirators, you must implement a respirator maintenance program in accordance with AS/NZS 1716:2003.
- Conduct training in the need for and correct use of respirators. Product training and motivation of users of personal protective equipment is vital to ensure the user's complete understanding of a respiratory protection program.

SPERIAN

Worker comfort and ease of use are our priority. That's why our products are designed to be worn day-in, day-out.

Sperian respiratory solutions include disposable respirators, re-useable


respirators, SCBA, and gas detection products all manufactured to protect workers in a variety of industries including: oil and gas, construction, mining, disaster and emergency services, fire fighting, chemicals and paint, science, and health.

If you have any further questions, telephone Sperian Customer Service on 1300 139 166 or visit www.sperian.com.

Making the best choice

When selecting a respirator, consider the chemical and physical properties of the contaminant, the toxicity and concentration of the hazardous material, and the amount of oxygen present.

Choosing the right respirator involves four main steps:



Key Terms

SCBA	Self Contained Breathing Apparatus		Mechanically generated solid particle suspended in air. (flour	Fume	Thermally generated solid particle which vaporises then	
PP	Positive Pressure	<u> </u>	grain, sanding, quarrying etc)		solidifies and drops down.	
IDLH	Immediately Dangerous to Life and Health	Mist	Mechanically generated liquid particle suspended in air	Gas/Vapour	i.e. welding, furnacing etc. Neither solid nor liquid at	
PAPR	Powered Air Purifying Respirator			-	room temperature	

Standards and safety




Sperian are committed to quality and safety.

Each and every product is subject to a strict testing and quality assurance program in accordance with the guidelines of the Australian and New Zealand Standard AS/NZS 1716:2003.

Sperian respiratory protective devices meet the stringent requirements of this standard. Please refer to individual product approval details throughout the catalogue.

For selection, use and maintenance of respiratory devices refer to AS/NZS 1715:2009.

This standard sets out principles of respiratory protection and makes recommendations for the selection, use and maintenance of respirators.





P1 Disposable Respirators

- > 2100 Nuisance Dust Mask
- > 5185 P1 Dust Respirator
- > 5110 P1 Premium Dust Respirator
- > 5111 P1 Premium Dust Respirator with Exhalation Valve
- > 4110 P1 Flat fold Style Dust Respirator
- > 4111 P1 Flat fold Style Dust Respirator with Exhalation Valve
- > 5140 P1 Premium Nuisance Odour Respirator
- > 5141 P1 Premium Nuisance Odour Respirator with Exhalation Valve



Page 10

P2 Disposable Respirators

- > 5210 P2 Premium Respirator
- > 5211 P2 Premium Respirator with Exhalation Valve
- > 4210 P2 Flat fold Style Respirator with Willtech® Seal
- > 4211 P2 Flat fold Style Respirator with Willtech® Seal and Exhalation Valve
- > 5251 P2 Premium Respirator with Willtech® Polo Seal and Exhalation Valve
- > 5261 P2 Premium Respirator with Willtech® Boomerang Seal and Exhalation Valve



Page 14

Superone Disposable Respirators

- > W3203 Superone P1 Respirator
- > W3204 Superone P1 Respirator with Exhalation Valve
- > W3205 Superone P2 Respirator

> W3206 Superone P2 Respirator with Exhalation Valve



Page 16

Disposable respirators are designed to be discarded after use. There are no spare parts and no maintenance is required.

Sperian disposable respirators protect the wearer against solid, water based and liquid aerosols. There are two classes of particulate filters suitable for protection against finely divided solid or liquid particles, or both.

- P1) For use against mechanically generated particulates
- P2) For use against mechanically and thermally generated particulates

Never use a disposable respirator when:

- > They are modified or damaged
- > Contaminant concentration is Immediately Dangerous to Life and Health (IDLH)
- Contaminant is over 10 x TLV (Threshold Limit Value)
- > Oxygen concentration is less than 19.5%
- > Spray painting
- > Fire fighting

Features of the 4000 & 5000 Series

The Sperian 4000 and 5000 Series include innovative features and design, providing great protection at a competitive price.



1 Fully featured respirator design

Increased inner volume provides a non-oppressive feeling on the face, and ease of movement for speech. The respirator can be easily molded to suit each individual's facial contours while ensuring a maximum respirator service life thanks to hypoallergenic and humidity resistant properties.

2 Exhalation valve

An innovative design exclusive to Sperian provides minimal breathing resistance while the valve membrane is protected from damage. Faster evacuation of moist exhaled air means easier breathing and comfort, encouraging longer wear time especially in hot or humid workplaces.

3 Colour coding for quick identification

The pre-formed colour coded nose bridge gives at-a-glance protection identification.

- P1 respirator
- P2 respirator
- Nuisance level organic vapours
- Nuisance level acid gases

4 Ultra-soft seal

The triple layer Willtech® Boomerang and Polo seals provide maximum protection and comfort by resting softly against the wearers skin to improve the air seal around the face and/or nose while absorbing perspiration.

Sperian disposable respirators provide a flexible strip nose seal with Willtech® options providing additional protection and comfort.

Strip Nose Seal - Standard protection

Boomerang Nose Seal - Standard protection with added wearer comfort

Polo Face Seal - High level protection with increased wearer comfort

5 Quality materials protect you and the environment

Flame retardant outer shell for greater safety. Masks with charcoal layers provide relief from nuisance levels of organic vapours and acid gases. The respirator strap staples do not penetrate the filter medium, ensuring the integrity of the filter. Latex (a common allergenic), PVC and Silicone are not used in respirator manufacture.

Versatile flat-fold style

Individually wrapped, flat-fold styles are available (4000 Series), for convenient and hygienic storage in a pocket. A fold-and-hold mechanism prevents contamination between uses and offers easy storage. The integrated chin piece design improves fit and allows better speaking movement. The sliding latex free elastic ring head band gives greater adjustment and is highly resistant to breakage. Flat fold disposable respirators have no staples, making them ideal for use in the food industry.

Dolomite tested

All Sperian 4000 and 5000 series respirators have undergone optional dolomite testing, clearly demonstrating resistance to clogging. This ensures better breathing comfort and less worker fatigue.



Fitting instructions & Fit testing

To provide optimum protection against air hazards your respirator must be fitted correctly. Follow the instructions below to achieve the best result.

Fitting Folding Respirators

- 1 Open Flat Fold Respirator by pushing slightly on both sides.
- Pre-form the nose-bridge.
- Place the respirator under the chin with chin-flap fully open. Holding the respirator against the face, place the lower headstrap around the neck below the ears and the top head-strap above the ears.
- This is how the respirator should look when correctly donned.
- 5 Mold nose area to the shape of the face by pinching the nose-bridge from the top to the bottom. Make sure that the chin-flap is open and secure around the chin area.
- Fit check: Fit check the face seal as follows: Place both hands over the respirator. If the respirator is not fitted with an exhalation valve, exhale sharply; if the respirator is fitted with an exhalation valve, inhale sharply. If leaks around the edge are detected, re-adjust the headstraps and/or the nose-piece. Repeat the procedure until a satisfactory face fit has been achieved. Important: If you feel that the headbands are too loose, you can

increase the tension by tying a small knot



in the headband.











Fitting Cup Respirators

- 1 Hold the respirator cup in your hand, allowing head-straps to hang freely.
- 2 Hold respirator under the chin with the nose-piece facing outwards. Place the respirator on your face ensuring that the lower part of the respirator is positioned under your chin. Pull the lower headstrap over your head and place it around the neck below the ears. Still holding the respirator against the face with one hand, pull the top head-strap over your head and position it above the ears, around the crown of the head.
- Mold the nose area to face shape, running the finger tips of both hands from the top of the nose-piece down both sides while pressing inward. Always use both hands.
- 4 Fit check the face seal as follows: Place both hands over the respirator. If the respirator is not fitted with an exhalation valve, exhale sharply; if the respirator is fitted with an exhalation valve, inhale sharply. If leaks around the edge are detected, re-adjust the head-straps and/or the nosepiece. Repeat until a satisfactory face fit has been achieved.









Fit Testing

There are two types of facial fit tests -Qualitative and Quantitative.

Qualitative fit testing is a simple pass/fail test based upon the user's subjective assessment of the leakage, via the face seal region, of a test agent.

Quantitative fit testing uses equipment (usually a portacount machine) to measure the efficiency of a respirator in preventing materials in the atmosphere from entering a users breathing zone.

ASNZS 1715: 2009 states that a Program Administrator (Person who is made responsible for a companies respiratory protection program) must ensure that a suitable fit test is carried out for all respirator users.

Fit Testing should be conducted annually or whenever there is a change in the wearers facial characteristics (such as the wearer was to grow facial hair)

The Bitrex Fit Test Kit provides a fit testing option as per section 8.5.3.2 of ASNZS 1715:2009 (Saccharin Mist test), and is suitable for testing both disposable and re-usable respirators fitted with a particulate filter.

If testing a gas or vapour filter the filter should also be fitted with a particulate filter to prevent the wearer inhaling any mist during testing

1010051 BITREX FIT TEST KIT. INCLUDES HOOD, PUMPS AND TEST SOLUTIONS 1010052 BITREX SENSITIVITY SOLUTION PACK OF 6 1010053 BITREX FIT TEST SOLUTION PACK OF 6



P1 Disposable Respirators

Protecting against mechanically generated dusts and mists. Approved for 10 times the exposure standard of dusts produced by grinding and drilling.



2100 Non-industrial Nuisance Dust Mask

A lightweight hygiene mask which provides relief from large dust particles in low concentrations

- > For sweeping, dusting, and non-industrial applications
- > Nose bridge is easily molded to provide correct fit

2100 STANDARD SIZE



5185 P1 Cup-shape Dust Respirator

Economical cup-shape P1 protection respirator suggested for use with particulate aerosols free of oil

- Yellow nose bridge indicating P1 protection
- Nose bridge is easily molded to provide correct fit
- > Strip nose-seal
- Large inner volume provides ease of movement and optimised breathing comfort
- > Elastic straps are stapled outside the filter media to ensure the integrity of the filter media is maintained
- > Silicone, PVC and latex free
- > For grinding, sanding, sweeping, woodworking and dusty operations

1007691 STANDARD SIZE



5110 P1 Premium Cup-shape Dust Respirator

Premium cup-shape P1 protection respirator suggested for use with particulate aerosols free of oil

- > Willtech® boomerang nose-seal, providing maximum protection and comfort
- Yellow nose bridge indicating P1 protection
- Nose bridge is easily molded to provide correct fit
- Large inner volume provides ease of movement and optimised breathing comfort
- Elastic straps are stapled outside the filter media to ensure the integrity of the filter media is maintained
- > Silicone, PVC and latex free
- > For medical, grinding, polishing, sanding, woodworking, sweeping and dusty operations

1007693 STANDARD SIZE **1007694** X-LARGE



Protection against dusts, mists and fumes including*

- > Calcium Carbonate
- > Cement Dust
- > Sulphur
- > Glass-Wool
- > Coal
- > Kaolin > Cellulose
- > Flour
- > Ferrous Metals
- * This is not a full contaminants list. For a full list, contact Sperian customer service for a copy of the respiratory contaminant guide.



5111 P1 Premium Cup-shape **Dust Respirator with Exhalation Valve**

Full feature premium cup-shape P1 protection respirator suggested for use with particulate aerosols free of oil

- > High quality exhalation valve facilitates effortless breathing during periods of extended use and in hot and humid work environments
- > Willtech® boomerang nose-seal, providing maximum protection and comfort
- > Yellow nose bridge indicating P1 protection
- > Nose bridge is easily molded to provide correct fit
- > Large inner volume provides ease of movement and optimised breathing comfort
- > Elastic straps are stapled outside the filter media to ensure the integrity of the filter media is maintained
- > Silicone, PVC and latex free
- > Size XL available
- > For grinding, sanding, sweeping, dusty and hot operations

1007696 STANDARD SIZE **1007697** X-LARGE



P1 Disposable Respirators

Protecting against mechanically generated dusts and mists. Approved for 10 times the exposure standard of dusts produced by grinding and drilling.



4110 P1 Flatfold Style Dust Respirator

Individually packaged P1 protection flat fold respirator for convenient pocket storage

- > Willtech® boomerang nose-seal, providing maximum protection and comfort
- Yellow nose bridge indicating P1 protection
- Nose bridge is easily molded to provide correct fit
- Sliding elastic ring headband eliminates staples
- Large inner volume provides ease of movement and optimised breathing comfort
- > Silicone, PVC and latex free
- > Individually wrapped
- For medical, grinding, polishing, food handling, sanding, sweeping and dusty operations

1007716 STANDARD SIZE



4111 Flat fold Style Dust Respirator with Exhalation Valve

Individually packaged P1 flat fold respirator with exhalation valve for convenient pocket storage

- High quality exhalation valve facilitates effortless breathing during periods of extended use and in hot and humid work environments
- > Willtech® boomerang nose-seal, providing maximum protection and comfort
- Yellow nose bridge indicating P1 protection
- Nose bridge is easily molded to provide correct fit
- Sliding elastic ring headband eliminates staples
- Large inner volume provides ease of movement and optimised breathing comfort
- > Silicone, PVC and latex free
- > Individually wrapped
- For medical, grinding, polishing, food handling, sanding, sweeping and dusty/hot operations

1007717 STANDARD SIZE



5140 P1 Premium Cup-shape Nuisance Odour Respirator

Premium cup-shape P1 protection respirator with charcoal layer filter for nuisance levels of organic vapour odour relief

- > Willtech® boomerang nose-seal, providing maximum protection and comfort
- > Brown nose bridge indicating relief from nuisance levels of organic vapours
- Nose bridge is easily molded to provide correct fit
- Large inner volume provides ease of movement and optimised breathing comfort
- > Elastics stapled to the outside of the filtering area ensure filter media is not damaged
- > Silicone, PVC and latex free
- > Size XL available
- > For grinding, sanding, sweeping and dusty operations

1007705 STANDARD SIZE **1007706** X-LARGE



Protection against dusts, mists and fumes including*

- > Calcium Carbonate
- > Cement Dust
- > Sulphur
- > Glass-Wool
- > Coal
- > Clav
- Kaolin Cellulose
- > Cotton I
- > Flour
- > Ferrous Metals
- * This is not a full contaminants list. For a full list, contact Sperian customer service for a copy of the respiratory contaminant guide.



5141 P1 Premium Cup-shape Nuisance Odour Respirator with Exhalation Valve

Premium cup-shape P1 protection respirator with exhalation valve and charcoal filter for organic vapour nuisance odour relief

- > High quality exhalation valve facilitates effortless breathing during periods of extended use and in hot and humid work environments
- > Willtech® boomerang nose-seal, providing maximum protection and comfort
- > Brown nose bridge indicating relief from nuisance levels of organic vapours
- Nose bridge is easily molded to provide correct fit
- Large inner volume provides ease of movement and optimised breathing comfort
- > Elastic straps are stapled outside the filter media to ensure the integrity of the filter media is maintained
- > Silicone, PVC and latex free
- > Size XL available
- > For glass etching, grinding, sanding, dusty/hot operations

1007708 STANDARD SIZE **1007709** X-LARGE



P2 Disposable Respirators

For protection against mechanically and thermally generated dusts, mists and fumes. Approved for 10 times the exposure standard of dusts produced by grinding, drilling and certain applications of brazing, welding etc.



5210 P2 Premium Cup-shape Respirator

Economical cup-shape P2 protection respirator suggested for use with particulate aerosols free of oil

- > Willtech® boomerang nose-seal, providing maximum protection and comfort
- Green nose bridge indicatingP2 protection
- Nose bridge is easily molded to provide correct fit
- Large inner volume provides ease of movement and optimised breathing comfort
- > Elastic straps are stapled outside the filter media to ensure the integrity of the filter media is maintained
- > Silicone, PVC and latex free
- > Size XL available
- > For glass etching, welding, soldering, brazing, torch cutting, metal pouring, grinding, sanding, sweeping and dusty operations

1007699 STANDARD SIZE **1007700** X-LARGE



5211 P2 Premium Cup-shape Respirator with Exhalation Valve

Full feature premium cup-shape P2 protection respirator suggested for use with particulate aerosols free of oil

- High quality exhalation valve facilitates effortless breathing during periods of extended use and in hot and humid work environments
- > Willtech® boomerang nose-seal, providing maximum protection and comfort
- Green nose bridge indicatingP2 protection
- Nose bridge is easily molded to provide correct fit
- Large inner volume provides ease of movement and optimised breathing comfort
- > Elastic straps are stapled outside the filter media to ensure the integrity of the filter media is maintained
- > Silicone, PVC and latex free
- > Size XL available
- > For glass etching, welding, soldering, brazing, torch cutting, metal pouring, grinding, sanding, sweeping, dusty and hot operations

1007702 STANDARD SIZE **1007703** X-LARGE



4210 P2 Flat-fold Style Respirator with Willtech® Seal

Individually packaged P2 protection flat-fold respirator for convenient pocket storage

- > Willtech® boomerang nose-seal, providing maximum protection and comfort
- Sliding elastic ring headband eliminates staples
- Green nose bridge indicatingP2 protection
- Nose bridge is easily molded to provide correct fit
- Large inner volume provides ease of movement and optimised breathing comfort
- > Silicone, PVC and latex free
- Individually wrapped
- > For glass etching, welding, soldering, brazing, torch cutting, metal pouring, grinding, sanding, sweeping, dusty and hot operations

1007718 STANDARD SIZE



Protection against dusts, mists and fumes including*

- > Calcium Carbonate
- Sodium Silicate
- > Graphite
- > Gypsum
- > Cellulose
- CelluloseSulphur
- CottonCement
- > Glass and Plastic Fibres
- > Coal
- > Quartz
- > Copper
- > Aluminium
- > Barium
- > Titanium
- > Vanadium
- > Chrome
- > Manganese Molybdenum
- * This is not a full contaminants list. For a full list, contact Sperian customer service for a copy of the respiratory contaminant guide.







4211 P2 Flat fold Style Respirator with Willtech® Seal & Exhalation Valve

Individually packaged P2 protection flat-fold respirator with exhalation valve for convenient pocket storage

- High quality exhalation valve facilitates effortless breathing during periods of extended use and in hot and humid work environments
- > Willtech® boomerang nose-seal, providing maximum protection and comfort
- Sliding elastic ring headband eliminates staples
- Green nose bridge indicating P2 protection
- Nose bridge is easily molded to provide correct fit
- Large inner volume provides ease of movement and optimised breathing comfort
- > Silicone, PVC and latex free
- > Individually wrapped
- > For glass etching, welding, soldering, brazing, torch cutting, metal pouring, grinding, sanding, sweeping, dusty and hot operations

1007720 STANDARD SIZE

5251 P2 Premium Cup-shape Respirator with Willtech® Polo Seal & Exhalation Valve

Premium cup-shape P2 protection respirator with high protection polo seal and charcoal layer filter for organic vapour odour relief

- > High quality exhalation valve facilitates effortless breathing during periods of extended use and in hot and humid work environments
- > High level comfort and protection achieved through the Willtech® polo seal
- > Brown nose bridge indicates organic vapour relief in nuisance levels
- Nose bridge is easily molded to provide correct fit
- Adjustable headband with no staples
- > Large inner volume provides ease of movement and optimised breathing comfort
- > Silicone, PVC and latex free
- > For glass etching, welding, soldering, brazing, torch cutting, metal pouring, grinding, sanding, sweeping, dusty and hot operations

1007711 STANDARD SIZE

5261 P2 Premium Cup-shape Respirator with Willtech® Boomerang Seal & Exhalation Valve

Premium cup-shape P2 protection respirator with exhalation valve and charcoal layer filter for acid gas and odour relief

- > High quality exhalation valve facilitates effortless breathing during periods of extended use and in hot and humid work environments
- > Willtech® boomerang nose-seal, providing maximum protection and comfort
- > Blue nose bridge indicating relief from nuisance levels of acid gases and vapours
- Nose bridge is easily molded to provide correct fit
- Large inner volume provides ease of movement and optimised breathing comfort
- > Elastic straps are stapled outside the filter media to ensure the integrity of the filter media is maintained
- > Silicone, PVC and latex free
- > For glass etching, welding, soldering, brazing, torch cutting, metal pouring, grinding, sanding, sweeping, dusty and hot operations

1007714 STANDARD SIZE **1007715** X-LARGE

Superone P1 & P2 Disposable Respirators

Protecting against mechanically generated dusts P₁ & P₂, mists P₁ & P₂ and fumes P₂. Providing high levels of filtration efficiency, fit and breathing comfort, Superone is the economical choice for effective single use respiratory protection.



W3203 Superone P1 Respirator

Economical P1 Cup-shape respirator suggested for use with particulate aerosols free of oil

- > Preformed for excellent fit, comfort and protection
- > Latex, silicone and PVC free
- No metal parts perfect for underground mining
- > Ultra-lightweight 7-12 grams
- > Suitable for use with spectacles
- > Welded straps provide increased comfort against wearers face
- > Fits a wide variety of facial profiles
- > Crush resistant
- Suitable for medical, sanding, grinding, woodworking, polishing and dusty environments

1015842 STANDARD SIZE



W3204 Superone P1 Respirator with Exhalation Valve

Economical P1 Cup-shape respirator suggested for use with particulate aerosols free of oil

- > Valve provides increased comfort in hot and dusty work environments.
- > Preformed for excellent fit, comfort and protection
- > Latex, silicone and PVC free
- No metal parts perfect for underground mining
- > Ultra-lightweight 7-12 grams
- > Suitable for use with spectacles
- > Welded straps provide increased comfort against wearer's face
- > Fits a wide variety of facial profiles
- > Crush resistant
- Suitable for medical, sanding, grinding, woodworking, polishing and hot dusty environments

1015843 STANDARD SIZE



W3205 Superone P2 Respirator

Economical P2 Cup-shape respirator suggested for use with particulate aerosols free of oil

- > Preformed for excellent fit, comfort and protection
- > Latex, silicone and PVC free
- No metal parts perfect for underground mining
- > Ultra-lightweight 7-12 grams
- > Suitable for use with spectacles
- > Welded straps provide increased comfort against wearers face
- > Fits a wide variety of facial profiles
- > Crush Resistant
- Suitable for welding, glass etching, soldering, brazing, torch cutting, metal pouring, sanding, grinding and dusty environments

1015844 STANDARD SIZE



Protection against dusts, mists and fumes including*

- > Clay P1 > Kaolin P1
- > Flour P1 > Glass-Wool P1
- > Ferrous Metals P1
 - > Calcium Carbonate P1 & P2
 - > Cellulose P1 & P2 > Sulphur P1 & P2
- > Cotton P1 & P2 > Cement P1 & P2
- > Sodium Silicate P2
- > Graphite P2
- > Gypsum P2
- > Glass and Plastic Fibres P2
- > Quartz P2
- > Copper P2
- > Aluminium P2
- > Barium P2 > Titanium P2
- > Vanadium P2 > Chrome P2
- > Manganese P2 > Molybdenum P2
- * This is not a full contaminants list. For a full list, contact Sperian customer service for a copy of the respiratory contaminant guide.




W3206 Superone P2 Respirator with **Exhalation Valve**

Economical P2 Cup-shape respirator suggested for use with particulate aerosols free of oil

- > Valve provides increased comfort in hot and dusty work environments
- > Preformed for excellent fit, comfort and protection
- > Latex, silicone and PVC free
- > No metal parts perfect for underground mining
- > Ultra-lightweight 7-12 grams
- > Suitable for use with spectacles
- > Welded straps provide increased comfort against wearers face
- > Fits a wide variety of facial profiles
- > Crush resistant
- > Suitable for welding, glass etching, soldering, brazing, torch cutting, metal pouring, sanding, grinding and dusty environments

1015846 STANDARD SIZE







APR - Air Purifying Respirators

- > Survivair 2000 Series
- > Survivair Blue 1
- > Survivair 3000 Series

- > Survivair 4000 Series
- > Survivair Opti-Fit Convertable APR



Page 24

PAPR - Powered Air Purifying Respirators

- > Survivair Opti-Fit Convertible
- > Turbovisor MV



Page 28

SAR - Supplied Air Respirators

- > Survivair Opti-fit convertible Constant Flow Respirator Full Facepiece
- > Survivair Constant Flow Respirator Half Face Piece Assembly
- > Survivair Conversion Kit
- > Sperian Spray Painters Kit
- > Airvisor MV Range
- > ClearFlow 2 Filter System



Page 29

SCBA - Self Contained Breathing Apparatus

- > Fenzy XPro
- > Fenzy Aeris
- > Fenzy Bio-Scape



Page 3

Re-usable respirators use replaceable filters to clean the air when combined with a half face piece, full face piece, or head covering. Wearers are protected from finely divided solids or liquid matter (particulates), or gases and vapours from the air.

Filters are available to protect against contaminants such as organic vapours, acid gases, sulphur dioxide and ammonia.

- P1) For use against mechanically generated particulates
- (P2) For use against mechanically and thermally generated particulates
- P3 For use against all particulates including highly toxic materials
- (ABEK) For use against various gases and vapours (refer page 26)

Features of the re-usable range

Sperian re-usable respirators include innovative features and design, providing great protection at a competitive price.

1 Comfortable materials

Manufactured from lightweight silicone to prevent oxidation reaction with ozone, and loss of elasticity, providing durability and comfort.

2 Multi-purpose

The Survivair Opti-Fit Convertible full face masks (refer pages 25, 28 & 29) are multi-purpose for easy conversion from APR, PAPR or SAR, to provide protection against almost any contaminant and concentration level.

3 Easy to breathe

Large inhalation ports reduce breathing resistance improving fit and comfort.

4 Range of sizes

All models offer a variety of mask sizes to allow for different face shapes and sizes.

5 Backup service

Complete range of replacement parts provides significant operational cost savings.





Fitting instructions

For optimum protection against airborne hazards your respirator must be fitted correctly. Follow the instructions below to achieve the best result.



Re-usable half mask respirator fitting instructions

- 1 Loosen the elastic band without completely pulling the band out of the slots in the crown suspension.
- 2 Pull gently on the lower neck strap, creating a large loop. Put lower neck strap loop over the head.
- 3 Place the respirator to the face, covering the mouth and nose. (The narrow part of the face piece should be over the nose.) Pull the crown suspension over the head and adjust its placement until it is comfortable.
- 4 Using both hands, grasp the free ends of the elastic band and gently pull the elastic straps away from your face until the respirator is snug and seated comfortably. Be sure the neck strap is flat and smooth against the back of the neck. To tighten the neck strap, make intermediate adjustments at the straps as they exit the top slots on the yoke. Gently pull the free ends to make final adjustments and secure a comfortable fit of the respirator to your face.









Fit Testing

There are two types of facial fit tests – Qualitative and Quantitative.

Qualitative fit testing is a simple pass/fail test based upon the user's subjective assessment of the leakage, via the face seal region, of a test agent.

Quantitative fit testing uses equipment (usually a portacount machine) to measure the efficiency of a respirator in preventing materials in the atmosphere from entering a users breathing zone.

ASNZS 1715: 2009 states that a Program Administrator (Person who is made responsible for a companies respiratory protection program) must ensure that a suitable fit test is carried out for all respirator users.

Fit Testing should be conducted annually or whenever there is a change in the wearers facial characteristics (such as the wearer was to grow facial hair)

The Bitrex Fit Test Kit provides a fit testing option as per section 8.5.3.2 of ASNZS 1715:2009 (Saccharin Mist test), and is suitable for testing both disposable and re-usable respirators fitted with a particulate filter.

If testing a gas or vapour filter the filter should also be fitted with a particulate filter to prevent the wearer inhaling any mist during testing

1010051 BITREX FIT TEST KIT. INCLUDES HOOD, PUMPS AND TEST SOLUTIONS 1010052 BITREX SENSITIVITY SOLUTION PACK OF 6 1010053 BITREX FIT TEST SOLUTION PACK OF 6




How re-usable respirators work

Sperian re-usable respirators utilise a variety of components to operate seamlessly and provide day-long comfort and safety. Contact Sperian customer service if you require additional information about respirator operation.



Powered Air Purifying Respirator PAPR

A switch is used to activate a motorised blower unit which draws air through a filter, delivering cool clean air into the



Constant Flow Supplied Air Respirator SAR

Compressed air from outside the hazard area delivered to a coalescing filter for cleaning and then to the respirator waist belt for regulating to a constant flow, delivering cool clean air into the face piece.

- 1 Compressor
- 2 Coalescing filter
- 3 Regulator
- 4 Face piece

Airvisor MV


Compressed air from outside the hazard area is delivered to a coalescing filter for cleaning and then to the respirator waist belt for regulating to a constant flow, delivering cool clean air into the face piece. Air is also available for air tools.

- 1 Compressed air
- 2 Coalescing filter
- 3 Regulator
- 4 Face piece
- 5 Air Tool


SCBA


Compressed air from a cylinder is delivered to the face piece via a demand valve and pressure reducer. Gauge displays cylinder volume and warning whistle is activated when remaining air is low.


- 1 Cylinder
- 2 Demand valve
- 3 Pressure reducer
- 4 Warning whistle and gauge



Note: The compressor is not provided







APR Re-usable Half Masks

Half-face protection used in conjunction with replaceable filters to protect against a variety of contaminants. Ideal for people who use masks on a regular basis.



Survivair 2000 Half Mask

Lightweight silicone construction with an impressive range of features provides a comfortable user-friendly half mask

- > Comfortable, pliable silicone prevents oxidation and elasticity loss
- > Large, pliable sealing area providing excellent fit
- > Oversized inhalation ports provide lower breathing resistance
- > Comfortable, angled self-adjusting nose allows for safety eyewear
- Yoke design for a snug secure fit and reduced face piece slippage
- Computer designed face piece provides optimal speech communication without using a speaking diaphragm
- Replacement parts available for significant cost savings
- > Ideal for use on a regular basis
- Accepts a range of Sperian threaded replacement cartridge/filters
- > Numerous applications -Refer to page 27 for available filters

U250000 SMALL SIZE U260000 MEDIUM SIZE U270000 LARGE SIZE



Survivair Blue 1 Half Mask

The only half mask with a speaking diaphragm. An economical way to improve communication in noisy areas

- > Comfortable, pliable silicone prevents oxidation and elasticity loss
- Yokeless head harness will not interfere with filter attachment
- Speech diaphragm for communication in noisy work environments
- > Comfortable, angled self-adjusting nose allows for safety eyewear
- > Replacement parts available for significant cost savings
- Face piece skirt is covered by a 5-year warranty
- > Excellent choice for professionals
- > Ideal for use on a regular basis
- > Accepts a range of Sperian threaded replacement cartridge/filters
- > Numerous applications -Refer to page 27 for available filters

U210010 SMALL SIZE U220010 MEDIUM SIZE U230010 LARGE SIZE



Survivair 3000 Half Mask

Economical half face mask packed full with all the features you expect in a quality respirator

- Comfortable, pliable silicone prevents oxidation and elasticity loss
- > Comfortable, angled self-adjusting nose allows for safety eyewear
- Yokeless head harness will not interfere with filter attachment
- > Replacement parts available for significant cost savings
- > Ideal for use on a regular basis
- Numerous applications –Refer to page 27 for available filters

U350000 SMALL SIZE **360000** MEDIUM SIZE **U370000** LARGE SIZE



APR Re-usable Full Face Masks

Full-face protection used in conjunction with replaceable filters to protect against a variety of contaminants. Ideal for people who use masks on a regular basis.



Survivair 3000 Kits

Pre-packaged kits include Survivair 3000 half mask and filters selected for welding and spray painting/pesticide spraying

- > Spray Painters Kit includes: 3000 series mask
 - 2 x A2 filters
- 2 x P2 pre-filters
- 2 x retainers
- > Welders Kit includes: 3000 series mask
- 2 x P3 filters
- > Suitable for Spray painting in low level contaminated environments and welding applications

U351033 SPRAY PAINTERS KIT SMALL SIZE **U351034 SPRAY PAINTERS KIT MEDIUM SIZE U351035** SPRAY PAINTERS KIT LARGE SIZE **U351036** WELDERS KIT SMALL SIZE U351037 WELDERS KIT MEDIUM SIZE U351038 WELDERS KIT LARGE SIZE



Survivair 4000 Full face piece

Full face piece Air Purifying Respirator provides workers with an unobstructed wide-angle view

- > Comfortable, pliable silicone prevents oxidation and elasticity loss
- > Hard coating on outside of lens protects against scratches
- > Face piece is pliable, elastic and comfortable
- > Large sealing surface for superior fit
- > Large inhalation ports for lower breathing resistance
- > Optional translucent nose cup to reduce fogging
- > Easily converts for use as a PAPR or SAR respirator
- > Accepts a range of Sperian threaded replacement cartridge/filters
- > Suitable for applications requiring increased protection
- > Numerous applications -Refer to page 27 for available filters

410010 SMALL SIZE 420010 STANDARD SIZE



Opti-Fit Convertible APR

Versatile full face respirator. Easily switch the face piece from various applications (APR, PAPR, SAR) without having to change face pieces

- > Convert for various applications (APR, PAPR and CF-SAR) using face piece caps and the appropriate ports
- > Only one fit test needed for APR, PAPR and CF-SAR applications
- > Saves on inventory, time and cost
- > Distortion-free lens for excellent visibility and wide viewing area
- > Lightweight design reduces head and neck stress
- > Choose from a 5-point strap or industrial mesh head net
- > All straps attached to the rim of the face piece, rather than the silicone skirt, to reduce pressure points and distortion of the sealing surface when tightened
- Nose cup prevents fogging. Optional kits for custom sizing (comes standard with medium nose cup) and optional clear nose cup kits are available
- > Numerous applications -Refer to page 27 for available filters

U754000 5-POINT STRAP SMALL SIZE U764000 5-POINT STRAP MEDIUM SIZE U774000 5-POINT STRAP LARGE SIZE U754100 MESH HEAD NET SMALL SIZE U764100 MESH HEAD NET MEDIUM SIZE U774100 MESH HEAD NET LARGE SIZE 702090 SURVIVAIR OPTIFIT MESH HEADNET RETRO FIT KIT

Filter selection chart

Use the contaminant hazard chart to help select the right filter for your work environment. Selecting a filter and mask combination is dependent on a number of factors, including the type of contaminant, exposure time and level of exposure.

Certified Product Australian Standard

Important Information

This filter selection chart should be used as a guide only. An MSDS sheet should be consulted and concentration levels of the contaminants you are working with should be checked before deciding on a disposable or reusable respirator with filters. Some contaminant concentrations may require a higher level of protection such as a PAPR, SAR or SCBA.


Hazard

Ha	Hazards Key				
Α	Organic Vapours				
В	Acid Gases				
E	Sulphur Dioxide (SO ₂)				
K	Ammonia (NH ₃)				
Р	Particulates				

Hazard	Α	В	E	K	P
Acetaldehyde					
Acetic acid	•				
Acetic acid Acetic anhydride					
Acetone	•				
	•				
Acetophenone					
Acrylic acid	•				
Acrylonitrile	•				
Aliphaticnaphtha	·				
Allyl alcohol	•				D.
Aluminium chloride					P1
Aluminium metal & oxide o	iust				P1
Ammonia				•	_
Ammoniumchloride, mist				•	P1
n-Amyl acetate	•				_
Antimony dust					P1
Antimony fume					P2
Aromatic naphtha	•				
Arsenic & soluble compour	ıds				P1
Asbestos					P1
Barium					P1
Benzaldehyde	•				
Benzoyl peroxide					P1
Benzyl chloride	•	•			
Beryllium					P3
Biphenyl	•				P1
Bromine	•	•			
Butyl acetate	•				
Butyl alcohol	•				
n-Butylamine				•	
Butyl phenol	•				P1
Butyraldehyde		•			Р3
Cadmium dust					P1
Cadmium fume					P2
Caprolactam	•				
Carbon disulfide	•				
Chlorine		•			
Chlorinedioxide		•			
Chlorineparaffin		•			
Chloroacetophenone	•				
Chlorobenzene					
Chromic acid and chromate	25				P1
Cobalt metal dust					P1
Cobalt metal fume					P2
Copper dust					P1
Copper fume					P2
Cresol, all isomers					. 2
Crotonaldehyde	•				
Cumene	•				
Cyclohexane	•				
Cyclohexanol	•				
	•				
Culohovanone					
Cylohexanone Diacetonealcohol	÷				

Tiuzuru	$\boldsymbol{\Lambda}$	ט	-	IX	
Dibutylphosphate	•				P1
Dichlorobenzene	•				P1
1, 2 - Dichloroethylene	•				
Diethylamine	•	•	•	•	
Diethyl ketone	•				
Dimethyl ether	•				
Dimethylamine				•	
Dinitrobenzene	•				P1
Ethanolamine	•				
2 - Ethoxyethanol	•				
Ethylacetate	•				
Ethyl acrylate	•				
Ethylamine				•	
Ethyl diamine	•				
Ethyleneglycol	•				
Ethylether	•				
Ferrous chloride					P1
Formaldehyde			•		11
Furfural					
Furfuryl alcohol	•				
•	•				
Glutaraldehyde	·				
Glycolmonoethyl ether	÷				
Heptane Hexachloroethane	·				
	·				
Hexane	·				
Hexylene glycol	·				D.
2 - Hydroxy propyl acrylate	•				P1
Hydrochloric acid gas		•			
Hydrogen bromide	•				ъ.
Hydroquinone					P1
Ironoxide fume					P2
Isoamyl acetate	•				
Isoamyl alcohol	•				
Isobutylacetate	•				
Isophorone	•				
Isopropyl acetate	•				
Isopropyl amine				•	
Isopropyl ether	•				
Lead dust					P1
Lead fume					P2
Maleicanhydride					P1
Manganese dust					P1
Manganese fume					P2
2 - Methoxy ethanol	•				
2 - Methoxy ethylacetate	•				
3 - Methoxy propyl amine				•	
Methyl acetate	•				
Methyl acrylate	•				
Methylamine				•	
Methyl amyl alcohol	•				
Methyl n-amyl ketone	•				
Methylcyclohexane	•				
Methyl ethyl ketone (MEK)	•				

Hazard	Α	В	Е	K	P
DIA de la companya de	(1				
PI Methylisobutyl ketone(MIBK					
PI Methylisopropyl ketone	•				
Methyl mercaptan	•				
Methyl methacrylate	•				
Methyl propyl ketone	•				
a - Methyl styrene	•				
Monoethylamine				•	
Morpholine	•				
Naphtha	•				_
Naphthalene	•				P1
Nickel metal dust					P1
Nickel metal fume					P2
Nitroaniline	•				P1
Nitrobenzene	•				
Nitrotoluene	•				
Octane	•				
OxalicAcid					P1
Phenol	•				P1
p - Phenylenediamine	•				P1
Phenyl ether	•				
Phenyl mercaptan	•				
Phosphoric acid					Р3
Phthalic anhydride	•				P1
Potassium hydroxide					P1
2 - Propanol	•				••
Propenoic acid	•				
Propionicacid	•				
Propylene dichloride					
Pyridine	•				
Quartz(silica)					P1
Selenium compounds(asSe)					P1
Selenium sulfide					P1
Sodiumbisulfite			÷		P1
Sodium fluoride		•	•		
		•			P3
Sodium hypochlorite					P1
Stoddard solvent	•				
Styrene monomer	•				_
Sulfamic acid					P1
Sulphur dioxide			•		
Sulfuric acid				•	P1
Tetrahydrofuran	•				
Toluene	•				
Tributyl phosphate	•				P1
Trichloroacetic acid	•	•			
Trichloromethylsilane		•			P1
Trimethyl benzene	•				
Trisodium phosphate					Р3
Turpentine	•				
Vinylacetate	•				
Vinyl toluene	•				
White spirits	•				
Xylene	•				
Zinc chloride fume					P2





Filter Life Expectancy

Filter life depends on a number of variable factors including: the wearers breathing rate, the characteristics and level of the contaminant, the length of exposure to a contaminant, and environmental conditions such as temperature

and humidity which could also effect the wearers breathing rate. Saturated or used filter cartridges will leak trace amounts of contaminants to the wearer which may be detected by odour, taste, and/or irritation – If a contaminant can be

detected by any of these means filter cartridges should be changed immediately.



For a full listing of contaminants and suitable respiratory protection contact Sperian for a copy of the Sperian 2010 Respiratory Contaminant Guide.

CD1 Respiratory Contaminant Guide



U100100 A2 FILTER



U100200 BE1 FILTER



U100300 ABE1 FILTER



U100400 K1 FILTER



100800 ABEK1 FILTER



U105000 P3 FILTER



U105100 A2-P3 FILTER



U105200 BE1-P3 FILTER



U105300 ABE1-P3 FILTER



U105400 K1-P3 FILTER



U105800 ABEK1-P3 FILTER



108000 PAPR-P3 FILTER



B140074 FILTER BASE PLATE



U101000 P2 PREFILTER



140079 FILTER RETAINER

Powered Air Purifying Respirators (PAPR)

Provides increased protection by delivering filtered air into the face piece, reducing inward leakage and increasing comfort.



Opti-Fit Convertible PAPR

Versatile full face respirator. Easily switch the face piece from various applications (APR, PAPR, SAR) without having to change face pieces

- > Convert for various applications (APR, PAPR and CF-SAR) using face piece caps and the appropriate ports
- > Only one fit test needed for APR, PAPR and CF-SAR applications
- > Saves on inventory, time and cost
- > Distortion-free lens for distortion free visibility and wide viewing area
- > Lightweight design reduces head and neck stress
- > Choose from a 5-point strap or industrial mesh head net
- Nose cup prevents fogging. Optional kits for custom sizing (comes standard with medium nose cup)
- Low cost High Efficiency (P3) filter consolidates inventory and reduces costs
- > Contoured, water resistant battery pack fits comfortably on wearer's hips
- > Efficient motor provides a high 170lpm air flow rate

U520600 5 POINT STRAP, MEDIUM 520073-AUST BATTERY CHARGER 108000 PAPR-P3 FILTER 702090 SURVIVAIR OPTIFIT MESH HEADNET RETRO FIT KIT



Turbovisor MV

Versatile power assisted respirator draws air through filter system and distributes it to the breathing zone

- > Robust design with lightweight construction
- > P2 electrostatic filter supplied as standard, odour filter optional
- > Wide view visor gives maximum comfort
- Detachable cotton neck cover to protect hair
- > Smooth, tilt visor can be raised when out of the hazard area
- Turbovisor comes standard with a polycarbonate visor for impact protection
- Acetate replacement visor available for chemical splash protection

1010032 6 HOUR HEAD MOUNTED BATTERY 1008030 8 HOUR WAIST MOUNTED BATTERY



Optrel E1100 PAPR

Provides ideal protection against UV-&IRradiations, flying particles, metal fumes and dusts emitted during welding and associated processes.

- > Re-chargeable lithium-ion battery
- > Blower draws ambient air through a fine particulate filter and ventilates the helmet with clean and refreshing air.
- > Fitted with both a visible and audible alarm, which tells the operator if the filter is blocked or battery is low
- Comfortable flame retardant waist belt threads through the leather lumbar support which fits the system to the user's body
- Smart electronics provide a constant airflow rate of 1701/min, regardless of battery charge and filter loading and keeps a permanent overpressure in the helmet to avoid the penetration of pollutant.
- Short air duct attached to helmet decreases the risk of snagging upon surrounding structures in 3D constructions.

4240.003 E1100 PAPR WITH OPTREL E680 SHADE 9-13 DARKBLUE WELDING HELMET **4280.000** E1100 PAPR WITH OPTREL E640 SHADE 10/11 BLACK WELDING HELMET



Constant Flow Supplied Air Respirators (SAR)

Provides high level of interchangeability and protection in non-IDLH environments, where air sources are available.



Survivair Constant Flow SAR Half-face Piece Assembly

Constant flowing clean air is supplied to the face for reduced fatigue and increased comfort

- Compatible with a wide range of common air sources
- > Comes complete with waistbelt
- > Easily adjustable head harness
- Cooling comfortable air flow across the face
- > Reduces fatigue as the operator's breathing is assisted

981323 HALF MASK ASSEMBLY



Survivair Conversion Kit

Allows 4000 series and Optifit convertible full face masks to be used for continuous flow SAR applications

- > Easy to use
- > Comfortable and lightweight
- > Waistbelt includes hose and air flow regulator

981223 CONVERSION KIT



Survivair Constant Flow Opti-Fit Convertible SAR

Versatile full face respirator. Easily switch the face piece from various applications (APR, PAPR, SAR) without having to change face pieces

- Convert for various applications (APR, PAPR and CF-SAR) using face piece caps and the appropriate ports
- Only one fit test needed for APR, PAPR and CF-SAR applications
- > Saves on inventory, time and cost
- > Distortion-free lens for distortion free visibility and wide viewing area
- > Lightweight to reduce head and neck stress
- > Available with a 5-point strap or an industrial mesh head net using the mesh retro fit kit
- > Connects to airline hose by a high volume, low pressure, durable rubber breathing tube
- > Breathing tube attaches to one front inlet nozzle port (side ports are capped off)
- > Conversion Kit available separately to convert APR or PAPR to SAR

U981501 5 POINT STRAP MEDIUM SIZE **702090** SURVIVAIR OPTIFIT MESH HEADNET RETRO FIT KIT



Opti-Fit Convertible Constant Flow SAR Yellow Air Breathing Hose

- > Material Inner: White Medical Grade PVC
- > Material Outer: Yellow Medical Grade PVC
- > Reinforcing: High Tenacity Polyester yarn
- > Inside Diameter : 10.5mm
- > Outside Diameter: 17.5mm
- > Working Pressure @ 20°C : 2.4MpA

10MTRE342 10M HOSE W/CEJN COUPLINGS 15MTRE342 15M HOSE W/CEJN COUPLINGS 20MTRE342 20M HOSE W/CEJN COUPLINGS 30MTRE342 30M HOSE W/CEJN COUPLINGS

Constant Flow Supplied Air Respirators (SAR)

Provides high level of interchangeability and protection in non-IDLH environments, where air sources are available.



Sperian Spray Painters Kit

A complete respiratory protective system, ideal when applying two-pack paint

- Complete with air-visor, 7.5m auxiliary air hose for spray tool, waistbelt regulator and Clearflow II wallmount filter
- > Two person combination filter set including airline fittings
- > Kit is packed in a re-usable plastic storage container

DCF-100SPW SPRAY PAINTERS KIT 1016962 CLEARFLOW II WALL MOUNT FILTER SET 1011061 7.5M AIR HOSE



Airvisor MV Re-finishers Spray Kit

SAR with additional spray gun hose assembly and acetate visor to provide protection against chemical splashes

- > Disposable fabric face skirt cassette
- > Waistbelt with tamper-proof airflow regulator
- Additional spray-gun hose assembly allows spray painters to run a spray-gun off the waistbelt regulator while also suppling air to the visor
- > Clear acetate visor

1007972 RE-FINISHERS KIT



Airvisor MV Chemical Kit

SAR with acetate visor which provides protection against chemical splashes

- > Disposable fabric face skirt cassette
- > Waistbelt with tamper-proof airflow regulator
- > Clear acetate visor

1007985 CHEMICAL KIT





Airvisor MV Industrial Kit

SAR with polycarbonate visor which provides impact resistance against flying particles

- > Disposable fabric face skirt cassette
- > Waistbelt with tamper-proof airflow regulator
- > Polycarbonate visor

1007973 INDUSTRIAL KIT



Airvisor Spray Kit

SAR featuring a foam face seal and acetate visor to provide protection against chemical splashes

- > Disposable foam face skirt cassette
- > Lightweight construction reduces stress on the head and neck
- > Acetate visor

1011060 SPRAY KIT




Clearflow 2 Filter System


Compressed air filter system delivers high quality breathable air to a range of supplied air respirator systems

- > Utilises air from a factory compressed air system or compressor
- > Particulates, bulk oil & water are removed by a high capacity coalescing filter
- > Oil vapour and odour are removed by a high capacity carbon absorber filter
- No need for filter bowls or auxiliary parts
- > Fluid drains are protected, reducing repairs and downtime
- > New one-piece aluminium body design
- > Modular design with 'Cliplok' system
- > High flow system (up to 1,600 l/min)
- > Pressure indicator, isolating valve and dual QR outlets for two users
- > Available as wall mounted and portable stand versions

1016962 - DCF-2152/T WALL MOUNTED 1016967 - DCF-2159/T PORTABLE STAND DCFS-2163 REPLACEMENT COALESCING FILTER ELEMENT DCFS-2165 REPLACEMENT CARBON ELEMENT

Spare Parts





2000 & 3000 SERIES HALF MASK

Νº Part Description 260048 Headband and Yoke 1 **B200019** Exhalation Valve Seat B140005 Exhalation Valve Pack of 4 **Exhalation Valve Cover** B260018 B140001 Inhalation Valve Pack of 6 5 6 **Cartridge Connector** B140002 7 B140074 Filter Holder/Base Pack of 2 8 140079 Filter Retainer

BLUE 1 HALF MASK

702028

Νº Part Description 1 Headband and Cradle B140040 2 B200019 **Exhalation Valve Seat** 3 B140005 Exhalation Valve Pack of 4 4 B260018 **Exhalation Valve Cover** 5 B140001 Inhalation Valve Pack of 6 B140002 **Cartridge Connector** Filter Holder/Base Pack of 2 7 B140074 Filter Retainer 140079 8 Speaking Diaphragm Blue 1 B220054

STANDARD OPTI-FIT FULL FACE MASK


(COMPLETE UNIT NO LONGER AVAILABLE)

Νº Part Description 1 702009 Headstrap 2 Small Skirt 962157 2 962167 Medium Skirt 2 962177 Large Skirt 3 702007 Replacement Lens Polycarbonate Anti Scratch Coating 4 962031 Upper Rim 5 962037 Lower Rim 6 839102 Screw For Lens Retainer (2 req.) 7 B140001 Inhalation Valve Pack of 6 8 Connector Threaded 702035 9 Twin Seal 702037 10 Exhalation Valve Pack of 4 B140005 11 820261 0 Ring 12 702003 Nozzle 13 702004 Cover 14 962090 Air Valve Holder 15 702023 Nose Cup 16 702016 Short Buckle Strap TPE 17 702012 Long Buckle Strap TPE 18 702011 Buckle

Survivair Clear Lens Tear Off Covers (not shown)



OPTI-FIT CONVERTIBLE: 7540/7640/7740/7541/7641/7741/5260/981501



OPTI-FIT CONVERTIBLE PAPR

Cap

Screw Cap

Nozzle Plug


Nozzle Gasket

ОРТ	OPTI-FIT CONVERTIBLE PAPR				
Nº	Part	Description			
1	U520600	Opti-Fit Convertible PAPR			
2	B520033	Blower Gasket			
3	82401410	O-RING for breathing tube & mask mounted blower			
4	520030	Replaceable Power Cord			
5	520020	Blower Assembly			
6	520073-AUST	Battery Charger for Survivair PAPR			
7	981177	Filter Shower Cap with holes			
8	981178	Filter Shower Cap without holes			
9	520050	Waist Belt			
10	108000	P3 filter to suit Survivair PAPR (mask mounted)			
11	A520060	Battery Pack			
12	985020	Threaded Cap (2 req)			

Adapter Assembly (O-Rings installed)




Spare Parts



4000 SERIES FULL FACE MASK

-		
Νº	Part	Description
1	941723	Headstrap 4-pt (Part will be be discontinued in 2011)
1	961094	Headstrap 5-pt (Part will be be discontinued in 2011)
2	450002	Standard Skirt 4-pt
3	839102	Screw For Lens Retainer (2 req.)
4	941280	Lens Retainer (2 req.)
5	941802	Replacement Lens Polycarbonate Anti-Scratch
		Coating (replaced part number 941712)
6	940135	Neck Strap
7	B520039	Cover (Part will be be discontinued in 2011)
8	955805	Screw for Cover (2 req.)
9	420020	Snap-on-Cap
10	B140001	Inhalation Valve Pack of 6
11	B140002	Cartridge Connector
12	B420008	Grill (Part will be be discontinued in 2011)
13	140079	Survivair Pre-Filter Retainer
14	941759	Speaking Diaphragm Assembly
15	820031	O-ring (speaking diaphragm)
16	980081	Nozzle
17	B140003	Exhalation Valve
18	82401410	O-ring (cover) Pack of 10
19	82401410	O-ring (cover) Pack of 10
20	420117	Nose Cup Kit
21	962080	Air Valve
22	962090	Air Valve Holder
	B140095	Clear Polyester Tear Off Covers (not shown)
	430000	Welding Lens Attachment for 4000 Series
		Shade 10 Lens (not shown)
	430005	Lower Protective bib for all Welding Shields
		(not shown)
	430010	Upper Protective Bib for all Welding Shields
		(not shown)



4000 SERIES PAPR

980019

(COMPLETE UNIT NO LONGER AVAILABLE)

(not shown)

Νº	Part	Description
1	420010	4000 Series Blue Silicon Full Face Mask
2	B520033	Blower Gasket
3	82401410	O-RING for breathing tube & mask mounted blower
4	520030	Replaceable Power Cord
5	520020	Blower Assembly
6	520073-AUST	Battery Charger for Survivair PAPR
7	981177	Filter Shower Cap with holes
8	981178	Filter Shower Cap without holes
9	520050	Waist Belt
10	108000	P3 filter to suit Survivair PAPR (mask mounted)
11	A520060	Battery Pack
12	985020	Threaded Cap (2 req)

Speaking Diaphragm Removal Tool 4000 Series



FULL FACE AND HALF FACE SAR

Part Description

981227 Refer 4000 Series mask for spares **981323** Refer Blue 1 mask for spares

U981501 Refer Opti-Fit Convertible mask for spares

TURBOVISOR MV 1008030 8 HOUR


Νº	Part	Description
1	DTVS-1517	Browguard & Frame
2	1001774	Polycarbonate Visor Pack of 5
2	1001775	Clear Acetate Visor Pack of 5
3	1001784	Fabric cassette Pack of 5
3	1001783	Flame Retardant Fabric Cassette
4	1001778	Visor Cover pack of 10
4	1001779	Visor Cover pack of 50
5	1001777	Blower 8-Hour suits DTMV-0301 Turbovisor
6	1001797	Turbovisor Pre-Filter pack of 10
7	1001793	Turbovisor P2 Main Filter pack of 2
7	1001794	Turbovisor A2 Odour Main Filter
8	1001792	8-Hour Batter Pack Suits DTMV 0301 Turbovisor
9	1012290	Replacement 4-8 hour battery charger
10	1001790	Neck Cover

Tyvek Storage Bag


TURBOVISOR MV 1010032 6 HOUR

11 1001738

Νō	Part	Description
1	DTVS-1517	Browguard & Frame
2	1001774	Polycarbonate Visor Pack of 5
2	1001775	Clear Acetate Visor Pack of 5
3	1001784	Fabric cassette Pack of 5
3	1001783	Flame Retardant Fabric Cassette
4	1001778	Visor Cover pack of 10
4	1001779	Visor Cover pack of 50
5	1001776	Blower 6-Hour Suits DTMV-0302
6	1001797	Turbovisor Pre-Filter Pack of 10
7	1001793	Turbovisor P2 Main Filter Pack of 2
7	1001794	Turbovisor A2 Odour Main Filter
8	1001782	6-Hour Batter Pack Suits DTMV-0302 Turbovisor
9	1012290	Replacement 4-8 hour battery charger
10	1001790	Neck Cover
11	1001738	Tyvek Storage Bag




Spare Parts



AIRVISOR MV 1007972, 1007985, 1007973

Νº	Part	Description
1	1008024	Airvisor Browguard Frame
2	1001775	Clear Acetate Visor Pack of 5
		(Suits DMAK-0201 & DMAK-0202)
2	1001774	Replacement Polycarbonate Visor Pack of 5 (Suits
		DMAK-0203)
3	1001675	Spare Air tube and Diffuser
4	1001778	Visor Covers pack of 10
4	1001779	Visor Covers pack of 50
5	1001784	Fabric Cassette Pack of 5
6	1001725	Airvisor Min QR Socket
7	1001673	Replacement Regulator Assembly
		(top housing of regulator)
8	1001672	Spare Carbon Cartridge for Waist belt regulator
9	1001674	Replacement Waist belt & bottom housing of
		Regulator
10	1001719	Airvisor QR Plug
11	1008025	Airvisor Standard QR Socket Double Action
11	1001718	Blanking Plug for waistbelt regulator (replaces
		DAF-6350 if no air tool is running off regulator)
12	DHFE-0075	Willson Blueline Hose 7.5m
12	DHFE-015	Willson Blueline Hose 15m
13	1001683	Air Powered Tool Hose
14	1001676	Neck Cover Pack of 5
15	1001733	Tyvek Hood Pack of 5

Tyvek Storage Bag



AIRVISOR - 1011060

1001738

Νº	Part	Description
1	1001669	Airvisor Browguard
2	1001670	Polycarbonate Visor with foam seal
2	1001671	Acetate Visor with foam seal
3	1001675	Air tube and Diffuser
4	1001732	Visor Cover Pack of 10
4	1001731	Visor Cover Pack of 50
5	1001725	Airvisor Min QR Socket
6	1001673	Replacement Regulator Assembly
		(top housing of regulator)
7	1001672	Spare Carbon Cartridge for Waist belt regulator
8	1001674	Replacement Waist belt & bottom housing
		of Regulator
9	1001719	Airvisor QR Plug
10	DHFE-0075	Willson Blueline Hose 7.5m
10	DHFE-015	Willson Blueline Hose 15m
11	1001676	Neck Cover Pack of 5
12	1001738	Tyvek Storage Bag
13	1001733	Tyvek Hood Pack of 5



WILLSON CLEARFLOW FILTER SYSTEMS PORTABLE STAND DCF-0155/T AND WALL MOUNTED DCF-0152/T

(Complete unit no longer available)

Part Description

1001705 Willson Coalescing Filter Element for

Clearflow Filter

1001706 Willson Carbon Element for Clearflow Filter Y Piece Connector with 1/4 BSP Male Thread 1005261

and two 1/4 Female Outlets

1008025 Standard QR Socket Double Action



(Complete unit no longer available)

Part Description

11.009 Wilkerson Coalescing Red Filter Element for

Clearflow system

11.011 Wilkerson Carbon Element for Clearflow System 1005261 Y Socket Piece Connector with 1/4 BSP Male

Thread and two 1/4 Female Outlets

1008025 Standard QR Socket Double Action



Refer Spare Parts Listing for 1007972 Airvisor

AIRVISOR MV COUPLINGS AND FITTINGS

Part Description

High Flow Self Seal Standard Quick Release 1008025

Socket. Double Action, with 1/4" BSP Male Thread

1001719 High Flow Standard Quick Release Plug with 1/4"

BSP Male Thread

1001718 Blanking Plug with 1/4" BSP Male Thread

(For Waistbelt Regulator)

High Flow Self Seal Miniature Quick Release 1001725

Socket with 1/4" BSP Male Thread

1005261 Y-piece Connector with 1/4" BSP Male Thread

and two 1/4" Female outlets

BLUE AIR LINE HOSES FOR ALL AIRVISORS

Part Description

DHFE-0035 Blueline Airhose 3.5m Blueline Airhose 7.5m 1011061 Blueline Airhose 15m 1011062 1008028 Blueline Airhose 30m

YELLOW AIR LINE HOSES FOR OPTIFIT CONVERTIBLE SUPPLIED AIR MODEL. APPROVED TO ASNZS 1716

Part Description

5MTRE342 5M hose w/CEJN Couplings 15MTRE342 15M hose w/CEJN Couplings 20MTRE342 20M hose w/CEJN Couplings 30MTRE342 30M hose w/CEJN Couplings







1008025 double action

1001725

















SCBA - Self Contained Breathing Apparatus

- > Fenzy XPro
- > Fenzy Aeris
- > Fenzy Bio-Scape



Page 41

Sperian Protection manufacture and design the Fenzy Breathing Apparatus range to protect you from hazardous

gases and dangerous atmospheres. From the top of the line Xpro SCBA for fire fighting applications, to the industrial Aeris SCBA or the Bio-S-cape for emergency situations, Sperian have the right BA to suit your needs.

Features of the Fenzy Xpro SCBA

Working in close collaboration with fire brigades and industry professionals for many years has allowed us to manufacture reliable, high performance breathing apparatus using the latest advancements in technology.

> New "Extreme Comfort" harness concept

Manufactured from antistatic polymeric resin, the Ultra-light X-Pro back plate was designed following research into body movement. It provides even weight distribution and optimum comfort for a wide variety of body shapes.

> Two position height adjustment device that adapts to all body sizes



> Back plate swivel follows the movements of the top half of the wearers back



- > Articulated waist belt follows the wearer's hip movements for increased comfort
- > Movable foot prevents damage from knocks to the cylinder valve and pressure reducer





Opti-Pro full mask

Unrivalled comfort and full panoramic vision for a view with optimum optical clarity.

> High quality silicone face piece and internal half-mask for optimal comfort and a perfect fit.

New SX-Pro first breath demand valve

High level breathing comfort and a fast reply time, even with high flow ventilation (positive pressure until 5001/ minute).

- Compact, ergonomic and does not disturb the field of vision
- > Equipped with 2 over sized fixation points for simple connection or removal, even with gloves

Quick-Fix system

> Quickly transform a single cylinder SCBA into a twincylinder SCBA



The unique X-Pro SCBA by Sperian Protection is designed for use under the toughest conditions. Developed by professionals for professionals, the X-Pro is an SCBA tailored specifically to the requirements of firemen.

X-Pro materials are resistant to hostile environments such as extreme temperatures or chemical product ejections, providing unrivalled SCBA endurance and lifespan.



Self-contained breathing apparatus (SCBA)

SCBA Provides the highest level of protection and are commonly used in IDLH environments, firefighting and industrial applications when concentration levels of a contaminant are unknown.



Fenzy Xpro SCBA

Designed specifically to the requirements of firemen for use under the toughest conditions

- > Resistant to hostile environments including extreme temperatures and chemical product ejections, providing unrivalled SCBA endurance and lifespan
- Developed for professional useUltra-light back plate provides
- optimum comfort
- > Opti-Pro mask provides unrivalled comfort and full panoramic vision
- > SX-Pro first breath demand valve provides a high level of comfort
- Quick fix system quickly changes from single to twin cylinder set up
- > Moveable foot prevents damage to the valve and pressure reducer

1823382 X-PRO SCBA WITH
OPTIPRO MASK MEDIUM SIZE
1823365 X-PRO SCBA WITH
OPTIPRO MASK AND ANGEL II
1715029 REPLACEMENT OPTIPRO FULL
FACE MASK MEDIUM SIZE
107573 9 LITRE 200 BAR ALUMINIUM
HOOP WRAP CYLINDER
118245 6.9 LITRE 300 BAR CARBON FIBRE
WRAP CYLINDER



Fenzy Aeris SCBA

User-friendly Aeris keeps you safe in toxic or oxygen-deficient (under 19.5%) atmospheres

- > Allows wearer to breathe safely and comfortably
- Designed for use in all industrial environments
- Zenith demand valve provides automatic air flow at the time of connection to the mask
- > Silicone face piece with polycarbonate lens with anti-scratch coating
- > Flame resistant reflective shoulder straps and fast-adjusting belt buckle
- > Quick adjustable camlock device secures any type of cylinder
- > High pressure gauge with low air warning whistle triggered at 55 bar

1823364 AERIS SCBA WITH BIOMASK MEDIUM SIZE 1814630 REPLACEMENT BIOMASK MEDIUM SIZE

107573 9 LITRE 200 BAR ALUMINIUM HOOP WRAP CYLINDER

118245 6.9 LITRE 300 BAR CARBON FIBRE WRAP CYLINDER



Fenzy Bio-Scape

For emergency escape in the event of an accident resulting in a toxic or oxygen deficient (less than 19.5%) atmosphere

- > Pressure reducer valve with automatic activated air flow
- > Hood with automatic half mask adjustment
- > Warning whistle and option of a 10 or 15 minute cylinder, activates when the pressure reducer valve is triggered, which occurs automatically when the carry bag is opened
- > The air contained in the cylinder is immediately released and a constant flow inflates the hood
- > Triple layer, hi-vis, waterproof, and flame retardant hood
- Synthetic rubber inner half-mask is fully adaptable to all faces
- Inflatable air cushion in the neck performs automatic donning
- > Hi-vis carry bag with Velcro® opening, adjustable neck strap and Integrity seal

1815741 200 BAR, 2L 10 MIN FOR AUST & NZ (CYLINDER INCLUDES LAB APPROVALS) 1815740 200 BAR, 3L 15 MIN FOR AUST & NZ (CYLINDER INCLUDES LAB APPROVALS)

Respiratory Support


Sperian Protection has a comprehensive range of respiratory support materials available. Contact Customer Service if you have any queries or wish to order support items, some of which are shown below:



BR041 Fenzy Breathing Apparatus Brochure




FLY35 Survivair Opti-Fit Convertible Flyer



CD1 Respiratory Contaminant Guide





Sperian Protection Australia Pty Ltd

Now part of Honeywell

43 Garden Boulevard Dingley, Victoria 3172 Australia

Tel: 1300 139 166 Fax: 1300 362 491

New Zealand Tel: 0800 322 200

