

# Clipper Vac® Attachment

## Compatible with Andis® Pulse Ion®



**Step 1** Remove the blade from your clipper to have an open view of the upper housing.

**Step 2** Clean both the top of the clipper and the bottom of the Clipper Vac® Attachment with alcohol to remove any residual oils. Open the small tube of silicone supplied with attachment and place a liberal amount on the entire bottom of the black attachment.



**Step 3** Place the Clipper Vac® Attachment, silicone side down, on the top of your clipper making sure to align the center mark on the attachment with the center mark on the body of the clipper. Press firmly to secure.

**Step 4** If excess silicone has squeezed from under the attachment, trim with a razor blade or other sharp object.

**Note:** *Allow 24 hours before using the clipper to insure a proper seal on the clipper.*

M.D.C. Romani, Inc./Clipper Vac® is not affiliated with, authorized by or endorsed in any way by Andis®.