
# TITAN12L1, 912L (w/1050) **Swing Gate System**

# **ACTUATOR AND CONTROL BOX INSTALLATION:**

### **EXTREMELY IMPORTANT!**

Read entire manual before attempting the installation. This is NOT a "do-it-yourself" project. Use a qualified contractor to install this system. Read all safety information!







FIGURE 1: INSTALLATION OF ACTUATOR TO PIVOT ARM AND GATE BRACKET



Open mechanical release on actuator. 0 Affix Gate Bracket to gate structural support by welding or using bolt/nut.

Manually Set Limits: With actuator mechanical release open, manually push gate to desired close limit, then push to desired open limit, and then push to halfway open position.

Close mechanical release, but do not lock.

Mount Control 8 same side as primary actuator and minimum six feet away from pivot arm (See FIG-URE 2).


Place Battery inside 9 control box with ter-

minals facing toward the front.

CAUTION! Do not mount the control box where the person using the push button on box can come in contact with the gate!

10 Wire actuator to control board: Pass cable through rubber grommets in bottom of control box and wire per diagram at right.

For dual gate, dig trench across drive and run 2nd actuator cable through con-



NOTE: Dual gate: wire Motor 1 and Motor 2 the same way.

# TITAN12L1, 912L (w/1050) Swing Gate System




FIGURE 2: TYPICAL TITAN GATE SYSTEM (PULL-TO-OPEN, DUAL-GATE SHOWN)

Determine BlueBUS photo eye locations: Install, and connect to control board, 100 feet max. See 1050 diagram below.

**POWER INPUTS** 


Attach warning signs to gate.


To power 1050 board, connect battery, optional power supply, and/or solar panels to board. See 1050 diagram below. Run AC power to AC-DC power supply, but do NOT connect AC power directly to control board!

Perform limit learn procedure (below).

Connect audio alarm, then connect other accessories, such as safety loops, strobes, photo eyes, or other safety devices. See FIGURE 3 below.

Program receiver and transmitters: a) Press/hold OXI/A RX button until green LED lights solid, then release. b) Within 10 seconds, press/hold any key on Nice TX until green LED blinks 3 times. c) Wait 15 sec. then press TX buttons to verify operation.





#### TROL BOARD Safety Device Conn. FIGURE 4: ENTERING LEARN MODE (1050 BOARD) **FUNCTIONS** Button LEARN Swing **PRESS** Average BLINKING = Use UP/DOWN Learn Mode UP buttons to Slide **FUNCTION** select "Average" 1. Learn

## **GATE LIMIT LEARN PROCEDURE:**

- Test Gate Conditions: Remove pivot bolt(s) and move gate to open/close positions. Check for free travel without binding, then reconnect actuator(s) to gate.
- 2. Connect power: See INSTRUCTION 13, above.
- Enter Learn Mode: See FIGURE 4. NOTE: With "ENTER" flashing, "OPEN" and "CLOSE" buttons must be held down to operate. Complete Step 4 for each actuator/gate individually (disconnect actuator NOT being adjusted). Reconnect both actuators prior to Step 5.
- 4. Adjust Limit Location: a) Hold down "OPEN" button until desired open position reached. If motion is opposite than desired, switch RED and BLACK wires at motor input. b) Adjust open limit until Limit LED glows GREEN. If illuminated RED, switch ORANGE & WHITE wires at terminal block. c) Hold down "CLOSE" button until desired close position. d) Adjust close limit until Motor Limit LED illuminates RED. e) Hold down "OPEN" until gate at middle of travel. If dual gate, connect both actuator cables to board.
- 5. Commence Limit Learn: In Learn Mode (with "ENTER" still flashing) press "OK" and the following events will occur: a) Partial open. b) Slow travel in close direction. c) Slow travel in open direction. d) Full speed in close direction.

Basic limit programming is complete. See the manual for additional programming.