



NITRO

True Wireless Earbuds



USER MANUAL

Introduction

Welcome to the Wings True Wireless Generation with the all new Wings Nitro. We hope you are as excited as us to feel and flaunt your latest soundwear.

But before you dive right in, we strongly recommend going through this user manual thoroughly as it contains important technical information to ensure you have a seamless audio experience with us. Once you are done reading the manual, we are sure you will be all set to.

FEEL IT! FLAUNT IT!

2

What's In The Box

- 2x Bluetooth Earphones
- 1x User Manual
- 1x Portable Charging Case
- 1x Type-C Charging Cable
- 4x Ear Cushions



S



L



3



How To Pair

- Step 1:** Open the lid of the charging case. The earbuds will automatically power on.
- Step 2:** Both earbuds will auto-pair with each other and enter pairing mode with light flashing white.
- Step 3:** Turn on the Bluetooth on your mobile and pair with device name "Wings Nitro".
- Step 4:** Congratulations! You are now connected and can start playing media.

Note: There is no master earbud and any one earbud can be taken out first and connected with your mobile.

Single Earbud Usage

- Step 1:** Take out any one earbud from the charging case.
- Step 2:** It will automatically power on and enter pairing mode with light flashing white.
- Step 3:** Turn on the Bluetooth on your mobile and pair with device name "Wings Nitro".
- Step 4:** Congratulations! You are now connected and can start playing media.

Note: During mono mode usage, at any time, you can take out the other earbud also and it will autoconnect and move into dual mode.

4

Touch Controls Usage

- Play/Pause:** Single Touch the sensor on any one earbud to pause music. Single Touch on any sensor again to resume playing music.
- Changing Songs:** Double Touch the sensor on right earbud to go to next song. Double Touch the sensor on left earbud to go to previous song.
- Adjusting Volume:** Long Touch the sensor on the right earbud to increase volume. Long Touch the sensor on the left earbud to decrease volume.
- Siri/Google Assistant:** Long Touch the sensor on any earbud for 1 second to activate voice assistant.

Note: Changing songs and adjust volume functions cannot be used in mono mode.

Call Controls

- Answer Incoming Call:** Single Touch the sensor on any earbud to answer incoming call.
- Reject Incoming Call:** Long Touch the sensor on any earbud for 1 seconds to reject incoming call.
- Hang Up After Call:** Single Touch the sensor on any earbud to end an active call.

5

Charging Function

- Charging the Earbuds:** Place the earbuds back into the charging case. Please make sure to close the lid of the case after which earbuds will start charging.
- Charging the Case:** Take the Type-C charging cable. Plug in the Type-C end into the charging case and the other end into a plug point/laptop/powerbank.
- Charging Level Indicators:** When left and right LED light are on, it means that the respective earbuds are charging. When the left or right LED goes off, it means that the respective earbud is fully charged.

The centre LED light show the case battery level as follows :

- 1. Red :** 0-30%
- 2. Yellow :** 30-60%
- 3. Green :** 60-90%
- 4. Fully Charged :** Center led will go off. Now you can take it out from charging port.

Note: Please do not use more than 5V output plug points to charge as it can cause damage to the case and will affect battery life.

Low Battery Warning: When the battery level on the earbuds is low, you will hear a voice prompt " BATTERY LOW ". Please place the earbuds back into the charging case to charge them immediately.

6

Resetting The Device

Please follow the below steps when you see 2 "Wings Nitro" in your bluetooth device menu on your mobile or you can hear music through only 1 earbud. This means the left and right earbuds have not autopaired with each other:

- Step 1:** Switch off your mobile Bluetooth and remove "Wings Nitro" from the list of paired devices in your mobile.
- Step 2:** Put both earbuds back into the charging case.
- Step 3:** While they are in the case, double touch the sensor on both left and right earbud.
- Step 4:** The lights on both earbuds will go off. Close the lid of the charging case.
- Step 5:** Open the lid of the charging case and switch on your mobile bluetooth. Now you will be able to see only 1 "Wings Nitro". Click on the device to connect.

Reset process is now complete and you will be able to hear music through both earbuds.

7

Technical Specifications

- Bluetooth Version: V5.0
- Bluetooth Profile: HSP, HFP, A2DP, AVRCP
- Audio Decoding: SBC, AAC
- Frequency: 20Hz-20000Hz
- Working Range: 10M
- Driver Size: Ø6mm
- Earphone Battery Capacity: 3.7V, 40mAhx2
- Charging Case Battery Capacity: 450 mAh
- Charge Jack: Type C
- Charging Time: 1.5 hours
- Talk Time: 4 hours
- Music Play Time: 4 hours
- Earphone Standby Time: 50 hours
- Charging Case Size: 60.7x51.8x30.2mm
- Sweat and Water Resistant: IPX5
- Earphone Weight: 4.1g each
- Charging Case Weight: 38.1g
- Product Weight: 46.3g

8

Safety And Maintenance

Please read below suggestions in order to helping prolong the product lifespan and clearly understand the warranty clauses:

- Keep the product dry, do not put it in humid conditions to avoid short circuit.
- Do not expose it to the peak sun or high heat for extended period of time as this will short lifespan of electronic components, damage battery and deform some plastic parts.
- Do not put it in cold circumstance to avoid damage to PCB board.
- Do not attempt to dismantle the product, as it maybe unsafe especially for non-professionals.
- Do not use chemical products, detergent, oily liquids to clean the item.
- Do not scratch the surface with sharp items to avoid damaging the case and appearance.
- Do not charge the case for more than 5 hours to avoid loss in battery life.
- Avoid hearing music at maximum volume for long periods of time as this can affect your hearing and is not advisable.

Note: Any damage to the product that is not manufacturing defect will lead to warranty being rendered null and void. Therefore, please take utmost care of your product.

9