



WINGS

# THUNDER



USER MANUAL

## Introduction

Welcome to the Wings Portable Speaker Generation with the all new Wings Thunder. We hope you are as excited as us to feel and flaunt your latest soundwear.

But before you dive right in, we strongly recommend going through this user manual thoroughly as it contains important technical information to ensure you have a seamless audio experience with us. Once you are done reading the manual, we are sure you will be all set to.

FEEL IT! FLAUNT IT!

②

## What's In The Box

1x Portable Speaker  
1x USB Charging Cable

1x User Manual  
1x Warranty Card



③

## How To Pair

**Step 1:** Long press the multifunction button '>' for 3 seconds until you hear a voice prompt. This means the speaker has entered the pairing mode.

**Step 2:** Switch on the bluetooth on your mobile phone (or other device that needs to be connected). The speaker pairing name "Wings Thunder" will be shown on your device.

**Step 3:** Select "Wings Thunder" and the speaker will automatically connect with your device. you will hear a voice prompt, this means that the Thunder is connected to your device.

**Step 4:** The next time you switch on the speaker, it will automatically connect with your mobile.

**Note:** If the speaker remain in pairing mode for 120 seconds without being pairing with any device, then the speaker will automatically switch off. Please retry steps 1 to 4 to pair again.

④

## Switch Modes FM/SD Card

Double Press the multifunction button '>' to switch between Bluetooth and FM/SD Card Mode.

## Stereo Party Mode

For connecting two Thunders into stereo Mode.

**Step 1:** Follow the step 1 of the 'How to Pair' steps for both the speakers to enter the pairing mode.

**Step 2:** Press the multifunction button '>' for any one of the speaker. Now both the speakers are connected with each other.

**Step 3:** Follow the step 2 & step 3 from 'How to Pair' steps. Now both the speakers are connected in the stereo mode with your device.

⑤

## Charging Function

**Charging The Speaker:** Plug in the micro USB cable into the speaker and connect USB port to charging source.

**Charging Time:** Charging time of speaker is 3 hours.

**Note:** Please do not use more than a 5V charging adapter to charge the speakers as higher voltage can destroy the battery and cause heating.

## Call Controls

**Answer Incoming Call:** When there is an incoming call, the speaker will issue a voice prompt, press the multifunction button '>' once to answer the call, or use your mobile phone to answer it.

**Reject A Call:** when there is an incoming call, the speaker will issue a voice prompt, press the multifunction button '>' twice to reject the call, or use the mobile phone to reject the call.

**Hang Up A Call:** Press the multifunction button '>' once or use your mobile to hang up your call.

⑥

## Technical Specifications

Function: Bluetooth/Handsfree/TF card/TWS

Material: ABS+Silica Gel

Charging: USB Micro

Unit Size: 83\*83\*99mm

Net Weight: 290g

Bluetooth: 5.0

Speaker: Ø52MM, 4Ω5W\*1

Bass Diaphragm: Ø52MM

Working Distant: >10M

Frequency: 120Hz-15KHz

Charge: 5V/0.5A MAX

Battery: 1200mAh

Charging Time: About 3 hours

Playing Time: About 4 hours (100%Vol) / 16hours (50%Vol)

⑦

## Safety And Maintenance

Please read below suggestions in order to helping prolong the product lifespan and clearly understand the warranty clauses:

- Keep the product dry, do not put it in humid conditions to avoid short circuit.
- Do not expose it to the peak sun or high heat for extended period of time as this will short lifespan of electronic components, damage battery and deform some plastic parts.
- Do not put it in cold circumstance to avoid damage to PCB board.
- Do not attempt to dismantle the product, as it maybe unsafe especially for non-professionals.
- Do not use chemical products, detergent, oily liquids to clean the item.
- Do not scratch the surface with sharp items to avoid damaging the case and appearance.
- Do not charge the case for more than 5 hours to avoid loss in battery life.
- Avoid hearing music at maximum volume for long periods of time as this can affect your hearing and is not advisable.

**Note:** Any damage to the product that is not manufacturing defect will lead to warranty being rendered null and void. Therefore, please take utmost care of your product.

⑧