



EcoSapiens









Energy Saving

Detachable remote control



Article: ES-411_gr E Model: ENILTH/B/OZ/K-220v Size: 150*180 cm Warranty: 24 months



Infrared Heating Electric Blanket by EcoSapiens, 150*180 cm

USER MANUAL

Dear customer!

Thank you for having chosen the infrared heating electric blanket (150*180 cm). We hope you will enjoy it!

Please read carefully the manual before use.

The electric blanket is a heating device, that is why it is important to know how to use it correctly. We give detailed information about device operation, correct usage and care.

How Infrared Heating Electric Blanket operates (Please read this information. It is important and interesting)

The heating blanket is a modern device for healthy sleep at night or comfortable rest throughout the day. It is designed to create a warm and cozy atmosphere, relax and fall asleep faster. The weight of the blanket uses deep pressure stimulation that helps to improve your mood, reduce stress, increase levels of melatonin, and improve overall sleep quality.

Infrared heating is produced by carbon fiber (not metal wire). Carbon fiber is a unique light and durable material that conducts heat. Unlike heating metal wire, carbon fiber conducts heat in the infrared range that is close to the heat temperature of the human body. Such heat is natural and safe. You will not feel dehydration and dry skin even if you spend a lot of time next to the heating pad

The heating blanket practically does not heat up by itself. If you set the maximum heating mode the blanket will stay cold. It is necessary to touch the blanket in order to feel the warmth. It is important to know that Infrared heating implies warming up the body or subjects but not the air. Therefore, the electric blanket has lower power consumption in comparison with other heating pads.



Precautions

The infrared heating blanket is a household heater that requires gentle use in compliance with all recommendations in the manual. Always disconnect the blanket from the power supply source if you do not plan to use it for a long time. Pay close attention when using the electric heating pad in the following conditions:

- When the blanket is used by children (allowed only under adult supervision);
- When the sensitivity of the skin is diminished;
- When using drugs that cause drowsiness or being under the influence of alcohol
- In case of extreme fatigue;
- In case of diseases when the use of heat is not recommended by a consulting physician.

PROHIBITED:

- Leave switched-on blanket without supervision;
- Use the blanket when it is folded or crumpled
- Stick metal or other objects in the electric heating device;
- Disassemble insulating covers and switchers;
 Use the electric device when the cover is torn and wire or switch are damaged;
- Turn on the wet electric device;
- Unstitch or rip up the blanket;

- · Wash and dry in a washing machine;
- Expose the switched-on heater to moisture:
- Put other heating devices on the device;
- Use by helpless people, people who are not sensitive to heat, people with disabilities and kids unsupervised.

How to use the infrared heating blanket

Electric blanket with infrared heating function is made for warming up at home. It can be used as a bedspread, blanket, or plaid. The heated blanket will help warm yourself up in cold weather and sleep with comfort throughout the whole night!

Place the electric blanket on the bed slightly lower than the pillow. It is designed to keep the head area cool. Prolonged heating of the head is not

The device should be unfolded and without any plaits. Plug the blanket

To warm yourself or your bed choose the maximum mode. The approximate warmup time is 15 minutes. After that regulate the temperature to a comfortable one using the remote control and enjoy soft heating.

- Mode 1 (Min) Low-temperature mode The blanket operates for 8 hours (480 minutes) and then turns off.
- Mode 2 (Med) Medium temperature mode The electric blanket operates for 4 hours (240 minutes) and then turns off.
- Mode 3 (Max) High-temperature mode The electric blanket operates for 1 hour (60 minutes) and then turns off.

When any mode is on, switching to another mode does not increase the total working time (480 minutes). For your safety, the product will turn off automatically after 1, 4 or 8 hours.

If you want to continue warming up turn off the device with the button on the remote control and turn it on again. The warm-up cycle in the selected mode will repeat.

Storage and care

- For the proper operation of the heater, store it at a temperature in the range from -15 to +25°C, in a dry room, in an individual container, without placing other items on top of it;
- Before use, inspect the product for signs of damage (if found, do not use) products and contact the service center);
- To clean the electric pad, disconnect the device from the mains;
- Dry hand wash and hand wash is allowed;
- Light stains can be removed with a damp cloth or a sponge and a small amount of soap;
- Hand wash with soap is allowed only at a temperature below 30 °C and detached remote control:
- Further use is possible only when the blanket dries completely the
- Avoid using clothes pegs and other mechanical attachments when drying;
- It is not recommended to wash the item too often; not more than 5 times during service life.

PRODUCT CERTIFICATE

Operating supply voltage, V Europlug (for UK adapter is included) The heating temperature when in contact with human body (in order to	220; o
feel warmth, press the palm down to the device and hold it for some ti	
	± 5);
medium °C45(±5);
high °C 55 (±5);
Number of temperature modes, pcs	3;
Automatic shut-off timer yes, 480/240/60	min;
	110;
(with rated voltage 220V)	1
Moisture protection level IP10, protection class	ss II;
	£1,8;
Size, cm 150*180 (a tolerance of ± 5 cm is accept	ed);
Wire length, m 1,1 (±10	cm);
Material 100% cot	tton;
Model ENILTH/B/OZ/K-2	20v;
Article ES-411	gr E:
	rey
In a set: electric heated blanket, remote control, user manual, packa	ge.

The product is not intended for medical use.

Produced for EcoSapiens. Manufacturer: GESS MARKET OÜ. Room No. 219, 2nd floor, Tulika 19 (A) 10613 Tallinn, Estonia | EU Place of manufacture: GME Europe Ltd., Ilzenes 2, Riga, LV-1005, Latvia

The service life is 5 years. The warranty period is 24 months. Date of manufacture: see on the sewn-in label.

Exclusive distributor in EU is GESS MARKET OU www.gessmarket.com Please send your inquiries and offers: info@gessmarket.com





Your opinion is important to us! You can always leave a review about the device in the store you purchased the item or send it by e-mail.

Customer service:

E-mail: info@gessmarket.com Tel. number: +372 51990171 Official website: gessmarket.com

