

INFRA SAUNA

INFRARED SPA BLANKET

Size: 180*220 cm

- Device for cosmetology procedures and weight loss
- Natural infrared heating
- 2 heating zones – 1 remote control
- Special durable material
- Overheat protection



5
SERVICE LIFE
YEARS



4 745010 327193



Article: S283_bg E
Model: ENILTH/IS/TZ/K-220v

Infrasauna Two-Zone Infrared Sauna Blanket, EcoSapiens, 180*220 cm

USER MANUAL

Dear customer!

Thank you for having chosen Infrasauna infrared blanket (180*220 cm). We hope you will enjoy it!

Please read carefully the manual before use.


The thermal blanket is a heating device, that is why it is important to know how to use it correctly. We give detailed information about device operation, correct usage and care.

How the infrared sauna blanket operates (Please read this information. It is important and interesting)

Infrared heating is produced by carbon fiber (not metal wire). Carbon fiber is a unique light and durable material that conducts heat. Unlike heating metal wire, carbon fiber conducts heat in the infrared range that is close to the heat temperature of the human body. Such heat is natural and safe. You will not feel dehydration and dry skin even if you spend a lot of time next to the heating blanket.

The heating blanket practically does not heat up by itself. If you set the maximum heating mode the blanket will stay cold. It is necessary to touch the blanket in order to feel the warmth. It is important to know that Infrared heating implies warming up the body or subjects but not the air. Therefore, the electric blanket has lower power consumption in comparison with other heating blankets.

Label signs explanation



Precautions

The infrared heating blanket is a household heater that requires gentle use in compliance with all recommendations in the manual. Always disconnect the blanket from the power supply source if you do not plan to use it for a long time. Pay close attention when using the electric heating blanket in the following conditions:

- When the blanket is used by children (allowed only under adult supervision);
- When the sensitivity of skin is diminished;
- When using drugs that cause drowsiness or being under the influence of alcohol;
- In case of extreme fatigue;
- In case of diseases when the use of heat is not recommended by a consulting physician;
- Prevent any liquid leaks on switched-on heater.

PROHIBITED:

- Leave switched-on blanket without supervision;
- Stick metal or other objects in the electric heating blanket;
- Disassemble insulating covers and switchers;
- Use the electric blanket when the cover is torn and wire or switch are damaged;
- Turn on wet electric blanket;
- Unstitch or rip up the blanket;
- Wash and dry in a washing machine;
- Iron;
- Put other heating devices on the blanket;
- Use by helpless people, people who are not sensitive to heat, people with disabilities and kids unsupervised.

How to use cosmetology thermal blanket

Infrared heating blanket for cosmetology has two heating zones – upper and lower one, which can function separately. They are operated by a 2-Zone remote control. The upper zone warms up the area from shoulders to lower abdomen. The lower zone is used for warming up hips, buttocks, and legs.

The electric blanket is used to improve the effect of the body wraps, as well as remove toxins and reduce cellulite, tighten and hydrate the skin. We suggest keeping a diary and taking photos regularly to track the results of your body changes before and after procedures. The blanket is suitable for people up to 180 cm and 100 kg.

The blanket is made of durable water-resistant material. It is easy to clean. The material effectively protects the heating element in case of water or other liquids ingress. With the loop fastener you can fix the upper part of the blanket and adjust for your body..

Place the thermal blanket on the bed slightly lower than the head area. It is designed to keep the head area cool (Prolonged heating of head is not safe for your health). Plug the thermal blanket into the mains. Lie on the blanket according to the recommendations of the procedure and wrap yourself with side parts. Regulate the temperature of Zone 1 and/or Zone 2 to a comfortable one using remote control and enjoy soft heating!

Modes:

- min-1 – the lowest heating level, below body temperature, similar to switched-off position;
- 2-8 – individually chosen levels for your comfortable temperature;
- max-9 – the highest heating level.

For your safety, the product will turn off automatically after 60 minutes. If you want to continue warming up turn off the device with the button on the remote control and turn it on again. The warm-up cycle in the selected mode will repeat.

Storage and care

- For the proper operation of the heater, store it at a temperature in the range from -15 to +25°C, in a dry room, in an individual container, without placing other items on top of it;
- Before use, inspect the product for signs of damage (if found, do not use products and contact the service center);
- To clean the electric blanket, disconnect the device from the mains;
- Dry hand wash and hand wash is allowed;

- Light stains can be removed with a damp cloth or a sponge and a small amount of soap;
- Hand wash with soap is allowed only at a temperature below 30 °C and detached remote control;
Further use is possible only when the blanket dries completely the natural way;
- Avoid using clothes pegs and other mechanical attachments when drying;
- It is not recommended to wash the item too often; not more than 5 times during service life.

PRODUCT CERTIFICATE

Operating supply voltage, V _____ 220;
Europlug (for UK adapter is included)
The heating temperature in contact with human body
(in order to feel warmth, press the palm down to the device and hold it for some time)
minimal °C _____ 35(± 5);
maximal °C _____ 55 (± 5);
Number of temperature modes, pcs _____ 9;
Automatic shut-off timer _____ yes, 60 min;
Power consumption, Watt _____ 130 (Zone 1 60 Watt, Zone 2 70 Watt);
(with rated voltage 220V)
Moisture protection level: _____ IP21, protection class II;
Weight, kg _____ ±2,5;
Size, cm _____ 180*220 (a tolerance of ± 5 cm is accepted);
Wire length, m _____ 1,35 (±10 cm);
Material _____ nylon (polyurethane);
Model _____ ENILTH/IS/TZ/K-220v;
Article _____ S283_bg E;
Color _____ beige

In a set: electric heated blanket, remote control, user manual, package.

The product is not intended for medical use.

Produced for EcoSapiens.

Manufacturer: GESS MARKET OÜ, Room No. 219, 2nd floor, Tulika 19 (A) 10613 Tallinn, Estonia | EU

Place of manufacture: GME Europe Ltd., Ilzenes 2, Riga, LV-1005, Latvia

Exclusive distributor in EU: GESS MARKET OU www.gessmarket.com
Please send your inquiries and offers: info@gessmarket.com

The service life is 5 years.

The warranty period is 24 months.

Date of manufacture: see on the sewn-in label.

Your opinion is important to us! You can always leave a review about the device in the store you purchased the item or send it by e-mail.

Customer service:

E-mail: info@gessmarket.com

Tel. number: +372 51990171

Official website: gessmarket.com

